



## Sentiotec F2 Bench Sensor Instruction Manual

[Home](#) » [sentiotec](#) » Sentiotec F2 Bench Sensor Instruction Manual 

### Sentiotec F2 Bench Sensor



Installation may only be performed by a qualified electrician or similarly qualified person.

## Contents

### 1 Arrangement

### 2 Installation


### 3 Connection

### 4 Documents / Resources

#### 4.1 References

### 5 Related Posts


## Arrangement



## Installation


### 1. Step:

Drill a hole  $\varnothing 5 - 8$  mm in the middle of a cabin wall panel.  
Keep 150 mm distance to the ceiling.




### 2. Step:

Pull the connecting line (2-wire) coming from the control unit through the hole from the outer side of the cabin.  
Connect and secure with the sensor system plug.




## Connection


Pro B3, Pro C3, Pro D3(i), just sauna combi




[home.com4](http://home.com4)




## K3-next



## K4-next



## Documents / Resources

	<p><a href="#">Sentiotec F2 Bench Sensor</a> [pdf] Instruction Manual Pro B3, Pro C3, Pro D3 i, F2 Bench Sensor, F2, Bench Sensor, Sensor</p>
---	---

## References

- [User Manual](#)

[Manuals+.](#) [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.