



# SIIG 2×1 HDMI 2.0 4K HDR KVM USB 3.0 Switch with Remote Control Instructions

[Home](#) » [SIIG](#) » SIIG 2×1 HDMI 2.0 4K HDR KVM USB 3.0 Switch with Remote Control Instructions 

## Contents

- [1 SIIG 2×1 HDMI 2.0 4K HDR KVM USB 3.0 Switch with Remote Control](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 Mouse Crossing Function and Hot key Enable/Disable Instruction](#)
- [5 Documents / Resources](#)



## SIIG 2×1 HDMI 2.0 4K HDR KVM USB 3.0 Switch with Remote Control



## Product Information

The product is equipped with a Mouse Crossing Function and Hot key Enable/Disable feature. The Mouse Crossing Function allows users to switch between different input sources using a mouse. The Hot key function enables or disables the use of keyboard shortcuts for input source selection.

**The product has two buttons on the front:** PC1 button and PC2 button. The PC1 button is used to enable/disable the mouse crossing switch function, while the PC2 button is used to enable/disable the keyboard hot key function. The product also has a USB port located on the back side.


## Product Usage Instructions

1. Press and hold the PC1 button on the front for about 3-5 seconds to enable or disable the mouse crossing switch function. When booting up, the default setting is on the mouse crossing function. To disable, long press the PC1 button for about 3-5 seconds. To enable it again, long press the PC1 button for about 3-5 seconds. Repeat this cycle as needed.
2. Press and hold the PC2 button on the front for about 3-5 seconds to enable or disable the keyboard hot key function. When booting up, the default setting is to enable the keyboard hot key function. To disable, long press the PC2 button for about 3-5 seconds. To enable it again, long press the PC2 button for about 3-5 seconds. Repeat this cycle as needed.
3. Refer to the product back side interface photo for locating the USB port.
4. Refer to the product front side photo for locating the PC1 button and PC2 button.
5. To disconnect the connection between the PC USB port and PC2 port, simply unplug the USB cable from the product.

## Mouse Crossing Function and Hot key Enable/Disable Instruction


**Keep pressing about 3 ~ 5 sec to enable or disable the feature.**

1. Press the PC1 button on the front about 3 ~ 5 sec to Enable/Disable the mouse crossing switch function. (Short press is select the input source PC1, the default is set on mouse crossing function when booting up, long press the PC1 button about 3 ~ 5 sec to disable, and then long press 3 ~ 5 sec to enable it again, and so on cycle)
2. Press the PC2 button on the front about 3 ~ 5 sec to enable/disable the keyboard hot key function. (Short press is select the input source PC2, the default is set on enable keyboard hot key function when booting up, long press the PC2 button about 3 ~ 5 sec to disable, and then long press 3 ~ 5 sec to enable it again, and so on cycle)
3. Product back side interface (USB port) photo



Disconnect the PC USB port and  
PC2 port connection

4. Product front side PC1 button / PC2 button photo



## Documents / Resources

