



socket Klip for DuraScan 800 Series and 800 Series with FlexGuard User Guide

[Home](#) » [Socket](#) » socket Klip for DuraScan 800 Series and 800 Series with FlexGuard User Guide 



Contents

- [1 socket Klip for DuraScan 800 Series and 800 Series with FlexGuard](#)
- [2 KLIP INSTRUCTION STEP 1](#)
- [3 HOW TO REMOVE SCANNER](#)
- [4 Documents / Resources](#)
- [5 Related Posts](#)

socket Klip for DuraScan 800 Series and 800 Series with FlexGuard



Durascan 800 Series
SocketScan 800 Series with FlexGuard



KLIP INSTRUCTION STEP 1

1. Attach your scanner in the Klip.



Ensure the power button on the side is visible.

DuraScan



FlexGuard



2. Peel and stick it on the desired location of the back of your case.




HOW TO REMOVE SCANNER

Slide scanner and Klip down from the cover piece.



Documents / Resources

| | |
|-------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | <p>socket Klip for DuraScan 800 Series and 800 Series with FlexGuard [pdf] User Guide Klip for DuraScan 800 Series and 800 Series with FlexGuard</p> |
|-------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------|