


TOPDON UltraDiag 2 in 1 Diagnostic Scanner and Key Programmer User Manual

Home » TOPDON » TOPDON UltraDiag 2 in 1 Diagnostic Scanner and Key Programmer User Manual



UltraDiag Quick User Guide



Figure 1




Figure 2

Contents

- 1 Getting Started
- 2 UltraDiag Tablet
- 3 Documents /

Resources

- 3.1 References
- **4 Related Posts**

Getting Started

1. Register & log in

Turn on the UltraDiag tablet and log in to your TOPDON account. (If you do not have an account, please register with your email.)

2. Plug the UltraDiag VCI into the vehicle's DLC

The vehicle's DLC is usually located under the dashboard.

- 3. Turn the ignition to the "ON" position
- 4. Bind the UltraDiag VCI
 - ① Go to User Info > VCI Management. Tap the + icon at the top right corner of the screen, and the device will ask you to connect the Bluetooth first.
 - 2 Connect the Bluetooth as prompted. Then the serial number and activation code will be automatically obtained (see Figure 1).

Then tap Activate to bind the UltraDiag VCI.

5. Connect the UltraDiag VCI to the UltraDiag tablet


The UltraDiag VCI can be connected to the UltraDiag tablet either via wireless (Bluetooth) or wired connection (USB cable) (see Figure 2).



VCF: UltraDiag VCI is successfully connected via Bluetooth

: UltraDiag VCI is successfully connected via USB cable


UltraDiag Tablet



- 1 .Eight-Inch Touch Screen
- 2. Reset Button
- 3. Power Button
- 4. 3.5 mm Audio Port
- 5. RJ45 Port
- 6. USB Type-A Port
- 7. 12V DC Power Supply Input Port
- 8. HDMI Port

- 9. USB Type-C Por
- 10 Screenshot Butt
- 11. Mic
- 12. TF Card Expan
- 13. VCI Slot
- 14. Camera Lens
- 15. Audio Speaker
- 16. Collapsible Star





- 1. Flashing Green: communicating with the vehicle
- 2. Solid Red: power on
- 3. Solid Blue: Bluetooth connected
- 4. USB Type-C Port
- 5. OBD-II 16 Pin Connector

Multilingual User Manual

Thanks for purchasing the UltraDiag automotive diagnostic tool. This quick user guide will walk you through the basic setup and operation of UltraDiag. Please carefully read all theinstructions before use. For further information, please download the detailed user manual via www.topdon.com/products/ultradiag or through the QR code below.

• For detailed user manual, please scan the QR code below.



http://www.topdon.com/products/ultradiag

© TEL	86-755-21612590 1-833-629-4832 (North America)
MEMAIL	SUPPORT@TOPDON.COM
WEBSITE	WWW.TOPDON.COM
f FACEBOOK	©TOPDONOFFICIAL
TWITTER	©TOPDONOFFICIAL

^{*}This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. *Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



Documents / Resources



TOPDON UltraDiag 2 in 1 Diagnostic Scanner and Key Programmer [pdf] User Manual UltraDiag 2 in 1 Diagnostic Scanner and Key Programmer, UltraDiag, 2 in 1 Diagnostic Scanner and Key Programmer, Diagnostic Scanner and Key Programmer, Scanner and Key Programmer, Key Programmer, Programmer

References

• 1 TOPDON Diagnostic Tool UltraDiag – TOPDON TECHNOLOGY Co., Ltd.

