



# TrainWorld 0001325 Handheld Controller Instruction Manual

[Home](#) » [TrainWorld](#) » TrainWorld 0001325 Handheld Controller Instruction Manual 

## TrainWorld 0001325 Handheld Controller Instruction Manual



### Contents

- [1 Introduction](#)
- [2 For Your Protection](#)
- [3 Operation](#)
- [4 SIX MONTH LIMITED WARRANTY](#)
- [5 CONDITIONS](#)
- [6 Service](#)
- [7 Documents / Resources](#)
  - [7.1 References](#)

## Introduction

Thank you for purchasing our MRC handheld controller #0001325. This item is used with the Throttle pack 9900 (#0001310) and Throttle pack 9950 (#0001320). This handheld controller will provide walkaround capability for your DC layout.

## For Your Protection

1. Never reverse a locomotive without stopping it first. To do so may damage the locomotive motor.
2. Unplug your power supply at the end of the day's operation.
3. Children under the age of 14 should be supervised by an adult when operating this product.

## Operation

Your power pack has a built-in jack for the handheld controller. The handheld operates in the same way as the main unit, except it can't set momentum. Only the main unit can set the momentum (on or off). After adding the handheld, your layout will now have two throttles, but only one may be used at a time. You must select either the main unit or the handheld controller to operate the throttle speed.

To select which throttle is active, press the direction button on the handheld. Simply moving the throttle will not activate the controller. For example, if the throttle on the main unit is currently active, and you want to switch to the handheld, just tap the direction button on the handheld. This will make the loco speed follow the handheld setting. Later, if you want to switch back to the throttle on the main unit, just tap the direction button on the main unit. As a precaution, we recommend bringing your locomotive to a stop before making the switch, in order to avoid the locomotive speed abruptly changing; risking damage or derailment.

This product carries a 6-month limited warranty against factory defects.

## SIX MONTH LIMITED WARRANTY

Model Rectifier Corporation (MRC) will, subject to the conditions explained and set forth below, repair at its expense, within six months from the date of sale, any component of this MRC product which is proven defective by reason of improper workmanship or materials. MRC will repair said component(s) without charge for necessary parts or labor. If the unit cannot be repaired, it will be replaced with another unit or similar product of equal or greater value.

## CONDITIONS

1. Limitation to original purchaser and proof of date of purchase: The obligations of MRC set forth herein shall only extend to the original purchaser. The burden of proof as to the date of purchase is on the purchaser, thus it is recommended that you retain your bill of sale or sales receipt and include it with the return of your product, keeping a copy of the same for your records. This bill of sale or sales receipt must have the date of purchase and the name and address of the dealer.
2. Validation of the Warranty: The validity of the above state warranty is contingent upon the original purchaser possessing an original copy of the sales receipt that shows the product's name and/or model number, purchase date, name of the dealer, and the address of the dealer. The burden of proof rests with the purchaser of the product.
3. Exclusions from Warranty: The warranty does not apply to **(a)** any marring, scratching, or defects in decoration and/or finish, **(b)** any damage or defect resulting from misuse, abnormal service, water, or weather damage, **(c)** any damage incurred in shipping and handling, **(d)** any incidental or consequential damage **(s)** caused by or

resulting from a defect in material or workmanship or other equipment failure, **(e)** any damage arising from the product not being used in accordance with the instructions provided. Your sole remedy shall be repair or replacement as herein above expressed. Under no circumstances shall MRC be liable for any losses or damage, direct or consequential, arising out of the use of or inability to use this MRC product. No implied warranty shall continue beyond the six months from the date of purchase. Further, any modification, alteration, or tampering with the MRC product or any repair other than that done at the factory automatically voids the warranty.

4. **Notice:** Some states do not allow limitations on how long an implied warranty lasts or the inclusion of limitation of incidental or consequential damages, so the above state limitations or exclusions may not apply to you. This warranty gives you specific legal rights and you may have other rights which vary from state to state.
5. Customers outside the continental United States, including; Hawaii, Alaska, Canada and Mexico, must contact MRC for return shipping rates for both warranty and non-warranty repairs. Email us at [mrcsupport@modelrectifier.com](mailto:mrcsupport@modelrectifier.com)

## Service

All MRC products have been thoroughly tested before leaving our facility. If for some reason you are having problems with any MRC product, please contact our Customer Service Department using the contact information below prior to sending the unit for service. This gives us the opportunity to troubleshoot issues which may be solved with technical phone support. If the unit needs to be sent for repair customer support will advise the correct fees for service and/or shipping.

If it should become necessary to return any MRC product for warranty repair/replacement, please include a copy of the original sales receipt and a letter with your name, address, daytime phone number, and a detailed description of the problem you are experiencing.

The 6 month limited warranty\* does not include return shipping for customers outside of the continental United States (including Hawaii, Alaska, Canada and Mexico). Customers outside of the continental United States must contact us for return shipping rates.

Questions regarding the 6 month limited warranty\* policy or troubleshooting issues can be directed to MRC Customer Support by calling 1-[732-225-6360](tel:732-225-6360) from Monday to Friday between 8:00am and 5:00pm EST or by emailing [mrcsupport@modelrectifier.com](mailto:mrcsupport@modelrectifier.com)

**Send the product to:**  
Model Rectifier Corporation  
360 Main St. STE #2  
Matawan, NJ 07747 U.S.A  
© 2024 Model Rectifier Corporation



## Documents / Resources

