




VULCAN 490059 Combi FastPAD User Guide

[Home](#) » [Vulcan](#) » VULCAN 490059 Combi FastPAD User Guide 



Contents

1 490059 Combi FastPAD

2 RECIPE DETAIL – AUTO MODE


3 CLEANING / RINSING

4 Documents / Resources


5 Related Posts

490059 Combi FastPAD

ON / OFF

	<p>Switch on: Push the coder 1 second</p> <p>Switch off: Push the coder 3 seconds</p> <p>Settings / adjustments: rotate the cc</p> <p>Settings validation: One push on the</p>
---	--


MANUAL MODE



AUTO MODE




RECIPE DETAIL – AUTO MODE



CLEANING / RINSING

CAUTION: Never use descaling product into the automatic cleaning system.



Note: refer to manual for cleaning and descaling product type to use.



12/2021 Code 490059 / F49544

Documents / Resources



[VULCAN 490059 Combi FastPAD](#) [pdf] User Guide
490059 Combi FastPAD, 490059, Combi FastPAD, FastPAD