

Wagner SprayTech FLEXiO iSpray Quick Start User Guide

Home » Wagner » Wagner SprayTech FLEXiO iSpray Quick Start User Guide

Contents

- 1 Wagner SprayTech FLEXiO iSpray Quick Start User Guide
- 2 Before You Spray
 - 2.1 Choose the Right Nozzle
- 3 Setup
- **4 Set Material Flow Control**
- **5 Set Pattern Direction and Width**
- 6 Two-Speed Switch
- 7 Spray
- 8 Clean
- 9 Questions about your Manual? Post in the comments!9.1 Related Posts

Wagner SprayTech FLEXiO iSpray Quick Start User Guide



Before You Spray

Prepare Surface and Mask

Prepare the surface you will be spraying and properly mask painting area.

Choose the Right Nozzle

This FLEXiO® sprayer comes with two spray nozzles designed to help you complete a variety of projects. iSpray® Fast coverage, large areas, thicker paints.

Detail Finish

Small projects, fine finishing, thin paints or stains.

Wagner SprayTech Corporation continually improves its products, therefore, there may be slight variations in appearance from those shown here.

Results may vary depending on coating, surface and experience.

Setup



Fill Cup Paint or stain (oil-based or latex).



Connect Nozzle
Turn and click.

Set Material Flow Control



iSpray Start low (1-6) to practice and turn up (7-12) for fast covering.



Detail Finish Turn left to decrease material flow and right to increase it.

Set Pattern Direction and Width



Adjust Pattern
Rotate for horizontal
or vertical spray
patterns.



Width Selector Adjust for wide or narrow pattern.

Two-Speed Switch



High SpeedFor paints and thicker materials.



Low Speed For stains.

Spray

Quick Tip

Before spraying your home or furniture, do a test spray with water or use a spray poster.



Point and Pull
Point gun straight at
surface, pull trigger.



Stay Close Keep nozzle 6-8" from surface. Use full passes.

Note: See product manual for more information on spraying technique.

Quick Tip

Wipe the tip frequently to remove dried paint.

Clean

Note: Paint will smooth out as it dries.



Disconnect Nozzle
Pour remaining
paint back into can
and wash all parts.



Clean Thoroughly
Be sure to clean
the suction tube air
hole (see picture)
located near the
top and fully remove
dried paint.

Quick Tip

Use soapy water for latex coatings and use mineral spirits for oil-based coatings.

Go to wagnerspraytech.com for more information and more tips for spraying or call 1-800-328-8251 for live help.

Read More About This User Manuals...

Wagner-SprayTech-FLEXiO-iSpray-Quick-Start-Guide-Optimized.pdf

Questions about your Manual? Post in the comments!

Manuals+,