



WATTS 2915949 Push to Connect Coupling



Contents [[hide](#)]

- [1 Important Information](#)
- [2 To Connect](#)
- [3 To Disconnect](#)
- [4 Customer Support](#)
- [5 Documents / Resources](#)
 - [5.1 References](#)

Important Information

Ensure that there are no scratches, gouges or any form of damage on the circumference

of the tubing within 1 in. (25.4 mm) of the cut end. Damage in this area may cause leakage.

Check the fitting for any signs of damage or foreign objects.

When a joint has to be disassembled and then reused, ensure the tubing that was removed from the joint has no damage on the circumference with 1 in. (25.4 mm) of the end. Inspect the tube and fitting for any signs of damage and ensure they are free of foreign materials. The joint can then be reassembled.



CAUTION

The polypropylene material used in the Push-to-Connect fittings can be compromised by exposure to volatile organic compounds (VOC's) and caustic chemicals.

Therefore, DO NOT expose this product to any such chemical or foreign substance, which would include exposure to the following products: Pipe Dopes (thread sealants), leak check compounds, bug sprays, lubricants, cleaners, paints, bleaches, acids, solder fluxes, plastic piping primers and cements, oxidizing agents, alkaline solutions, thinners, fuels, oil based caulks, hydrocarbons, spray foam or foaming agents (i.e.insulation).

NOTICE

Failure to follow these instructions will void the warranty and possibly result in leaks and water damage.


Please read and retain these instructions.

Instructions for use of Mini Series AquaLock™ fittings:


To Connect: Cut tubing or pipe to desired length. Make sure that tubing or pipe is cut squarely, and all burrs are removed. Push fitting onto end of tube or pipe. Fitting will grip before it seals. Ensure that tubing or pipe is pushed into the fitting until the end is fully seated into the internal tube stop.

To Disconnect: Press collet squarely against face of fitting. With collet depressed, pull tubing to remove from fitting. Fitting may be reused.

To Connect



To Disconnect



Customer Support

IS-AQ Mini Series 2016

EDP# 2915949

Warranty information @watts.com.



Documents / Resources



[WATTS 2915949 Push to Connect Coupling \[pdf\]](#) User Manual

2915949 Push to Connect Coupling, 2915949, Push to Connect Coupling, Coupling

References

- [User Manual](#)

2915949, 2915949 Push to Connect Coupling, Coupling, Push to Connect Coupling,

WATTS WATTS

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.