



# WRIGHT PRODUCTS V2010BL Hold-Open Closer Instruction Manual

[Home](#) » [WRIGHT PRODUCTS](#) » WRIGHT PRODUCTS V2010BL Hold-Open Closer Instruction Manual 



## INSTALLATION INSTRUCTIONS FOR EZ-HOLD™ DOOR CLOSERS V2010BL, V2010WH, V2012BL, V2012WH

### Contents

- [1 INSTALLATION INSTRUCTIONS](#)
- [2 OPERATING INSTRUCTIONS](#)
- [3 FULL FIVE YEAR WARRANTY](#)
- [4 Documents / Resources](#)
  - [4.1 References](#)
- [5 Related Posts](#)

## INSTALLATION INSTRUCTIONS

**Note:** Before installation, check door to see that it closes freely.

**Step 1** – On hinge side of door, at the desired height, fasten the jamb bracket to the door jamb using (4) long screws. The open side of the bracket should be 1/4" from door as shown. (See Fig. A) If replacing an existing closer, use existing jamb bracket screw holes if possible.


**Step 2** – Using short connecting pin, connect closer to FRONT hole in jamb bracket. (See Fig. B) Pull out closer rod until the point of the arrow on the rod is just past end of closer. Push button and let closer close. Check that arrow is aligned with end of closer. This will give proper tension for installation. (Do not change until installation is completed.) (See Fig. C) NOTE: If arrow is not lined up properly, simply pull out closer rod to release hold open feature, allow closer to retract fully, and repeat the process.



**IF REPLACING AN EXISITING CLOSER SKIP STEP 3 AND GO TO STEP 4**




**Step 3** – Attach door bracket to closer tube with long connecting pin. (See Fig. D) With door tightly closed, hold closer and door bracket against door in a level position. Pencil outline of door bracket onto door. (See Fig. D) Remove door bracket from closer and place it on door in previously marked location, making sure that bracket is in the correct position. (See Fig. D) Mark and drill (2) 1/8" pilot holes. **CAUTION:** Do not drill holes all the way through the door. Fasten door bracket to door with short screws. Reconnect door bracket to closer with long connecting pin. Push door slightly open and release. Closer is now ready to operate. (See Fig. F)

**Step 4** – Attach door bracket to closer tube with long connection pin. (See Fig. E) With door tightly closed, hold closer and door bracket against door in a level position. Pencil outline of door bracket onto door. Remove door bracket from closer and place it on door in previously marked location, making sure that bracket is in the correct position. (See Fig. E) If one of the mounting holes from the previous installation is visible in the door bracket slot or hole, use this existing hole for one of the mounting screws. (See Fig. E) Mark locations of other hole and drill (1) 1/8" pilot holes.

**CAUTION:** Do not drill holes all the way through the door. Fasten door bracket to door with short screws. Reconnect door bracket to closer with long connecting pin. Push door slightly open and release. Closer is now ready to operate. (See Fig. F)







## OPERATING INSTRUCTIONS

Hold open feature – To activate hold open feature, press button (See Fig. C), and open door to desired location. To release, simply open door slightly further, and release.

Speed Adjustment – To regulate closing speed of door, turn adjusting screw counter-clockwise for faster and clockwise for slower. (See Fig. D)

Snap Action Closing – Installed as directed above, the door is in the maximum latching position. For a smoother and quieter latching, hold door open about 8" push button. (See Fig. C) Remove the short connecting pin from the jamb bracket and relocate closer in rear hole. (See Fig. B) Push door slightly open release. (See Fig. C)

## FULL FIVE YEAR WARRANTY



For warranty details or to make a warranty claim for repair or replacement, please visit [www.hampton.care](http://www.hampton.care) or contact Hampton Care at 1-800-562-5625. Return of defective product and receipt may be required for warranty claims.



50 Icon, Foothill Ranch, CA 92610-3000

email: [info@hamptonproducts.com](mailto:info@hamptonproducts.com)


[www.hamptonproducts.com](http://www.hamptonproducts.com) • 1-800-562-5625

©2022 Hampton Products International Corp.

95000000\_REVE 08/22

---

## Documents / Resources



[WRIGHT PRODUCTS V2010BL Hold-Open Closer](#) [pdf] Instruction Manual  
V2010BL Hold-Open Closer, V2010BL, Hold-Open Closer, Open Closer, Closer

## References

- [Hampton Products | Home](#)