



Yealink SIP-T29 High-End Color Screen IP Phone Installation Guide

[Home](#) » [Yealink](#) » Yealink SIP-T29 High-End Color Screen IP Phone Installation Guide 

Yealink

Contents

- [1 SIP-T29 High-End Color Screen IP Phone](#)
- [2 Documents / Resources](#)
- [3 Related Posts](#)

SIP-T29 High-End Color Screen IP Phone


Hookswitch Tab Installation Guide for SIP-T29_T27_T4X IP Phones

The IP phone is packaged with the hookswitch tab in the desk mount position. Before mounting the IP phone to a wall, you must set the hookswitch tab to the wall mount position.

To adjust the hookswitch tab:

1. Pull the hookswitch tab in the handset cradle.
2. Rotate the hookswitch tab 180 degrees.
3. Reinsert the hookswitch tab.


Adjust the hookswitch tab as shown below (Take a SIP-T46G IP phone as an example):



The hookswitch tab has a lip that allows the handset to stay on the hook when the IP phone is mounted vertically.

Hookswitch Tab Installation Guide

Documents / Resources

	<p>Yealink SIP-T29 High-End Color Screen IP Phone [pdf] Installation Guide SIP-T29, High-End Color Screen IP Phone, SIP-T29 High-End Color Screen IP Phone</p>
-------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------