

# 8BitDo Retro 18 Numeric Keyboard Instruction Manual





## Contents

- [1 Instruction Manual](#)
- [2 Retro 18 Mechanical Numpad](#)
  - [2.1 Number Lock on/off](#)
  - [2.2 2.4G Connection](#)
  - [2.3 Wired Connection](#)
  - [2.4 Bluetooth Connection](#)
  - [2.5 Calculator Mode](#)
  - [2.6 Battery](#)
  - [2.7 Ultimate Software V2](#)
  - [2.8 Support](#)
    - [2.8.1 RF Exposure](#)
- [3 Documents / Resources](#)
  - [3.1 References](#)
- [4 Related Posts](#)

## Instruction Manual

## Retro 18 Mechanical Numpad



- **System requirement:** devices that support Bluetooth® Low Energy or USB port.

1. Mode switch
2. Pair button
3. Connection indicator
4. Windows calculator shortcut
5. Calculator mode button
6. Calculator mode indicator
7. SOC (%)
8. Power LED
9. INPUT (W)
10. 2.4G adapter / Adapter compartment
11. Charging port (USB Type-C)

## Number Lock on/off



hold



hold

## 2.4G Connection



1. Turn the **Mode switch** to **2.4**.



2. Connect the 2.4G adapter to the USB port of your device.
3. The **Connection indicator** will remain solid for 8 seconds and then go off to indicate a successful connection.

❗ Follow the steps below to re-pair the numpad with the adapter:


1. Turn the **Mode switch** to **2.4**
2. Connect the 2.4G adapter to the USB port of your device.
3. Hold the **Pair button** for 3 seconds to enter the pairing mode, the **Connection indicator** starts to blink rapidly.
4. Wait for the numpad to automatically pair with the adapter. The **Connection indicator** will remain solid for 8 seconds and then go off to indicate a successful connection.

## Wired Connection

OFF



1. Turn the **Mode switch** to **OFF**.



2. Connect the numpad to the USB port of your device using the USB cable and wait until the numpad is successfully recognized by your device before using it.


### Bluetooth Connection



1. Turn the **Mode switch** to **BT**.



2. Press and hold the **Pair button** for 3 seconds until the **Connection indicator** blinks rapidly to enter the pairing mode. (Pairing is only required for first-time connection.)



3. Go to your device's Bluetooth list and pair with [**8BitDo Retro 18 Numpad**].

4. The **Connection indicator** will remain solid for 8 seconds and then go off to indicate a successful connection.

### Calculator Mode

- All keys on the numpad will transform into regular calculator function keys when the “**Calculator mode**” is activated. All keys will not be recognized by your connected device.

Press the **Calculator mode button** to enter the Calculator Mode, the **Calculator mode indicator** will become solid. The **Calculator mode indicator** will turn off when switching between connection modes, powering off, or pressing the **Calculator mode button** to exit the Calculator Mode.

### Battery

Status –		Power status indicator –
Low battery	→	LED blinks
Battery charging	→	LED breathing
Fully charged	→	LED stays solid

Built-in 1000mAh rechargeable lithium polymer battery with 160 hours of playtime, with a charging time of 4 hours.

## Ultimate Software V2

Please visit [app.8bitdo.com](http://app.8bitdo.com) to get the 8BitDo Ultimate Software V2, which allows you to customize key mapping, macro, and more.

## Support

Please visit [support.8bitdo.com](http://support.8bitdo.com) for further information and additional support.



Manual



## FCC regulatory conformance:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

**NOTE:** This equipment has been tested and found to comply with the limits for a **Class B** digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

**NOTE:** The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

## RF Exposure

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

## IC regulatory conformance

This device complies with CAN ICES-003 (B)/NMB-003(B).


This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following

- two conditions:
- (1) this device may not cause harmful interference, and
  - (2) this device must accept any interference received, including interference that may cause undesired operation.

**RF Exposure**

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment.

**Documents / Resources**

	<a href="#">8BitDo Retro 18 Numeric Keyboard</a> [pdf] Instruction Manual Retro 18, Retro 18 Numeric Keyboard, Numeric Keyboard, Keyboard
---	--

**References**

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.