



B74 Back Box
Mounting Base



i3 B74 Back Box Mounting Base User Manual

[Home](#) » [i3](#) » i3 B74 Back Box Mounting Base User Manual 

Contents

- [1 i3 B74 Back Box Mounting Base](#)
- [2 DIMENSIONS](#)
- [3 INSTALLATION](#)
- [4 Documents / Resources](#)
 - [4.1 References](#)



i3 B74 Back Box Mounting Base



Back Box Mounting Base

The B74 v2 is an extension back box for cable management used for surface mounting of the i3's M74 camera series.

PACKAGE CONTENTS




Fig. 1. Accessories

In addition to this guide and B74 back box, the packing box includes:

1. Round head screw, machine type x4
2. Plastic anchor x3
3. Round head screw, tapping type x3
4. Mounting template x1

DIMENSIONS




Fig. 2. B74 v2, Dimensions

INSTALLATION NOTES

- To ensure the IP67 waterproof rating, use the provided waterproof RJ45 connector.
- Choose the appropriate mounting surface and hardware.
- Remove RP1 for DB60 wall mount gooseneck bracket, or EMT pipe.
- Exchange RP1 with the metal plug for side conduit use.
- Apply sealant on all outdoor threads (refer to Fig. 3).
- For direct surface mounting, secure tapping screws to compress the 'O' ring.
- For a proper seal in RP1, use a network cable with a diameter of 5mm or more.

INSTALLATION

Use the hex bit to loosen the set screw securing the camera module to the socket housing and pull the camera's mounting base away from the socket housing.


Surface Installation

1. B74 v2 comes with three 90% pre-drilled hole dimples. Depending on the type of installation and mounting surface, complete drilling 2-3 holes.
2. Attach the mounting template (4) to the mounting surface.
3. Use template to drill holes in the mounting surface, to match the B74 v2 holes pre-drilled in Step 1.
4. Insert anchors (3) into the holes.
5. Use the template to drill the conduit hole for the camera cable, if using. If using the side conduit opening, do not drill the conduit hole and swap RP1 and the side conduit metal plugs.
6. Secure the B74 v2 back box to the mounting surface using the tapping screws with the O-ring (2). Tighten to fully compress the 'O' ring.
7. Use the round head machine screws (1) to secure the mounting base to the back box.
8. Pull the camera's cable into the B74 v2 back box.
9. Rotate the camera module inside the housing socket to achieve the preferred view angle.
10. Re-tighten the set screw to secure the camera module in position.

DB60 / Pendant Installation (Fig. 3)

Note: Do not drill holes in B74 v2 for this installation.

1. Remove RP1 from the top cable opening and pull the camera's cable through and into the DB60 or the 3/4" EMT pipe.
2. Attach B74 v2 to the DB60 or to the 3/4" EMT pipe (using a conduit fitting). Add sealant to all threads as shown in Fig. 3.
3. Use the round head machine screws (1) to secure the M74 camera mounting base to the M74 v2 back box.
4. Re-attach the camera to the mounting base and re-tighten the set screw to secure it.
5. Rotate the camera module inside the housing socket to achieve the preferred view angle.
6. Re-tighten the set screw to secure the camera module in position.



- Scan this QR code or visit
- <https://i3international.com/support/documentation> to view additional documentation.



- Contact our Technical Support team at: 1.877.877.7241 or support@i3international.com if you have any questions or concerns regarding camera installation or if you require software services or support.

Documents / Resources



[i3 B74 Back Box Mounting Base](#) [pdf] User Manual
B74 Back Box Mounting Base, B74, Back Box Mounting Base, Mounting Base, Base

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.