



## mi Window and Door Sensor User Manual

[Home](#) » [Mi](#) » mi Window and Door Sensor User Manual 

*mi Window and Door Sensor User Manual*

# Mi Window and Door Sensor User Manual




## Contents

- [1 Product Overview](#)
- [2 Connecting with Mi Home / Xiaomi Home App](#)
- [3 Installation](#)
- [4 Specifications](#)
- [5 Documents / Resources](#)
- [6 Related Posts](#)

## Product Overview

Mi Window and Door Sensor detects the opening or closing of an object, including door, window, drawer, and wardrobe. It features a built-in reed switch, enabling precise detection of opening or closing. Based on the status change detected, it can realize automatic control over other smart devices via the hub to intelligently perform various scenarios. This product is for indoor use only, and needs to be used along with a device with gateway capabilities.



## Connecting with Mi Home / Xiaomi Home App

This product works with Mi Home / Xiaomi Home app\*. Control your device with Mi Home / Xiaomi Home app. Scan the QR code to download and install the app. You will be directed to the connection setup page if the app is installed already. Or search “Mi Home / Xiaomi Home” in the [app Store](#) to download and install it. Open Mi Home / Xiaomi Home app, tap “+” on the upper right. Select “Mi Window and Door Sensor”, and then follow prompts to add your device. The app is referred to as Xiaomi Home app in Europe (except for Russia). The name of the app displayed on your device should be taken as the default.



[http://home.mi.com/do/index.html?  
model=lumi.sensor\\_magnet.v2](http://home.mi.com/do/index.html?model=lumi.sensor_magnet.v2)

Note: The version of the app might have been updated, please follow the instructions based on the current app version.

## Installation

Effective Range Test: Press the reset button at the desired location. If the hub beeps, it indicates that the sensor

can communicate effectively with the hub.

(1) Remove the protective film (an additional adhesive sticker can be found inside the box) to stick it at the desired location.

(2) Align the marks on the side of the sensor and the side of the magnet as much as possible.


(3) Stick both pieces on the desired location. It is recommended to install the sensor on the frame of the door or window, and the magnet on the moveable part of the door or window. Make sure the clearance between them is less than 22 mm when the window or door is closed.

\*Make sure the surface is clean and dry.


\*Do not install them on any metal surface.



(1) Remove the protective film.



(2) Align as much as possible.



(3) Make sure the clearance is less than 22 mm.

## Specifications

Model: MCCGQ01LM Item

Dimensions: 40.8 × 20.8 × 11 mm

Wireless Connectivity: ZigBee

Battery Type: CR1632

Operating Temperature: -10°C to 50°C

Operating Humidity: 095% RH,  
non-condensing

Maximum Transmit Power: 10.5 dBm

Working Frequency: 2405 MHz~2480 MHz



Hereby, Lummi United Technology Co., Ltd., declares that the radio equipment type [Mi Window and Door Sensor, MCCGQ01LM] is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address:

<http://www.mi.com/global/service/support/declaran.html>



All products bearing this symbol are waste electrical and electronic equipment (WEEE as in directive 2012/19/EU) which should not be mixed with unsorted household waste. Instead, you should protect human health and the environment by handing over your waste equipment to a designated collection point for the recycling of waste electrical and electronic equipment, appointed by the government or local authorities. Correct disposal and recycling will help prevent potential negative consequences to the environment and human health. Please contact the installer or local authorities for more information about the location as well as terms and conditions of such collection points. Symbol for "ENVIRONMENT PROTECTION Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your local Authority or retailer for recycling advice".



Symbol on the product or on its packaging indicates that this product may not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment.

## Documents / Resources



[mi Window and Door Sensor](#) [pdf] User Manual  
Mi, Window and Door Sensor