


# **NB F80 LCD LED Monitor Installation Guide**

Home » NB » NB F80 LCD LED Monitor Installation Guide 🖫




#### **Contents**

- 1 F80 LCD LED Monitor
- 2 A-1 Table edge


### installation

- 3 A-2 Grommet installation
- 4 B Directional usage guide
- **5 C Cable routing**
- **6 D Display installation**
- 7 E Torque adjustment
- 8 F Setting tilt angles
- 9 G Display rotation
- 10 Documents / Resources
  - 10.1 References

### **F80 LCD LED Monitor**





<sup>\*</sup> Optional



## A-1 Table edge installation


**Warning** Ensure screws are secured firmly






A-2 Grommet installation


Warning Ensure screws are secured firmly



## **B** Directional usage guide




Working load 2~9 kg




For table edge	For grommet	
----------------	-------------	--


# C Cable routing





# D Display installation



(1) VESA:75x75mm,100x100mm










Ensure screws are secured firmly


## E Torque adjustment




- 1. If display can be hovered at any height after display installed. No adjustment needed.
- 2. If display lift up automatically after display installed, adjust the following: One man hand press down the screen,

- the other wind set screw at the bottom of upper arm at joint to '-' direction to reduce torque by using F, 5mm. Allen key as shown in Fig-1 and 2 until display can be hovered at any point of positions.
- 3. If display sit at the lowest position after installation, repeat #2 procedu res but winding set screws to ' + ' direction to increase torque as Fig-1 and 2 until display can be hovered at any point of positions.

## F Setting tilt angles




**G** Display rotation



Only display comes with central gravity will has the best performance



- 1. Do not adjust tension without putting on display
- 2. Ensure display has been put onto mount
- 3. Working load 2~9 kg



F80
Desk mount with gas spring
Display size: 17" ~ 30"
Max load : 2 ~ 9 kg
VESA: 75×75, 100×100 mm

Severe personal injury and property damage can result from improper installation or assembly Read the following warning carefully before beginning.

- Products must be installed by professional or installer.
- If you do not understand the instructions or have any concerns or questions, please contact a qualified local installer.
- Do not install or assemble if the product or hardware is damaged or missing, if you require replacement parts, please contact you local distributor for assistance.
- This product fits most 17"-30" LCD / monitor; maximum weight of LCD / monitor: 9 kg.
- Installer-friendly and straight forward.
- For safe installation, the desk you are mounting to must support minimum 3 times the weight of the total load (the mount, the monitor and all accessories weight).
- Do not use this product for other than the original designed.
- This product contain moving parts, please use with caution.
- When installing monitor, please do not damage electrical wiring or power source.
- Installation and routing of monitor cables on the monitor bracket must comply with electro-technical regulations.
- Importantly, mains- and data-cables must be secured against twisting and squeezing or shearing.
- The manufacturer will bear no responsibility to the desk of mounting, or incidental or consequential damages arising thereof.
- The manufacturer disclaims any liability for the modifications, improper installation, or installation over the specified weight range. The manufacturer will not be liable for any damages arising out of the use of, or inability to use, the product.
- This product is designed for indoor used only, use of this product outdoor could lead to product failer and severe personal injury.
  - ▲ This product contains a high pressure gas spring, fire and percussion prohibited. Also it is strictly prohibited to dismantle without professionals. Please return to the manufacturer or hand over to professional agencies if the product is abandoned. In order to ensure the performance of gas spring, full direction adjustment of the product arm is recommended several times per month.
  - ▲ All images are for reference only. As product in kind prevail.

We reserve the right to modify or alter instructions. No modification or alteration without formal notice.



#### www.nbavmount.com

Kunshan Hongjie Electronics Co., Ltd

1050, Fu chun Jiang Road, Economic Development Zone, Kunshan City, Jiangsu Province, China 215333

Mail: <a href="mailto:info@nbavmount.com">info@nbavmount.com</a>

www.nbavmount.com

ERGOsolid	ERGOSOLID SARL 36 rue du Louvre 75001 Paris, France Tel. (+33)7 72 15 51 60 www.ergosolid.fr
ERGOSOLIC	Ergosolid Italia S.R.L Via Giosuè Carducci 32 – 20123 Milano, Italia Tel. +39 02 5656 8661 www.ergosolid.it
FIBERNOVELTY	Fiber Novelty ul. Boya Żeleńskiego 15 35-105 Rzeszów, Poland tel. +48 17 787 60 70 www.fibernovelty.pl

### **Documents / Resources**



NB F80 LCD LED Monitor [pdf] Installation Guide F80 LCD LED Monitor, F80, LCD LED Monitor, LED Monitor, Monitor

### References

- 9 Bienvenue dans notre boutique en ligne Ergosolid.
- 9 Supporti per TV, Monitor e Proiettori
- Signatur Uchwyty do Telewizorów i Mobilne Stojaki TV Sklep

Manuals+,