



Acekool CW-100 Refrigerating Showcase Instruction Manual

Home » ACEKOOL » Acekool CW-100 Refrigerating Showcase Instruction Manual



Contents

- 1 Acekool CW-100 Refrigerating Showcase
- **3 General Information**
- **4 Structure and Parts**
- **5 Handle and Erection**
- **6 Preparation and PowerSupply**
- 7 Use and Caution
- 8 Maintenance
- 9 Trouble Shooting
- 10 Principle of Refrigeration System and Electric Circuit
- 11 Circuit Diagram
- 12 Major Parameters
- 13 Documents / Resources
 - 13.1 References



Acekool CW-100 Refrigerating Showcase



Models



CW-100





CW-120R/CW-160R


CW-120/CW-160

Thank you for choosing and purchasing our product. Please carefully read the operation instructions before use for a correct application and satisfactory effect.

General Information

- 1. Top brand fully enclosed compressor is used on the desktop refrigerator. The refrigerant R290/R134a is an environmentally friendly agent. It features a rational configuration of a refrigeration system with blower forced air cooling. The temperature is quite even inside the refrigerator.
- 2. Double hollow transparent glasses are used on the door and body. It features an artistic and elegant appearance, perfect perspective and easy. access.
- 3. It has a wide application in department stores and houses as well as in the meeting room and sitting room.


Structure and Parts



Handle and Erection

· Handle with care

Unplug the wall socket first. Never tilt it over 45 degrees during handling.




Dry place

Always locate the refrigerator in a dry place.




Sufficient space

The distance from both sides and back of the refrigerator to the wall or other substance must be more than 10cm. The refrigeration capability might be decreased if its surrounding space is too small to circulate air.




Well ventilation

Always locate the refrigerator in a place with fine ventilation. For first-time use, wait for 2 hours after handling and then plug the wall socket and start it.




· Far from heat source

Never place the refrigerator directly under the sunshine. Never locate it nearby any heat source or heater to prevent it from reducing refrigeration capability.




· No heavy load

Never put any heavy load on the top of the refrigerator.




· No hole making

Never make a hole in the refrigerator. Never install other matter on the refrigerator.



Stable location

To avoid unexpected noise and vibration, Unpack and locate the refrigerator in a flat and solid place.



Preparation and PowerSupply


• Exclusive power socket

Normally, the power supply should be 110-120V,60Hz single phase AC with exclusive single phase three pin receptacle.




· No share on socket

Never let the refrigerator share the common socket with other appliances, otherwise the cable becomes hot and fire might be resulted



Protect cables

Never break or damage the cables otherwise current leakage and fire might be resulted.




· No water flushing

Never give the refrigerator surface a flush otherwise current leakage might have resulted.




• Prevent flammables and explosive

Never put any flammable or explosive inside the refrigerator such as ether, gasoline, alcohol, adhesive, or explosives. Never put dangerous products near the refrigerator.



• No spray

Spray the flammables such as paint or coating near the refrigerator is not allowed, otherwise, a fire might result.



After power break

After power break or unplugging the refrigerator, always wait at least 5 minutes and then you may plug the refrigerator and start it again.



• No medicine

No medicine is allowed to be kept inside the refrigerator.




Use and Caution

1. Before use:

Plug the refrigerator on 110-120V— exclusive socket. After the refrigerator running, put your hand on the air suction to confirm it is sufficiently cold. Then you may put food inside the cold box.

2. Digital temperature controller



Features of function

- It is a mini-sized and integrated intelligent controller and applies to the compressor of one HP.
- The main functions are: Temperature Display/Temperature Control/Manual, automatic defrost by turning off/illumination Control/Value Storing /Self Testing /Parameter Locking

Front panel operation

1. Set temperature

• Press the **SET** button, the set temperature is displayed.

- Press or button to modify and store the displayed value.
- Press the set button to exit the adjustment and display the cold room temperature.
- 2. If no more button is pressed within 10 seconds, the cold-room temperature will be displayed.
- 3. Illumination: Press the button, and it lights; Press again, and it stops. Manual start/stop defrost: Press the button and hold for 6 seconds to defrost or stop defrost.
- 4. Refrigerant LED: During refrigeration, the LED is on; When the cold room temp. is constant, the LED flashes.
- 5. Defrost LED: during defrosting, the LED is on; When it stops defrosting, the LED is off.
- 6. Digital controller reset

When the display shows "Disorder", press the" button for 2s until the buzzer rings, and quickly Press the" button for 6s until the buzzer rings again, the display will flash for 3s, and it restores the factory setting.

Cautions

- Shortening the door opening time and reducing open frequency is good for keeping a cold temperature inside the refrigerator.
- Never block the air suction and outlet. Keep air circulation and refrigeration capability.
- Do not make food congested as it will influence the cooling effect.
- Adjust the rack height for proper food storage.
- Cool the hot food down to room temperature before you put it into the refrigerator.
- Try to reduce the open times and keep the refrigerator inside cold in case the power is cut off.
- Only skilled serviceman is allowed to repair the damaged power cable with special tools.
- Never touch othe ompressor to avoid from scald.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- The operation manual is not suitable for persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- During normal operation, the emission noise level does not exceed 70dB(A).
- The maximum loading of the Shelf does not exceed 18kg(39.71b).
- The climatic class of the appliance is 4, the Units are suggested to be used at 160C-320C (60.80F-89.60F) ambient temperature.
- To avoid damages or other problems, this product can not be put or stored with any corrosive food
- WARNING: Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
- **WARNING:** Do not use mechanical devices of other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- WARNING: Do not damage the refrigerant circuit.

• **WARNING:** Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.

ADDITIONAL WARNING

Caution:

Risk of fire. The height of the triangle in the symbol shall be at least 15mm.



Maintenance

1. Notice

- Often keep the refrigerator clean and periodical maintenance is necessary.
- Always unplug the socket before maintenance.
- Never use a damaged plug or loose socket to prevent electric shock or short circuit.
- Never flush the refrigerator-Never use alkali detergent, soap, gasoline, acetone, or brush.

2. Clean outside

Dip a soft cloth in neutral detergent(tableware detergent) to clean the outside of the refrigerator and then wipe it with a dry soft cloth.

3. Clean inside

- Take the rack out for cleaning with water.
- Use a soft cloth to wipe the box.
- 4. Shut down the refrigerator for a long time
 - Take all food out and unplug the wall socket.
 - Clean both the inside and outside of the refrigerator thoroughly and open the door for sufficient drying.
 - The glass breaks easily- Keep the glass far from children.
- 5. Replacement of lamp in the lightbox

If the LED lamp is damaged, it must be replaced by the manufacturer or its service agent.

Trouble Shooting

Trouble	Cause and Remedy	
	Is the plug in socket well?	
No refrigeration	Is the fuse broken?	
	Is there no power?	
Unsatisfactory refrigeration	Is it under the sunshine?Is there any heat source nearby?	
	Is the surrounding ventilation bad?	
	Does the door close well?Does door open for a long time?	
	Is the door seal strip deformed or damaged?	
	Is food congested or too much?	
	Does food block the air suction or outlet?	
	Regulate the temperature controller.	
Much noise	The refrigerator does not level.	
	The refrigerator contacts wall or other matter.	
	There is loose part in refrigerator.	
Contact local service agent for help if simple trouble shooting does not solve the problems.		


Note

The following phenomena are not troubles


- The murmur of water is heard when the refrigerator is working. It is a normal phenomenon as the coolant is circulating in the system.
- In the wet season, condensation might be found on the outside of the refrigerator. It is not a trouble, which is caused by high humidity. Simply use a cloth to wipe it.

Principle of Refrigeration System and Electric Circuit Diagram

The principle of compression refrigeration consists of "compression", "condensation" "throttling" and "vaporization". The compression is undertaken by the compressor, the condensation is completed by the condenser, the throttling valve is executed by the capillary and the vaporization is implemented by the evaporator. When the coolant is circulating in the closed refrigeration system, the compressor sucks coolant, which absorbs heat in the evaporator, and the coolant becomes a high-pressure and high-temperature gas. In the condenser, it dissipates heat in the air, while the coolant is re-liquefied and throttled in capillary and then enters into the evaporator with low pressure. The liquefied coolant quickly boils and vaporizes into gas when the pressure suddenly drops. Meanwhile, it absorbs heat inside the refrigerator. And the compressor sucks the low-pressure and low-temperature gaseous coolant. It is circulating in this way up to the realization of intended refrigeration.



Circuit Diagram



Major Parameters

Model	CW-100	CW-120/CW-120R	CW-160/CW-160R
Coolant and injection quantity(g)	R290(40)	R290(55)	R290(65)
General Rated input power(W)	200	230	250
Type of climate	4	4	4
Refrigeration temperature(°F)	32-53.6	32-53.6	32-53.6
Electric shock protection class	1	1	I
Total effective volume(CU.FT)	3.5	5.1/4.2	5.7/4.8
Net weight(lb)	86	125.7	145.5
Rated voltage(V)	110-120~	110-120~	110-120~
Rated Current (A)	2.7	2.7	3.0
Rated Frequency (Hz)	60	60	60
Overall dimension (in) (LxWxH)	26.9x17.7x26.6	27.6x22.4x27	34.6x22.4x27

Note

- 1. The electric circuit diagram and parameters on the product nameplate are the final ones if they have been changed.
- 2. The design might be improved without notice.



WARNING: Refrigerant is facility burning of R290, please protect against fire.



Meaning of crossed-out wheeled dustbin:

- Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities.
- Contact your local government for information regarding the collection systems available.
- If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being.
- When replacing old appliances with new ones, the retailer is legally obligated to take back your old appliance for disposal at least free of charge.

Acekool

• Model: cw-100/CW-120/CW-120R/CW-160/CW-160R

• Email: support@acekool.vip

Website: https://www.acekool.vip.

Made in China.

Documents / Resources



Acekool CW-100 Refrigerating Showcase [pdf] Instruction Manual CW-100 Refrigerating Showcase, CW-100, Refrigerating Showcase, Showcase

References

• User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.