




Adx Labs MINI2 Bluetooth Speaker User Manual

[Home](#) » [adx labs](#) » Adx Labs MINI2 Bluetooth Speaker User Manual 



Contents

- [1 Warnings](#)
- [2 Packing Details](#)
- [3 Button Functions](#)
- [4 Port function indicators](#)
- [5 Bluetooth Connection](#)
- [6 True Wireless Stereo Function](#)
- [7 Technical Specifications](#)
- [8 Documents / Resources](#)
- [9 Related Posts](#)

Warnings




- To ensure proper use and trouble-free operation, please carefully read this user manual first.
- Charge fully prior to first use.
- Use and store this product at room temperature.
- To avoid damage, do not drop or throw the speaker.
- Do not expose to fire, high temperature, or direct sunlight
- Do not clean with organic solvents or other chemical cleaners.
- Do not allow small particles to get into the product.
- Keep speaker volume at a moderate level to avoid temporary or permanent hearing impairment.
- Do not disassemble the product or make any modifications to the structure or any parts.
- Keep product out of reach of children.

Packing Details



MINI 2 Speaker *1



USB Type-C Charging cable *1



3.5MM Audio cable *1




User manual *1



Lanyard *1


Button Functions



Disconnect Bluetooth

Press and void “+” and “-” at the same time to disconnect the current device and set MINI 2 into discoverable status; short press the power button to connect to the last connected device.

Port function indicators



Data Access

Insert a Micro SD card when the speaker is powered off. Use the data cable to connect to the PC, and press and hold the “Power” button to enter SD card mode, the user can copy music files to the Micro SD card.

Bluetooth Connection

1. Power On

Press and hold the “Power” button for 2 seconds. When you hear the audio prompts “ding ding” and “ding” the

blue LED will blink, indicating that the speaker is awaiting a Bluetooth connection.

2. Connect to Bluetooth

Go to your device's Bluetooth list, and find an arid connection to the device "MY MINI 2". Speaker is connected when you hear the audio prompt "ding ding" and the blue LED remains lit.



The MINI 2 can reconnect automatically when the Bluetooth is switched ON, for the device.

Other tips

To connect to another Bluetooth device, press and hold "+" and "-" at the same time to disconnect the current Bluetooth device, MINI 2 will enter pairing mode to await a new device connection.

True Wireless Stereo Function

1. TWS connection Before starting, the speakers cannot be connected to any Bluetooth devices. Power on both MINI 2 speakers at the same time (both LED lights will be flashing). Choose one speaker and press the "+" and "-" buttons at the same time, once connected, the other MINI 2 LED light will stop blinking.
2. Let TWS Speakers connect to the Bluetooth device Go to the CIPViCP'S Bluetooth list, find "MY MINI 2" to connect (if you see 2 MY MINI on the list, the speakers are not in TWS mode) and the LED light will stop blinking.
3. TWS disconnect On the MINI 2 press the "+" and "-" buttons to disconnect the TWS.



Main Speaker

Tips;


1. Connecting two MINI 2 (TWS Mode) on the first one press “+” and “-“, this speaker will become the master speaker (left channel) and the other will become the slave speaker (right channel).
2. Only supports two speakers under a TWS connection.
3. Speakers will remember the TWS relationship (master/slave) when reconnected.
4. Once TWS is connected, the slave speaker's LED will be ON and the master speaker's LED indicates the status of play, pause, Bluetooth connection, etc.
5. When TWS is connected the function is the same on each MINI 2 speaker (synchronous functions).
6. Upon powering both MINI 2 speakers at the same time, if the LED is solid on one and the other is blinking, the speakers are in TWS mode.



Slave Speaker

Technical Specifications

Basic	
Type	Bluetooth Speaker
Micro SD card	Supports up to 32G
Power Supply	Built-in 2000mAh Li-ion battery
	DC5V2A Type C charging cable
Technical	
Trumpet	52MM trumpet with X bass radiator
Output	7.5W THD<10%
Frequency Response	100Hz- 18KHz
BT version	Bluetooth 5.0
Music files	MP3, WMA, WMV, APE, FLAC, AAC, P3:8Kbps-320Kbps WMA:32kbps-384Kbps WAV:32Kbps-1411Kbps



Product Size: 118 x 90 x 90mm

Product weight: 417g (used Lithium battery)

Questions	Solutions
Cannot connect	1. Restart the speaker
	2. If a Passcode is required, enter 0000
Discontinuity	1. Ensure there is no more than 10M (301 between the device and the speaker 2. Ensure there are no barriers between the device and the speaker
Micro SD cannot play	1. The Micro SO should be formatted as FAT32
	2. The formats of music files should be WAV, MP3, WMA
No sound when playing	1. Check the volume levels & adjust
	2. Check if paused or muted
Cannot power on	1. Check for low battery
No response	1. Reset the speaker (hold the power button for 8 -10 seconds)

FCC Caution.

(1)§ 15.19 Labelling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

§ 15.21 Changes or modification warning

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

§ 15.105 Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Documents / Resources

	<p>Adx Labs MINI2 Bluetooth Speaker [pdf] User Manual MINI2, 2AWHJ-MINI2, 2AWHJMINI2, MINI2 Bluetooth Speaker, Bluetooth Speaker</p>
---	--

