


**AEMC®
BR07 Resistance
and Capacitance
Boxes**



AEMC BR07 Resistance and Capacitance Boxes User Manual

[Home](#) » [AEMC](#) » AEMC BR07 Resistance and Capacitance Boxes User Manual 

Contents

- [1 AEMC BR07 Resistance and Capacitance Boxes](#)
- [2 Product Usage Instructions](#)
- [3 Statement of Compliance](#)
- [4 Description](#)
- [5 Operation](#)
- [6 General Specifications](#)
- [7 Maintenance](#)
- [8 Limited Warranty](#)
- [9 FAQ](#)
- [10 Documents / Resources](#)
 - [10.1 References](#)

AEMC®

AEMC BR07 Resistance and Capacitance Boxes



Specifications

- **Model:** BR07
- **Decades:** 7
- **Resistance Range:** 1Ω to $11.11111M\Omega$
- **Maximum Voltage:** 150V CAT II
- **Compliance:** EN 61010-1 (2001)

Product Usage Instructions

Safety Instructions

Before operating the resistance and capacitance boxes, ensure the ground (earth) terminal is connected to a protective ground (earth) for safety.

Resistance Box Model BR07

1. Connect the ground (earth) terminal to a protective ground (earth) before taking any measurements.
2. Ensure the resistance of the measurement leads is considered in the overall accuracy, especially in the first decade.
3. Avoid applying voltages greater than 150V to the ground (earth) and adhere to the specified current limits for each decade switch.

Capacitance Box Model BR07

1. Follow similar safety precautions as mentioned for the resistance box.
2. Use the rotary decade switches to set the desired capacitance value within the specified range.

Copyright© Chauvin Arnoux®, Inc. d.b.a. AEMC® Instruments. All rights reserved. No part of this documentation may be reproduced in any form or by any means (including electronic storage and retrieval or translation into any other language) without prior agreement and written consent from Chauvin Arnoux®, Inc., as governed by United States and International copyright laws.

Chauvin Arnoux®, Inc. d.b.a. AEMC® Instruments

- 15 Faraday Drive
- Dover, NH 03820 USA
- Phone: [603-749-6434](tel:603-749-6434) or [800-343-1391](tel:800-343-1391)
- Fax: [603-742-2346](tel:603-742-2346)

This documentation is provided as is, without warranty of any kind, express, implied, or otherwise. Chauvin Arnoux®, Inc. has made every reasonable effort to ensure that this documentation is accurate; but does not warrant the accuracy or completeness of the text, graphics, or other information contained in this documentation. Chauvin Arnoux®, Inc. shall not be liable for any damages, special, indirect, incidental, or inconsequential; including (but not limited to) physical, emotional or monetary damages due to lost revenues or lost profits that may result from the use of this documentation, whether or not the user of the documentation has been advised of the possibility of such damages.

Statement of Compliance

Chauvin Arnoux®, Inc. d.b.a. AEMC® Instruments certifies that this instrument has been calibrated using standards and instruments traceable to international standards. We guarantee that at the time of shipping your instrument has met its published specifications. An NIST traceable certificate may be requested at the time of purchase, or obtained by returning the instrument to our repair and calibration facility, for a nominal charge. The recommended calibration interval for this instrument is 12 months and begins on the date of receipt by the customer. For recalibration, please use our calibration services.

Refer to our repair and calibration section at www.aemc.com.

- Serial #: _____
- Catalog #: 2131.25
- Model #: BR07

Please fill in the appropriate date as indicated:

- Date Received: _____
- Date Calibration Due: _____

Chauvin Arnoux®, Inc.

d.b.a AEMC® Instruments www.aemc.com

Warning

Only use these decade boxes on Category II installations for voltages that do not exceed 150V in relation to the earth.

International Electrical Symbols

This symbol on the instrument indicates a WARNING and that the operator must refer to the user manual for instructions before operating the instrument. In this manual, the symbol preceding instructions indicates that if the instructions are not followed, bodily injury, installation/sample and product damage may result.

- Ground (Earth) Terminal
- Protective Ground (Earth)

Receiving Your Shipment

Make sure that the contents shipped are consistent with the packing list. Notify your distributor of any missing items. If the equipment appears to be damaged, file a claim immediately with the carrier and notify your distributor at once, giving a detailed description of any damage. Save the damaged packing container to substantiate your claim.

Ordering Information

- Decade Resistance Box Model BR07.....Cat. #2131.25 All decade boxes are shipped with a 9.8" (25cm) safety lead with Ø 4mm connectors
- Decade Capacitance Box Model BC05 (Discontinued).....Cat. #2131.26 (No longer Available for Purchase)

Replacement Parts:

Safety lead with connectors Ø 4mm, length 9.8" (25cm).....Cat. #2131.35

Description

- **Resistance Boxes:**

Model BR07: 7 decades – 1Ω to 11.11111MΩ covering all the resistance values from 1Ω to 11.11111MΩ

- **Capacitance Box:**

Model BC05: 5 decades – 0.1nF to 11.111μF covering all the capacitance values from 0 to 11.111μF

These decade boxes are built into a metal bench-top box. They are used for testing and calibration. The main function of these decade boxes is to create a resistance, capacitance or inductance with a specific value by using a combination of the rotary decade switches. They are equipped with Ø 4mm safety terminals for connection. For safe use, they comply with standard EN 61010-1 (2001).

Operation

The ground (earth) terminal must be connected to a protective ground (earth) before taking any measurements. Do not inject any voltage measurements greater than 150V to the ground (earth) and comply with the maximum acceptable current for each decade switch.

Resistance Box Model BR07

- Resistance box: 7 decades covering a range from 1Ω to 11.11111MΩ
- 11 position switches
- Output on safety sockets Ø 4mm
- **Accuracy:** 1% ±10mW on all ranges

Connect the ground (earth) terminal to a protective ground (earth) before taking any measurements. Do not forget the resistance of the measurement leads in overall accuracy, particularly on the first decade

Types	Multiplying factor in W						
BR07	1	10	100	1k	10k	100k	1M
Accuracy	1% ±10mW	1% ± 10mW	1% ± 10mW	1% ± 10mW	1% ± 10mW	1% ± 10mW	1% ± 10mW
Max current mADC	700mA	200mA	70mA	20mA	7mA	1mA	0.1mA

Capacitance Decade Box Model BC05

- Capacitance box with 5 decades; 11 position switches
- Total capacitance 11.111µF
- Very high insulation
- Output on safety sockets Ø 4mm
- The residual capacitance is approximately 25 pF
- Accuracy: 3% on all the ranges (residual capacitance deducted)

Type	Multiplying factor in nF				
BC05	0.1	1	10	100	1k

Connect the ground (earth) terminal to a protective ground (earth) before taking any measurements. Comply with the maximum operating voltage of 300VDC or 230VAC at 50Hz and the voltage of 150V maximum to ground (earth). After each use, discharge the voltage stored by the capacitors into a resistance with an appropriate value.

General Specifications

- **Operating Temperature:** 14° to 131°F (-10° to + 55°C)
- **Storage Temperature:** -40° to 158°F (-40° to + 70°C)
- **Relative Humidity:** 20% < RH < 96%
- **Altitude:** 2000m
- **Dimensions** – BR07: 16 x 3.4 x 3" (410 x 86 x 76mm)
- **Weight** – BR07: 3 lbs (1.4kg)
- **Dimensions** – BC05: 12 x 3.4 x 3" (310 x 86 x 76mm)
- **Weight** – BC05: 2.2 lbs (1kg)
- **Watertightness** (as per EN 60529 Ed. 92): Protection index IP 40
- **Rated Voltage:** 150V
- **Installation** Category II – Pollution level 2

Maintenance

The decade boxes must be disconnected from any electrical source before cleaning or maintenance. For maintenance, only use the specified factory spare parts. The manufacturer cannot be held responsible for any accidents that occur due to repairs done outside its after-sales department or certified repair agents. To clean the

console, use a cloth with a little soapy water. Never use abrasive products or solvents. Rinse with a damp cloth and then wipe quickly with a dry cloth or pulsed air.

Repair and Calibration

To ensure that your instrument meets factory specifications, we recommend that it be scheduled back to our factory Service Center at one-year intervals for recalibration, or as required by other standards or internal procedures.

For instrument repair and calibration:

You must contact our Service Center for a Customer Service Authorization Number (CSA#). This will ensure that when your instrument arrives, it will be tracked and processed promptly. Please write the CSA# on the outside of the shipping container. If the instrument is returned for calibration, we need to know if you want a standard calibration, or a calibration traceable to N.I.S.T. (Includes calibration certificate plus recorded calibration data).

- **Ship To:** Chauvin Arnoux®, Inc. d.b.a. AEMC® Instruments 15 Faraday Drive Dover, NH 03820 USA
- **Phone:** [800-945-2362](tel:800-945-2362) (Ext. 360) [603-749-6434](tel:603-749-6434) (Ext. 360)
- **Fax:** [603-742-2346](tel:603-742-2346) or [603-749-6309](tel:603-749-6309)
- **E-mail:** repair@aemc.com

(Or contact your authorized distributor) Costs for repair, standard calibration, and calibration traceable to N.I.S.T. are available.

NOTE: You must obtain a CSA# before returning any instrument.

Technical and Sales Assistance

If you are experiencing any technical problems, or require any assistance with the proper operation or application of your instrument, please call, fax or email our technical support team:

- **Contact:** Chauvin Arnoux®, Inc. d.b.a. AEMC® Instruments
- **Phone:** [800-945-2362](tel:800-945-2362) (Ext. 351) [603-749-6434](tel:603-749-6434) (Ext. 351)
- **Fax:** [603-742-2346](tel:603-742-2346)
- **E-mail:** techsupport@aemc.com

Limited Warranty

The Decade Boxes are warranted to the owner for a period of two years from the date of original purchase against defects in manufacture. This limited warranty is given by AEMC® Instruments, not by the distributor from whom it was purchased. This warranty is void if the unit has been tampered with, abused or if the defect is related to service not performed by AEMC® Instruments.

Full warranty coverage and product registration is available on our website at www.aemc.com/warranty.html.

Please print the online Warranty Coverage Information for your records.

What AEMC® Instruments will do: If a malfunction occurs within the warranty period, you may return the instrument to us for repair, provided we have your warranty registration information on file or a proof of purchase. AEMC® Instruments will, at its option, repair or replace the faulty material.

REGISTER ONLINE AT: www.aemc.com/warranty.html

Warranty Repairs

What you must do to return an Instrument for Warranty Repair:

First, request a Customer Service Authorization Number (CSA#) by phone or by fax from our Service Department (see address below), then return the instrument along with the signed CSA Form. Please write the CSA# on the outside of the shipping container. Return the instrument, postage or shipment pre-paid to:

- **Ship To:** Chauvin Arnoux®, Inc. d.b.a. AEMC® Instruments 15 Faraday Drive • Dover, NH 03820 USA
- **Phone:** [800-945-2362](tel:800-945-2362) (Ext. 360) [603-749-6434](tel:603-749-6434) (Ext. 360)
- **Fax:** [603-742-2346](tel:603-742-2346) or [603-749-6309](tel:603-749-6309)
- **E-mail:** repair@aemc.com

Caution: To protect yourself against in-transit loss, we recommend you insure your returned material.

NOTE: You must obtain a CSA# before returning any instrument.

Chauvin Arnoux®, Inc. d.b.a. AEMC® Instruments

- 15 Faraday Drive
- Dover, NH 03820 USA
- **Phone:** [603-749-6434](tel:603-749-6434)
- **Fax:** [603-742-2346](tel:603-742-2346)
- www.aemc.com

FAQ

Q: What is the recommended calibration interval for the resistance and capacitance boxes?

A: The recommended calibration interval is 12 months starting from the date of receipt by the customer. Recalibration services can be availed through our calibration services.


Q: How can I obtain an NIST traceable certificate for the instrument?

A: You can request an NIST traceable certificate at the time of purchase or by returning the instrument to our repair and calibration facility for a nominal charge.

Q: What standards do the resistance and capacitance boxes comply with?


A: The boxes comply with standard EN 61010-1 (2001) for safe usage.

Documents / Resources

	<p>AEMC BR07 Resistance and Capacitance Boxes [pdf] User Manual BC05, BR07 Resistance and Capacitance Boxes, BR07, Resistance and Capacitance Boxes, Capacitance Boxes, Boxes</p>
---	---

References

-  [Get Electrical Testers – Power Analyzers | AEMC Instruments](#)

-  [AEMC Warranty Registration](#)
- [User Manual](#)

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.