



## Aeotec GP-AEOBTNEU SmartThings Smart Button User Guide

[Home](#) » [Aeotec](#) » Aeotec GP-AEOBTNEU SmartThings Smart Button User Guide 

### Aeotec Button user guide

Modified on: Thu, 19 Nov 2020 at 5:49 PM



Aeotec Button was developed to control devices connected to Aeotec Smart Home Hub through the use of a physical and wireless button.

It is powered by Aeotec Zigbee technology.

Aeotec Button must be used with an Aeotec Smart Home Hub in order to work.

## Contents

### 1 Familiarize yourself with Aeotec Button

### 2 Package contents:

### 3 Important safety information.

### 4 Connect the Aeotec Button

### 5 Programming Aeotec Button

### 6 Steps in Smartthings Connect.


### 7 Factory reset your Aeotec Button

### 8 Aeotec Button technical specifications

### 9 Documents / Resources

### 10 Related Posts

## Familiarize yourself with Aeotec Button



## Package contents:

1. Aeotec button
2. User manual
3. 1x CR2 battery

## Important safety information.

- Read, keep, and follow these instructions. Heed all warnings.
- Clean only with a dry cloth.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Only use attachments and accessories specified by the Manufacturer

## Connect the Aeotec Button

## Steps in SmartThings Connect.

1. From the Home screen, tap the Plus (+) icon and select Device.
2. Select Aeotec and Remote/Button.
3. Tap Start.
4. Choose a Hub for the device.
5. Choose a Room for the device and tap Next.
6. While the Hub searches:
  - Pull the “Remove when Connecting” tab found in the sensor.
  - Scan the code on the back of the device.

## Programming Aeotec Button

Aeotec Button supports 3 separate button presses that can be used in an Automation in your Aeotec Smart Home hub. You can program the Aeotec button either from

- (1) Aeotec Button interface,
- (2) Custom Automation,
- (3) or SmartApps such as **WebCore**.

This section will go over how to program (1) Aeotec Button interface.

### Steps in Smarththings Connect.

1. From the Home screen, scroll down to your Aeotec Button and tap its widget.
2. Look for the 3 button press options and tap on any of them to program them.
  - Single Press (Pressed)
  - Double Pressed
  - Held
3. Under “Then”, tap on the Plus (+) icon.
4. Select one of the 2 options
  - Control Devices
    1. Select all devices you want to control
    2. Tap Next
    3. Tap on each device that you want to change the reaction.
  - Run Scenes
    1. Select all scenes you want this button press to run.
5. Tap Done
6. Test your button control by pressing the Aeotec Button.

## Factory reset your Aeotec Button

Aeotec button can be factory reset at any time if you come across any issues, or if you need to repair Aeotec Button to another hub.

Steps in Smarththings Connect.

1. Press and Hold the recessed connect button for five (5) seconds.
2. Release the button when the LED starts blinking red.
3. The LED will blink red and green while attempting to connect.

4. Use the Smarththings app and steps detailed in “Connect an Aeotec Button” above.

## Aeotec Button technical specifications

Modified on: Sun, 27 Jun 2021 at 4:18 PM

**Name:** Aeotec Button

**Model number:**

**EU:** GP-AEOBTNEU

**US:** GP-AEOBTNUS

**AU:** GP-AEOBTNAU

**EAN:** 4251295701677

**UPC:** 810667025458

**Hardware required:** Aeotec Smart Home Hub

**Software required:** SmartThings (iOS or Android)

**Radio protocol:** Zigbee

**Power supply:** No

**Battery charger input:** No

**Battery type:** 1 \* CR2

**Radiofrequency:** 2.4 GHz


**Indoor/Outdoor use:** Indoor only

**Operating distance:** 50 – 100 ft 15.2 – 40 m

**Dimension of Button:** 1.61 x 0.58 x 1.61 in 41 x 15 x 41 mm

**Weight:** 22.7 g0.8 oz

## Documents / Resources

	<p><a href="#">Aeotec GP-AEOBTNEU SmartThings Smart Button</a> [pdf] User Guide GP-AEOBTNEU, SmartThings Smart Button</p>
---	---