



AEROPRESS XL Flow Control Filter Cap Instructions

[Home](#) » [AEROPRESS](#) » AEROPRESS XL Flow Control Filter Cap Instructions 

AEROPRESS[®]

Questions?
Visit aeropress.com

Contents

- [1 SAFETY NOTICE](#)
- [2 How To Clean](#)
- [3 Filter Choice](#)
- [4 Documents / Resources](#)
- [5 Related Posts](#)

SAFETY NOTICE

Please read these instructions carefully. If the AeroPress Flow Control Filter Cap isn't used properly, it may result in an accident, in damage to your AeroPress coffee maker, or in damage to your AeroPress Flow Control Filter Cap.

Not compatible with AeroPress XL.

How To Clean

Wash the AeroPress Flow Control Filter Cap with warm water and dish soap (no harsh chemicals such as bleach) or clean in dishwasher (top rack only) before first use.

Day to day, a simple rinse is sufficient to clean the AeroPress Flow Control Filter Cap.

However, we do recommend occasionally giving the AeroPress Flow Control Filter Cap a thorough washing with soap and water.


Filter Choice

You can use an AeroPress metal filter, paper filter or both a metal and paper filter.
Never use the AeroPress Flow Control Filter Cap without an AeroPress filter.


Pressing Safely

Only press with your AeroPress coffee maker over a sturdy carafe or mug, with the support ring resting on the rim. Make sure your AeroPress coffee maker is stable and level on top of your carafe or mug before pressing.

1. Insert AeroPress filter of your choice.



2. Twist the AeroPress Flow Control Filter Cap onto the chamber very tightly.



3. Now you're ready to brew. Scan the QR Code for brewing instructions.



[illegible]