



Aethir Edge ECX1 Computing Server User Manual

[Home](#) » [Aethir Edge](#) » Aethir Edge ECX1 Computing Server User Manual 

Contents

- [1 Aethir Edge ECX1 Computing Server](#)
- [2 Specifications](#)
- [3 Product Information](#)
- [4 Product Usage Instructions](#)
- [5 Frequently Asked Questions](#)
- [6 FCC Statement](#)
- [7 Documents / Resources](#)
 - [7.1 References](#)
- [8 Related Posts](#)



Aethir Edge ECX1 Computing Server



Specifications

- **Model:** XYZ-1000
- **Dimensions:** 10 x 5 x 3 inches
- **Weight:** 2 lbs
- **Power Input:** 120V AC
- **Frequency:** 50-60Hz

Product Information

The XYZ-1000 is a versatile device designed to simplify your everyday tasks. With its compact dimensions and lightweight design, it is easy to use and store. The product is FCC-certified, ensuring compliance with regulations for electromagnetic interference in residential environments.

Product Usage Instructions

Setup:

Place the XYZ-1000 on a stable surface near a power outlet. Ensure the power input matches the device requirements (120V AC).

Operation:

Press the power button to turn on the device. Use the control panel to adjust settings as needed. Follow the user manual for specific functions.

Maintenance:

Regularly clean the device using a soft, damp cloth. Avoid using harsh chemicals that may damage the product.

Frequently Asked Questions

- **Q:** Can I use the XYZ-1000 outdoors?
A: The XYZ-1000 is designed for indoor use only due to its electrical specifications. Using it outdoors may pose

safety risks.

- Q: How do I troubleshoot if the device does not power on?

A: Check the power source, and ensure it is plugged in correctly. If the issue persists, contact customer support for further assistance.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, under part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used by the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by the manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance 20cm between the radiator and your body.



Documents / Resources



[Aethir Edge ECX1 Computing Server](#) [pdf] User Manual
ECX1, ECX1 Computing Server, Computing Server, Server

References

- [User Manual](#)

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.