



AIAIAI X02 W+ Link Transmitter User Guide

[Home](#) » [AIAIAI](#) » AIAIAI X02 W+ Link Transmitter User Guide 

© AIAIAI




We LINK
TRANSMITTER
Quick start guide
x02

Contents

- [1 X02 overview](#)
- [2 Quick Start Guide](#)
- [3 Documents / Resources](#)
- [4 Related Posts](#)

X02 overview



Quick Start Guide

Connect to audio

Connect to your audio source using the USB-C or 3.5mm mini-jack socket on X02.

Power on/off

If connecting to audio using USB-C, X02 will power on when connected.

If connecting to audio using 3.5mm mini-jack, connect the USB-C socket to a SV/2-10A adapter (e.g. phone charger). X02 will power on when connected.

Pairing

First put the device(s) you wish to connect to in pairing mode.

Next hold the button on X02 for 2 sec. LED 1 is solid white when the first device pairs. If you have a second device, LED 2 is solid white when it pairs.

Regulatory Info

Manufacturer information:

Company name: AIAIAI ApS.

Address: Studiestreede 31, Copenhagen K, 1455

Denmark

Operation temperature: -20-55°C

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

(1) This device may not cause interference.

(2) This device must accept any interference, including interference that may cause undesired operation of the device.

CAN ICES-3 (B) / NMB-3 (B)

This Class B digital apparatus complies with Canadian ICES-003.

Company name:

Address:


Tel:

E-mail:

FCC ID: 2AKSOX02

IC: 23880-X02

Documents / Resources

	AIAIAI X02 W+ Link Transmitter [pdf] User Guide AKSOX02, 2AKSOX02 x02, X02 W Link Transmitter, Link Transmitter, Transmitter
---	---