



# AIHOOR A1 TWS Bluetooth Headset User Manual

[Home](#) » [AIHOOR](#) » AIHOOR A1 TWS Bluetooth Headset User Manual 

## AIHOOR AIHOOR A1 USER MANUAL

Thank you for purchasing the AIHOOR A1 True Wireless Earbuds. Please read this user manual carefully and keep it for future reference. If you need any assistance, please contact our support team with your product model number.


### Contents

- [1 Package Contents](#)
- [2 Product Diagram](#)
- [3 Specifications](#)
- [4 FAQ](#)
- [5 Documents / Resources](#)
- [6 Related Posts](#)

### Package Contents

- True Wireless Earbuds
- Charging Case
- Four Pairs of Ear-Tips (XS/S/M/L)
- USB-A to C Cable
- Quick Start Guide °User Manual

Product Diagram



Specifications


Earbuds

Model	AIHOOR AI
Technology	A2DP, HFP, HSP, AVRCP
Driver (each channel)	1 x 1 Omm / 0.3" speaker driver
Sensitivity	101dB ±3dB
Frequency Range	20Hz — 20kHz
Impedance	32 ohm
Microphone Type	MEMS mic (microphone chip)
Microphone Sensitivity	-42dB ±1 dB
Microphone Frequency Range	30Hz – 10Hz
Charging Time	1.5 hours
Battery Life	Up to 7 hours
Battery Type	Li-polymer (2 x 60mAh)
Operating Range	Up to 10m / 33ft
Weight	4.8g (each)

Charging Case

Charging Input	DC 5V
Charging Time	2 hours
Battery Type	Li-polymer (500mAh)
Number of Earbuds Recharges	4 times (pair)
Weight	37.8g

- Fully charge the charging case before first use. Connect the charging case to a USB charger or charging port with the included USB-A to C cable. Only one green light is on when the battery is 0-25% remaining, two green lights are on when the battery is 26%-50% remaining, three green lights are on when the battery is 51%-75% remaining, when all 4 LED charging indicator lights are green, the case is fully charged. Charging takes around 2 hours, and after being fully charged, the case can fully charge the earbuds for 4 times.
- The earbuds should be stored in the case when not in use.



Turn On	Remove both earbuds from the charging case
Turn Off	Return both earbuds to the charging case

## AUTOMATIC CONNECTION

### Pairing:

- Turn on the Bluetooth of your mobile phone.
- Open the charging case, they will automatically turn on and enter the pairing mode.
- Turn on the pairing function on the device to be paired with the earbuds.
- From the list of available devices, Find and select "AIHOOR A1" from the list of available devices.
- If a code or PIN code is required for pairing, please enter "0000".

### Notes

- When you turn on the earbuds, they will automatically reconnect to the last-paired device or enter pairing mode if no paired device is found.
- To clear the pairing list, take either the earbuds out of the charging case and then tap the touch-sensitive panel 7 times, After that, put the earbud back in and take it out again to enter pairing mode.

- In pairing mode, the earbuds will automatically turn off after 5 minutes if no devices are paired.
- If one of the earbuds has no sound output, put both earbuds back into the charging case and take them out again.
- The maximum wireless operating range is 10m (33ft). If you exceed this range, the earbuds will disconnect from your paired device. The connection will be re-established if you re-enter the wireless range within 5 minutes. The earbuds will automatically reconnect to the last paired device. To connect with other devices, repeat the previous pairing steps.

## Controls & LED Indicators

### Streaming Audio

Once paired, you can wirelessly stream audio from your device to the earbuds. Music will automatically pause when you receive an incoming phone call and resume once the call has ended.

Play or pause	Tap the touch-sensitive panel on either earbud
Skip to the next track	Double-tap the touch-sensitive panel on the right earbud
Skip to the previous track	Double-tap the touch-sensitive panel on the left earbud

### Active Noise Canceling

Active noise canceling functionality requires the use of both earbuds.

Turn on / off	Touch and hold the touch-sensitive panel on/off the noise canceling
---------------	---

### Taking Calls

Answer or end a call	Tap the touch-sensitive panel on either earbud during the call.
Reject an incoming call	Touch and hold either earbud for 2 seconds
Use Siri or other voice assistants	While your device is connected, triple-tap either earbud

LED Indicator (Earbuds)	Status
Flashing green and red	Pairing
Flashing red	Low battery

## FAQ

### The earbuds are on, but not connecting to my device

For the earbuds and your device to establish a connection, you need to put them both in pairing mode. Please follow the instructions in the Pairing section of this manual.

### I've connected the earbuds with my smartphone but can't hear any sound

Double-check the volume level on your smartphone and the earbuds. Some smartphones require you to set up the earbuds as an audio output device before the audio can be transmitted. If you're using a music player or other device, please make sure it supports the A2DP profile.

**The sound isn't very clear or the caller can't hear my voice clearly**

Adjust the volume on your smartphone and the earbuds. Try moving closer to your smartphone to rule out the possibility of interference or wireless range-related issues.

**What's the wireless range of the earbuds?**

The maximum range is 10m (33ft). However, the actual range depends on environmental factors. For optimal performance, keep your device connected within a range of roughly 4m to 8m and make sure that there are no major obstacles (like reinforced steel walls) between the earbuds and your device.

**The earbuds won't turn on**

Try charging the earbuds for a while. If the earbuds still won't power on, please contact our support team at the email address given in 'Warranty & Customer Support.'

**I put the earbuds back in the charging case, but the earbuds are still connected**

The charging case is probably out of power. Try charging it.

**Product Care & Use**

- Keep away from liquids and extreme heat.
- Don't use the earbuds at high volume for extended periods, as this may cause.

**Warranty & Customer Support**

For questions, support, or warranty claims, contact us at the address below that corresponds with your region. Please include your Amazon order number and product model number.

**Amazon US orders:** [info@aihoor.net](mailto:info@aihoor.net)

**Amazon EU orders:** [info@aihoor.net](mailto:info@aihoor.net)

**Amazon CA orders:** [info@aihoor.net](mailto:info@aihoor.net)

**Amazon JP orders:** [info@aihoor.net](mailto:info@aihoor.net)

\*Please note, AIHOOR can only provide after-sales service for products purchased directly from AIHOOR. If you have purchased from a different seller, please contact them directly for service or warranty issues.

**FCC Information for Users**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio/TV technician for help.

**RF Exposure Information**

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

**CE Statement**

Max RF power level:

BT classic (2402–2480MHz): 2.281dBm

RF exposure assessment has been performed to prove that this unit will not generate the harmful EM emission above the reference level as specified in EC

Council Recommendation (1999/519/EC).

**CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.**

Excessive sound pressure from earphones and headphones can cause hearing loss.



Hereby, Shenzhen Ausounds Intelligent Co., Ltd.A1. declares that the radio equipment type (True Wireless Earbuds, A1) is in compliance with Directive 2014/53/EU.



**Notice:** This device may be used in each member state of the EU.

#### WARRANTY CARD

NAME:.....

EMAIL:.....

DATE OF ORIGINAL PURCHASE:.....

DEALER.....

PHONE NUMBER.....

MODEL.....

DESCRIPTION OF PROBLEM.....

Model: A1

AUSOUNDS Intelligence, LLC.

[www.aihoor.net](http://www.aihoor.net)

[info@aihoor.net](mailto:info@aihoor.net)

Designed by AUSOUNDS In California USA

FCC ID: 2AZLD-ARA1



**RoHS**  
Made in China



#### Documents / Resources



[AIHOOR AIHOOR A1 TWS Bluetooth Headset](#) [pdf] User Manual

AIHOORA1, 2AZLD-AIHOORA1, 2AZLDAIHOORA1, AIHOOR A1, TWS Bluetooth Headset