

AIMOTION 1019 Casambi Push Button Module



AIMOTION 1019 Casambi Push Button Module Instruction Manual

[Home](#) » [AIMOTION](#) » AIMOTION 1019 Casambi Push Button Module Instruction Manual 

Contents

- [1 AIMOTION 1019 Casambi Push Button Module](#)
- [2 Product Information](#)
- [3 Frequently Asked Questions](#)
- [4 Features](#)
- [5 Dimension](#)
- [6 Connections](#)
- [7 Safety instructions](#)
- [8 Waste disposal](#)
- [9 Documents / Resources](#)
 - [9.1 References](#)
- [10 Related Posts](#)

AIMOTION

AIMOTION 1019 Casambi Push Button Module



Product Information

- **Product:** Casambi Pushbutton Module
- **Item No.:** 1019
- **Operating Voltage:** 100-240V
- **Max Current:** 10A

Installation Instructions:

1. Read all safety instructions and information in the manual carefully before installation.
2. Ensure the unit is installed and serviced by a qualified electrician specialist following all relevant regulations and safety directives.
3. Check that the mains voltage matches the specified operating voltage before powering the device.
4. Ensure good ventilation and avoid humidity or high temperatures in the installation location.
5. Avoid exposure to rain, snow, or heat sources like radiators. Do not open the device.

Operation Instructions:

1. Do not operate the device without a cover to avoid electric shock.
2. When working on the device or connected loads, always disconnect the upstream fuse from the power supply.
3. If any abnormality occurs (e.g., liquid spillage, exposure to rain, device malfunction), do not operate the device without proper inspection.
4. Clean the device only with a dry, soft cloth; do not use liquids for cleaning.

Compliance:

- The devices are CE-marked and comply with EU directives applicable at the time of market placement.
- Dispose of electronic devices and batteries in accordance with European Directives for environmentally sound recycling.
- Follow local regulations for disposing of old appliances separately from household waste.

Frequently Asked Questions

Q: Can I install the Casambi Pushbutton Module myself?

A: The unit must be installed by a qualified electrician specialist to ensure safety and compliance with regulations.

Q: What should I do if the device malfunctions?




A: If the device does not operate normally or if there are any signs of damage, do not operate it and seek professional assistance for inspection and repair.

Q: How should I clean the Casambi Pushbutton Module?


A: Use a dry, soft cloth for cleaning; do not use any liquids to clean the device.

Product:	Item No.
Casambi Pushbutton Module	1019
Document: AIMOTION_1019_IN_pushbutton_20240213	


Features



Dimension



Connections



WARNING

DO NOT connect mains (L) to COM/1/2/3/4, ignoring leads to a defect of the device.

Safety instructions

WARNING

- For your safety, read all instructions and information in this manual carefully before the initial operation. Keep this manual for future reference.
- The instructions are an integral part of the product and must be handed to the end customer.
- All information and instructions in this manual must be observed completely and in detail. The manufacturer is not responsible for any direct or consequential damage that results from disregarding any information in this manual.

DANGER

- The unit must only be installed and serviced by a proven electrician specialist, by all relevant regulations, and safety and accident prevention directives of the country.
- Be sure that the existing mains voltage corresponds with the specified operating voltage before operating the device.
- Risk of electric shock. Do not operate the device without a cover. Even when switched off, voltage may be present at the outputs. When working on the device or connected loads, always disconnect the upstream fuse from the power supply.
- Only install the device in places with good ventilation and without humidity or high temperatures. Do not expose

the unit to rain or snow. Do not operate the unit near heat sources, e.g. radiators. Do not open the device. Otherwise, you will risk damage and void the warranty.

- If any of the following occurs, do not operate the device without first checking it:
 - if objects have fallen or liquid has been spilled into the unit.
 - if the device has been exposed to rain.
 - if the device does not operate normally or with altered characteristics.
 - if the device has been dropped or has a broken housing.



The devices comply with the EU directives applicable at the time they are placed on the market.

Waste disposal



- By European Directive 2002/96/EC (it`s) not longer usable electronic devices and defective or used batteries (European Directive 2006/66EG) must collected separately and disposed of by an environmentally sound recycling.
- This symbol indicates that electrical and electronic equip-ment must be disposed of separately from normal waste at the end of its operational lifetime.
- Should these products no longer be useable, the user is required by law to dispose of old appliances separately from their household waste e. g. at a local authority collection point or recycling center.

Product information and related documents

<https://www.aimotion-smartliving.de/en/produkt/pushbutton-module-4ch>.



Important:

Notice all safety instructions and related documents for Installation and operation. Names, brand marks, products, or companies can be claimed. All rights are on their respective owners.

AIMOTION GmbH

- Offakamp 9d 22539 Hamburg Germany
- +49 (0)40 57257993
- info@casambi-aimotion.de
- www.casambi-aimotion.de.

Documents / Resources



[AIMOTION 1019 Casambi Push Button Module](#) [pdf] Instruction Manual
1019 Casambi Push Button Module, 1019, Casambi Push Button Module, Button Module, Module

References

- [Hightech Agenda Bayern: KI-Mobilitätsknoten an der THI](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.