

AJAX
LeaksProtect-B
Wireless Leak
Detector



AJAX LeaksProtect-B Wireless Leak Detector User Manual

[Home](#) » [ajax](#) » AJAX LeaksProtect-B Wireless Leak Detector User Manual 

Contents

- [1 AJAX LeaksProtect-B Wireless Leak Detector](#)
- [2 Product Usage Instructions](#)
- [3 INTRODUCTION](#)
- [4 Functional Elements and Indication](#)
- [5 Operating Principle](#)
- [6 Indication](#)
- [7 Turned-on detector indication](#)
- [8 Functionality Testing](#)
- [9 Selecting the Location](#)
- [10 Maintenance](#)
- [11 Tech specs](#)
- [12 Warranty](#)
- [13 FAQ](#)
- [14 Documents / Resources](#)
 - [14.1 References](#)
- [15 Related Posts](#)

AJAX

AJAX LeaksProtect-B Wireless Leak Detector



Product Usage Instructions

- At the bottom of its body, LeaksProtect is equipped with four pairs of water-sensitive contacts.
- If at least one contact pair gets wet, the detector immediately transmits an alarm signal to the hub, notifying the user and security company.
- The detector also notifies users if the water dries out. When switched on, LeaksProtect is always active and monitors the situation regardless of the security mode: disarmed or armed.
- If a leak is detected, LeaksProtect notifies once, and the next alarm is transmitted when the contacts have dried out and gotten wet again.
- LeaksProtect can operate as a water leak detection system with a hub and WaterStop smart shutoff valve.
- WaterStop shuts off the water supply as soon as the LeaksProtect leak detector transmits an alarm.
- Connect the necessary devices and configure the automation scenario.

INTRODUCTION

- **LeaksProtect** is a wireless leak detector for indoor use. Detects minimal leaks so you can respond and fix the problem in time.
- LeaksProtect connects to the Ajax system via the protected [Jeweller](#) radio protocol.
- The communication range is up to 1300 meters in line of sight.
- LeaksProtect can work as part of a water leak detection system together with the Ajax hub and [WaterStop](#) smart shutoff valve. Also, LeaksProtect can be connected to third-party security systems using connected to third-party security systems using the [uartBridge](#) or [ocBridge Plus](#)

Users can configure LeaksProtect via the [Ajax app](#) for macOS, Windows, iOS, or Android. The system notifies users of all events through push notifications, SMS, and calls (if activated). [Buy leak detector LeaksProtect](#)

Functional Elements and Indication



1. LED indicator
2. Water sensor contacts
3. QR code with the device registration key
4. On/off button

Operating Principle




At the bottom of its body, LeaksProtect is equipped with four pairs of water-sensitive contacts. If at least one contact pair gets wet, the detector immediately transmits an alarm signal to the hub, notifying the user and security company. Also, the detector notifies users if the water dries out.

- When switched on, LeaksProtect is always active and monitors the situation regardless of the security mode: disarmed or armed.

If the leak is detected, LeaksProtect notifies once, and the next alarm is transmitted when the contacts have dried out and gotten wet again.

Operation as part of the water leak detection system

LeaksProtect with a hub and WaterStop smart shutoff valve can operate as a water leak detection system. WaterStop shuts off the water supply as soon as LeaksProtect leak detector transmits an alarm. To do this, connect the necessary devices and configure the automation scenario.



You can configure other automation scenarios, for example, to stop the water supply either by schedule or after arming the system. [More about scenarios](#)

Connecting the detector to the Ajax system

Detector connection to hub

Before connecting

1. Following the hub user manual, install the [Ajax app](#). Create an account, add the hub to the app, and create at least one room.
2. Check the internet connection (via Ethernet cable and/or GSM network).
3. Check the hub status in the app: make sure that it is disarmed and does not update.

Only users with administrator rights can add the device to the hub.

How to pair the detector with the hub:

1. Select Add Device in the Ajax app.
2. Name the device, scan or enter the QR Code (located on the body and packaging), and select the location room.
3. Select Add — the countdown will begin.
4. Switch on the device.

LeaksProtect has a rigid “ON” button: press it with force to switch the detector on.

- For the detection and pairing to occur, the device should be located within the wireless coverage area of the hub (at the same facility).
- The connection request is transmitted for a short time at the moment of switching on the device.
- If the connection fails, LeaksProtect switches off after 6 seconds. To retry the connection, you do not need to reboot the device.
- If LeaksProtect is paired with another hub, switch the detector off, then retry the standard adding procedure.
- The detector connected to the hub is displayed in the list of devices in the app.

- The update of the detector status in the list depends on the device inquiry time set in the hub settings (the default value is 36 seconds).

Connecting to third-party security systems

To connect the detector to a third-party security central unit using the or [ocBridge Plus](#) integration module, follow the recommendations in the manual of the respective device. The detector is always active. When connecting LeaksProtect to third security systems, it is appropriate to place the detector in a permanently active protection zone.

States

1. Devices

2. LeaksProtect

Parameter	Value
Temperature	<div>The temperature of the detector is measured on the processor and changes gradually.</div> <div>Acceptable error between the value in the app and the room temperature — 2°C.</div> <div>The value is updated as soon as the detector identifies a temperature change of at least 2°C.</div> <div>You can configure a scenario by temperature to control automation devices</div> <div>Learn more</div>
Jeweller Signal Strength	Signal strength between the hub and detector
Battery Charge	<div>Battery level of the device. Displayed as a percentage</div> <div>How battery charge is displayed in Ajax apps</div>
Lid	The state of the tamper, which reacts to the body being disassembled or damaged

ReX	Displays the status of using a radio signal range extender
Connection	Connection status between the hub and detector
Leakage detected	Alarm if the water sensor contacts wet
Permanent Deactivation	Shows the status of the device: active, completely disabled by the user, or only notifications about triggering of the device tamper button are disabled
Firmware	Detector firmware version
Device ID	

1. Devices 

2. LeaksProtect

3. Settings 

Setting	Value
First field	Detector name, can be edited
Room	Selecting the virtual room to which the device is assigned
Alert with a siren if leakage is detected	If active, sirens added to the system are activated if leakage is detected
Jeweller Signal Strength Test	Switches the detector to the signal strength test mode
Permanent Deactivation	<p>Allows the user to disconnect the device without removing it from the system.</p> <p>Three options are available:</p>

	<p>No — the device operates normally and transmits all events</p> <p>Entirely — the device will not execute system commands or participate in automation scenarios, and the system will ignore device alarms and other notifications</p> <p>Lid only — the system will ignore only notifications about the triggering of the device tamper button</p> <p>Learn more about the permanent deactivation of devices</p>
User Guide	Open the detector User Manual
Delete Device	Disconnects the detector from the hub and deletes its settings

Indication



00:00

00:04

The LeaksProtect

LED indicator may light up red or green depending on the device status.

Indication when pressing the power button

Event	Indication
Pressing the power button (detector is switched on)	Lights up red while the button is held down

Switching on	Lights up green while the device is switching on
Switching off	Initially lights up red, then blinks three times

Turned-on detector indication

Event	Indication	Note
Detector connection to the hub , o cBridge Plus , and uartBridge	Lights up green for a few seconds	
Hardware error	Blinks red continuously	The detector requires repair, Please contact Support Service
Leakage detected	Lights up red for about one second	
Battery needs replacing	During the alarm, it slowly lights up red and slowly goes out	Replacement of the detector battery is described in the Battery replacement manual

Functionality Testing

Ajax system allows tests for checking the functionality of connected devices. The tests do not start straight away but within a period of 36 seconds when using the standard settings. The test time depends on the detector scanning period settings (the paragraph on “Jeweller” settings in the hub settings).

- [Jeweller Signal Strength Test](#)
- [Attenuation Test](#)

Selecting the Location



When selecting the device location, please take into account its remoteness from the hub (up to 1300 meters) and the absence of any obstacles between the devices that could hinder the radio signal transmission: walls, floors, large objects located in the room.

- The device was developed only for indoor use.
- Check the Jeweller signal strength level at the installation place.

If the signal level is low (one bar), we cannot guarantee the stable operation of the device. Take all possible measures to improve the signal strength. At least, move the device: even a 20 cm shift can significantly improve the quality of signal reception. If, after moving the device still has a low or unstable signal strength, use a [radio signal range extender](#).

Install LeaksProtect in the place of potential leakage: on the floor under the bath, sink, washing machine, etc.

Do not install the detector:

- outside the premises (outdoors);
- nearby any metal objects or mirrors causing attenuation and screening of the signal;
- within any premises with the temperature beyond the range of permissible limit;
- on conductive surfaces;
- closer than 1 m to the hub.

Detector Testing

When the liquid gets on the detector contacts, it closes the electrical circuit. It is enough to close one contact pair to activate the alarm.

1. To check LeaksProtect, close one contact pair with a wet finger for 3 seconds (the delay prevents false triggering). If water is detected, the detector LED will light up red for 1 second.

2. Wipe the contacts with a dry napkin. When the electrical circuit is open, LeaksProtect switches on its LED red for 1 second and notifies that the water has dried out.

If you drown the detector with soapy water, it may continue signal flooding after getting dry. The issue is about the soapy film closing the contacts. To eliminate the problem, wipe the detector contacts with a napkin moistened with pure water and then dry them up.

Maintenance

Check the LeaksProtect operational capability regularly. We recommend cleaning the detector contacts as it get dirty at least once every 2-3 months. Use an alcohol solution for cleaning the contacts. Clean the detector body from dust, spider webs, and other contaminants as they appear: they can conduct electricity and cause false actuation. Use a soft, dry napkin suitable for equipment maintenance. Do not use any substances containing alcohol, acetone, gasoline or other active solvents for cleaning the detector body. The batteries installed in the detector ensure up to 5 years of autonomous operation on average (with the inquiry frequency by the hub of 1 minute). If the detector batteries are low, the security system sends a notification, and the detector LED smoothly lights up and goes out green every hour if the device is triggered. To replace the batteries, turn off the detector, loosen the screws and remove the LeaksProtect front panel. Change the batteries with new ones, type AAA, adhering to polarity.

- [How long Ajax devices operate on batteries, and what affects this Battery replacement](#)

Tech specs

Radio communication protocol	Jeweller Learn more
Radio frequency band	866.0 – 866.5 MHz 868.0 – 868.6 MHz 868.7 – 869.2 MHz 905.0 – 926.5 MHz 915.85 – 926.5 MHz 921.0 – 922.0 MHz Depends on the region of sale.
Compatibility	Operates with all Ajax hubs , radio signal range extenders , ocBridge Plus , uartBridge
Maximum RF output power	Up to 20 mW
Modulation of the radio signal	GFSK
Radio signal range	Up to 1,300 m (any obstacles absent)

	Learn more
Power supply	2 × AAA batteries
Battery life	Up to 5 years
Dust and moisture protection class	IP65
Installation method	Indoors
Operating temperature range	From 0°C to +50°C
Operating humidity	Up to 100%
Overall dimensions	56 × 56 × 14 mm
Weight	40 g
Service life	10 years

[Compliance with standards](#)

Complete Set

1. LeaksProtect
2. Batteries AAA (pre-installed) — 2 pcs
3. Quick start guide

Warranty

Warranty for the Limited Liability Company “Ajax Systems Manufacturing” products is valid for 2 years after the purchase and does not apply to the pre-installed battery. If the device does not work correctly, you should first contact the support service — in half of the cases, technical issues can be solved remotely!

- [The full text of the warranty](#)
- [User Agreement](#)

Technical support: support@ajax.systems


Subscribe to the newsletter about a safe life. No spam

Subscribe

FAQ

- **Q:** How is the battery charge displayed in Ajax apps?
- **A:** The battery level of the device is displayed as a percentage in Ajax apps.
- **Q:** What happens if a leak is detected by LeaksProtect?
- **A:** When a leak is detected, LeaksProtect immediately transmits an alarm signal to the hub, notifying the user and security company. The detector also notifies users if the water dries out.

Documents / Resources



References

- [!\[\]\(4c660a3c4ce1da3313488b7854f55083_img.jpg\) End user agreement - Ajax Systems](#)
- [!\[\]\(f01c435bb39e3068a9b4895c9a993158_img.jpg\) Security system control panels | Ajax Systems](#)
- [!\[\]\(c5f009707b314589d498a683120545c5_img.jpg\) Signal range extenders in the security system | Ajax Systems](#)
- [!\[\]\(8b308e9f1e6682fd04ddef01495a93be_img.jpg\) Alarm sirens for Ajax security systems](#)
- [!\[\]\(7a2466fab2a9c99ba33ed3fbd8b0c93f_img.jpg\) uartBridge — Module for Ajax devices integration with third-party wireless alarms systems](#)
- [!\[\]\(f632f5613101834356c1771a91f82a1c_img.jpg\) What affects the quality of radio communication between Ajax devices](#)
- [!\[\]\(1e76af9967ccdbc9d35eeb7f7c74a0bb_img.jpg\) Software | Ajax Systems](#)
- [!\[\]\(13f95891d017add9bb2bd324d9543b27_img.jpg\) Warranty - Ajax Systems](#)
- [!\[\]\(63cc436de7726865a4fe5c59fc1020e2_img.jpg\) How battery charge is displayed in Ajax apps | Ajax Systems Support](#)
- [!\[\]\(f4d81379fada60627f0dc1fa410d9772_img.jpg\) How long Ajax devices operate on batteries, and what affects this | Ajax Systems Support](#)
- [!\[\]\(2e60bb17bbb3e5e5a880f4d2d24cf4bf_img.jpg\) How to deactivate a device without removing it from the system | Ajax Systems Support](#)
- [!\[\]\(94762637b13435d7e8cc90d87c3a4a05_img.jpg\) How to change batteries in the LeaksProtect | Ajax Systems Support](#)
- [!\[\]\(1d5544ed379feda028810e2d2a62e302_img.jpg\) Jeweller radio protocol: technology and capabilities | Ajax Systems Support](#)
- [!\[\]\(2ff1500a322a187b96ccc730045322cf_img.jpg\) How to create and configure a scenario in the Ajax system | Ajax Systems Support](#)
- [!\[\]\(df6e53878debaaf1f4685fe5ee148f0f_img.jpg\) What is Signal Attenuation Test | Ajax Systems Support](#)
- [!\[\]\(b9844542d84917bc2873109c06d1b615_img.jpg\) What is Jeweller Signal Strength Test | Ajax Systems Support](#)
- [!\[\]\(eefc434132748e00145694f36477483d_img.jpg\) User Manual](#)

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.