



AK18 WIRELESS NUMBER KEYBOARD

User Manual

Contents [[hide](#)]

- [1 AK18 Wireless Number Keyboard](#)
- [2 Install the battery in the keyboard](#)
- [3 Other Considerations](#)
- [4 Connecting the Receiver](#)
- [5 Restoring Factory Default Settings](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)

AK18 Wireless Number Keyboard


Thank you for purchasing the AJAZZAK18 wireless numeric keyboard.
Please read this manual carefully before using this product.

Install the battery in the keyboard

Step 1: Remove the battery compartment cover on the bottom of the keyboard by squeezing the cover in from the tab to release it.

Step 2: Insert the battery as shown inside the battery compartment.

Step 3: Replace the cover.




Other Considerations

1. Power-saving design: When the keyboard does not take any action about 2 seconds into hibernation, press any KEY.
2. 1 AAA dry batteries: The whole boost to 1.5V. The whole system is 1.5V system.

Connecting the Receiver

1. The receiver is inserted to USB port immediately, or by a extra USB cable.



2. Connect the UBS plug to USB Port for your computer.

Restoring Factory Default Settings

When you find this wireless keyboard doesn't work, you can make the keyboard in working condition by restoring back to factory default settings.

1. Check the battery volume is normal; if the battery is used out, please replace new batteries.
2. Insert the USB receiver onto the USB port the PC or notebook.

3. At the same time the battery into the keyboard, the keyboard LED lights flash quickly said, restor factory Settings successfully.

Warning Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Documents / Resources



[AJAZZ AK18 Wireless Number Keyboard \[pdf\]](#) User Manual
2AY3H-AK18, 2AY3HAK18, ak18, AK18 Wireless Number Keyboard, AK18, Wireless Number Keyboard, Number Keyboard, Keyboard

References

- [User Manual](#)

■ AJAZZ

🔍 2AY3H-AK18, 2AY3HAK18, aJAZZ, ak18, AK18 Wireless Number Keyboard, Keyboard, Number Keyboard, Wireless Number Keyboard

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.