

ALL BEST
An Tag
Finder



ALL BEST An Tag Finder User Manual

[Home](#) » [ALL BEST](#) » ALL BEST An Tag Finder User Manual 

Contents

- 1 ALL BEST A Tag Finder
- 2 Product Information
- 3 Product Usage Instructions
 - 3.1 Resetting An Tag
- 4 FAQ
- 5 Getting Started
- 6 Add Your An Tag
- 7 Locate Your Tag
- 8 Notifications
- 9 When Your An Tag Is Lost
- 10 Resetting An Tag
- 11 Extras
- 12 The Fine Print
- 13 About Apple Find My
- 14 Documents / Resources
 - 14.1 References
- 15 Related Posts

ALL BEST

ALL BEST A Tag Finder



Product Information

Specifications:

- **Model:** A Tag
- **Battery:** CR2032
- **Compliance:** FCC Part 15

Product Usage Instructions

Getting Started

Power On / Off:

Remove the insulating film to turn on the device. Connect the device within 3 minutes of powering it on to avoid an automatic shutdown. If the connection fails, rotate the battery cover counterclockwise, reinstall the battery, and restart.

Add Your An Tag

Connect Your An Tag:

Click on the item option in the Find app, select Add item, choose Other supported item, connect your An Tag, enter a name and emoji, and then confirm to set it up.

Locate Your Tag

Find A Tag When It's Nearby:

Open the Find My app, select the Items tab, or use the Find Items app on your Apple Watch, tap on your An Tag, play sound to locate, and stop the sound once found.

Notifications

Enabling Notify When Left Behind:

Enable Notify When Left Behind in the Find My app to receive notifications when your An Tag is out of range.

Resetting An Tag

Remove The An Tag From Find My App:

In Find My app, disable Lost Mode, remove the An Tag, and confirm the removal.

Connect Your An Tag:

To reset, remove, and reinstall the battery to restart the device for pairing with a new Apple ID.

Extras

Replace The Battery:

Replace the CR2032 battery by opening the cover, placing the new battery with the positive side up, and closing the cover.

The Fine Print

This device complies with FCC Part 15 rules and operates under specified conditions to prevent interference.

FAQ

How do I know if my An Tag is out of range?


Enable Notify When Left Behind in the Find My app to receive notifications when your An Tag is no longer in range of your device.

Important tips: When pairing a device with the Find My® app, the phone will link to the Apple® Server. Pairing may fail because of network problems. The following actions are recommended: Change the phone's network, such as switching between WiFi and mobile network.

Getting Started

Power On / Off:

- Remove the insulating film to turn on the device.
- After powering on, please connect the device within 3 minutes. Otherwise, the device will automatically shut down. If you fail to connect the device successfully within 3 minutes, please rotate the battery cover counterclockwise, and reinstall the battery to restart the device.



Check For Updates:

To use the Apple® Find My® app to locate this item, the latest version of iOS®, iPadOS®, or macOS® is recommended. The Find Items app on Apple Watch® requires the latest version of watchOS®.

Add Your An Tag

Start The App

Open Find My app on your supported iPhone®.

Connect Your Tag

- Click on the item option at the bottom of the Find app, then click on “Add item.”

- Select Other supported items and wait for the app to search for the item.
- Once your An Tag is located, tap “Connect”
- Enter a name choose An emoji for your An Tag And tap “Continue”.
- Find My will ask for confirmation to add your An Tag to your Apple ID Tap “Agree”
- Tap “Finish” And your An Tag will be set up And ready to be used.

Locate Your Tag

Find A Tag When It’s Nearby:

- Open the Find My app And select the “Items” tab or open the Find Items app on your Apple Watch.
- Tap on your An Tag from the list.
- Tap “Play Sound” to make your An Tag beep.
- Tap “Stop Sound” to stop the beeps once you find them.

Find An Tag’s Location:

- Open Find My app And select the “Items” tab or open the
- Find Items app on your Apple Watch.
- Tap on your An Tag from the list.
- Your An Tag’s location will appear on the Map with a timestamp of when the item was located.
- To navigate to the An Tag’s location, tap “Directions” to open Apple Maps.

Notifications

Enabling “Notify When Left Behind”:

- Open the Find My app And select the “Items” tab or open the Find Items app on your Apple Watch.
- Tap on your An Tag from the list.
- Under “Notifications” enable the “Notify When Left Behind” toggle.
- You will receive a notification when you leave your An Tag behind And it’s no longer in range of your device.

Enabling “Notify When Found”:

- Under “Notifications”, enable the “Notify When Found” toggle.
 - When your An Tag is seen by Another Find My network device, you will receive a notification of its location.
- Note:** “Notify When Found” can only be activated when your An Tag is out of range.

When Your An Tag Is Lost

Enabling “Lost Mode”:

- Open the Find My app And select the “Items” tab or open the Find Items app on your Apple Watch.
- Tap on your An Tag from the list.
- Under “Lost Mode” tap “Enable”

- A screen detailing Lost Mode will pop up, tap “Continue” Enter your phone number or email address, And tap “Next”. You may enter a message that will be shared with the person that finds your item.
- Tap “Activate” to enable “Lost Mode”
Note: When “Lost Mode” is enabled, “Notify When Found” is automatically enabled.
Note: When “Lost Mode” is enabled, you’re Tag is locked And cannot be paired to a new device.

Resetting An Tag

Remove The An Tag From Find My App:

- Open Find My app And select the “Items” tab.
- Tap on your An Tag from the list. Please ensure “Lost Mode” is disabled.
- Scroll to the bottom of the screen And tap “Remove item”.
- A summary will open, tap “Remove” to confirm.

Connect Your Tag

- After successfully removing the An Tag from the Find My app.
- Please rotate the battery cover counterclockwise, and reinstall the battery to restart the device. Then the An Tag is now reset And ready to be paired to a new Apple ID.

Extras

Replace The Battery:

- Rotate the battery cover on the back of your An Tag counterclockwise and carefully open it. Replace it with a new
- CR2032 battery, placing its positive side upwards (with the text facing upwards). Then rotate the battery cover clockwise to close it.

Enabling “Notify When Found”:

- If any Find My Network accessory separated from its owner is seen moving with you over time, you’ll be notified in one of two ways:
 1. If you have an iPhone or iPad®, Find My will send a notification to your Apple device. This feature is available on iOS or iPadOS 14.5 or later.
 2. If you don’t have an ios device or a smartphone, a Find
- My network accessory that hasn’tn’t with its owner for some time will emit a sound when it’s moved.
- These features were created specifically to discourage people from trying to track you without your knowledge.

The Fine Print

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference

2. This device must accept any interference received, including interference that may cause undesired operation.

NOTE:

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or changes to this equipment. Such modifications or changes not expressly approved by the party responsible for compliance could void the user's authority to operate this device.


The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction. Federal Communication Commission (FCC) Radiation Exposure Statement Power is so low that no RF exposure calculation is needed.

This equipment has been tested and found to comply with the limits for a Class B digital device, under part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates and radiates radiofrequency energy, if not installed and used according to the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. Suppose this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on. In that case, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and the receiver. Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.

About Apple Find My

- The Apple Find My network provides an easy, secure way to locate compatible personal items using the Find My app on your iPhone, iPad, Mac®, or the Find Items app on your Apple Watch.
- Use of the Works with Apple badge means a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturers to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.
- Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, macOS and iOS, macOS watchOS are trademarks of Apple Inc. IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

Documents / Resources

	ALL BEST An Tag Finder [pdf] User Manual RH8-ANTAG, RH8ANTAG, An Tag Finder, Finder
---	--

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.