

altice labs GR140IG Wi-Fi 6 Fiber Gateway Instructions

Home » altice labs » altice labs GR140IG Wi-Fi 6 Fiber Gateway Instructions

altice labs GR140IG Wi-Fi 6 Fiber Gateway



altice labs GR140IG Wi-Fi 6 Fiber Gateway

Contents

- 1 FEDERAL COMMUNICATION COMMISSION (FCC) INTERFERENCE STATEMENT
- **2 DECLARATION OF CONFORMITY**
- **3 CUSTOMER SUPPORT**
- 4 Documents / Resources
 - 4.1 References
- **5 Related Posts**

FEDERAL COMMUNICATION COMMISSION (FCC) INTERFERENCE STATEMENT

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC CAUTION:

The grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. Such modifications could void the user's authority to operate the equipment. IEEE 802 11b or 802 11g operation of this product in the USA is firmware limited to channel 1~11. This device is restricted for indoor use.

Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment This equipment should be installed and operated with minimum distance 25 cm between the radiator and your body. This device and it's antennas(s) must not be co-located or operating in conjunction with any other antenna or transmitter except in accordance with FCC multi-transmitter product procedures.

5GHz Wireless Statement:

For operation within the 5.15~5.25GHz and 5.45~5.725GHz frequency ranges, this device is restricted to indoor environments.

This device meets all the other requirements specified in Part 15E, Section 15.407 of the FCC Rules.

Safety Warnings:

- CAUTION: do not look into the end of the fiber connector as this can cause eye damage.
- This device uses passive cooling, with ventilation holes in its faces. To avoid overheating, please do not block these holes.
- Install this device in a site that meets the following conditions:
 - Temperature (41ºF − 104ºF)
 - Humidity (0% to 95%)

DECLARATION OF CONFORMITY



CUSTOMER SUPPORT

Aveiro – Portugal Rua Eng. José Ferreira Pinto Basto 3810 – 106 Aveiro (Portugal)

www.alticelabs.com

© 2020 Altice Labs. All rights reserved. August 2020



Documents / Resources



altice labs GR140IG Wi-Fi 6 Fiber Gateway [pdf] Instructions
GR140IG, GR140IG Wi-Fi 6 Fiber Gateway, Wi-Fi 6 Fiber Gateway, Fiber Gateway, Gateway

References

User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.