

amazon basics B0787D6SGQ Wireless Ergonomic Mouse for **PC User Manual**

Home » amazon basics » amazon basics B0787D6SGQ Wireless Ergonomic Mouse for PC User Manual



amazonbasics

Ergonomic Wireless Mouse - DPI Adjustable B0787D6SGQ, B0787PGF9N, B0787K1MLT, **BO787QZ6WD, BO787G1YFF**




Contents

- 1 Parts List
- 2 Setup
- 3 Operation
- **4 FCC Compliance Statement**
- **5 Canada IC Notice**
- 6 Simplified EU Declaration of

Conformity

- 7 Simplified UK Declaration of
- Conformity
- 8 Intended Use
- 9 Safety and Compliance
- **10 Symbols Explanation**
- 11 Cleaning and Maintenance
- 12 Specifications
- 13 Disposal (for Europe only)
- **14 Battery Disposal**
- 15 Documents / Resources
 - 15.1 References

Parts List




Setup

2.1 Installing The Battery (battery included)


- Always purchase the correct size and grade of battery most suitable for the intended use.
- Clean the battery contacts and also those of the device prior to battery installation.
- Always insert batteries correctly with regard to polarity (+ and -) marked on the battery and the battery compartment.
- Remove batteries from equipment that is not to be used for an extended period of time. Remove used batteries

promptly.



- Remove the battery cover.
- Insert the battery correctly with regard to polarity (+ and -) marked on the battery and the product.
- Place the cover back over the battery compartment.
- Set the ON/OFF switch to ON.


2.2 Connecting Mouse to Receiver



- Remove the battery cover, and take the nano receiver out.
- Plug the nano receiver into a USB port of your computer.

2.3 Setup the Connection between the Receiver and the Mouse

- 1. Insert the battery into the mouse, then follow the steps below.
- 2. In the meantime, to take the nano receiver, open the cover under the mouse.
- 3. Plug the Nano receiver into the USB port on your computer.



- 4. If the mouse does not work, please put it into pairing mode.
- 5. Pairing: Re-plug the receiver into the USB port on your computer, then press the connect button on the mouse. If the mouse does not work after 10 seconds, pair them again. (The receiver has auto pairing function).

- 6. The LED indicator on mouse flashes steadily when it is in pairing mode and stops blinking when it is successfully paired with the receiver.
- 7. When low battery, the battery indicator (DPI key) on the mouse will start to blink.

Operation

3.1 Controls

3.2 Forward

Press this button to view the next page in your Internet browser.


3.3 Backward

Press this button to view the previous page in your Internet browser.

3.4 DPI Setting Adjustment

- 5 DPI settings are available.
- The number of times the DPI key blinks indicates the current DPI setting (**Note:** the default setting is 1600 DPI).

| DPI | Number of Blinks |
|----------|------------------|
| 600 DPI | 1 |
| 1000 DPI | 2 |
| 1600 DPI | 3 |
| 2400 DPI | 4 |
| 3600 DPI | 5 |



- 1. This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions
 - (1) this device may not cause harmful interference, and
 - (2) this device must accept any interference received, including interference that may cause undesired operation.
- 2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

4. 1 FCC Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Canada IC Notice

- This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:
 - (1) this device may not cause interference, and
 - (2) this device must accept any interference, including interference that may cause undesired operation of the device.
- This equipment complies with Industry Canada radiation exposure limits set forth for an uncontrolled environment.
- This Class B digital apparatus complies with Canadian CAN ICES-003(B) / NMB-003(B) standard.

Simplified EU Declaration of Conformity

- Hereby, Amazon EU Sarl declares that the radio equipment type B0787D6SGQ, B0787PGF9N, BO787K1MLT, BO787QZ6WD, BO787G1YFF is in compliance with Directive 2014/53/EU.
- The full text of the EU declaration of conformity is available at the following internet address: https://www.amazon.co.uk/amazon.private-brand-EU compliance

Simplified UK Declaration of Conformity

Hereby, Amazon EU SARL, UK Branch declares that the radio equipment type B0787D6SGQ, B0787PGFON, B0787K1MLT, B0787QZ6WD, B0787G1YFF is in compliance with The Radio Equipment Regulations 2017. The full text of the UK declaration of conformity is available at the following internet address: https://www.amazon.co.uk/amazon_private_brand_EU_compliance

Intended Use

This product is a wireless computer peripheral intended for interacting with your desktop/laptop.

Safety and Compliance

Read this instruction manual carefully before using the product. It contains important information for your safety as well as operating and maintenance advice. Observe all safety instructions to avoid damage through improper use! Follow all warnings on the product. Keep this instruction manual for future use. Should this product be passed on to a third party, then this instruction manual must be included.

- · Never use this product if damaged.
- Do not insert any foreign objects into the inside of the casing.
- Protect the product from extreme temperatures, hot surfaces, open flames, direct sunlight, water, high humidity, moisture, strong jolts, flammable gases, vapours and solvents.
- Keep this product and its packaging out of the reach of children and pets.

CAUTION Avoid looking directly into the beam.

9.1 Battery Warnings

DANGER Risk of explosion!

Risk of explosion if the battery is replaced by an incorrect type.

- When used correctly, primary batteries provide a safe and dependable source of portable power. However, misuse or abuse may result in leakage, fire, or explosion.
- Always take care to install your batteries correctly observing the "+" and "—" marks on the battery and the device. Batteries which are incorrectly placed into some equipment may be short-circuited, or charged. This can result in a rapid temperature rise causing venting, leakage, explosion and personal injury.
- Always replace the whole set of batteries at one time, taking care not to mix old and new ones or batteries of
 different types. When batteries of different brand or type are used together, or new and old batteries are used
 together, some batteries may be over-discharged due to a difference of voltage or capacity. This can result in
 venting, leakage, and explosion and may cause personal injury.
- Keep batteries out of the reach of children, especially small batteries that could be easily ingested.
- Immediately seek medical attention if a cell or battery has been swallowed. Also, contact your local poison control center.
- Store unused batteries in their original packaging and away from metal objects. Unpacked batteries could get
 jumbled or get mixed with metal objects. This can cause battery short-circuiting which may result in venting,
 leakage and explosion and personal injury; one of the best ways to avoid this from happening is to store
 unused batteries in their original packaging.
- Never dispose of batteries in fire. When batteries are disposed of in fire, the heat build-up may cause explosion and personal injury. Do not incinerate batteries except for approved disposal in a controlled incinerator.
- Never attempt to recharge primary batteries. Attempting to charge a non-rechargeable (primary) battery may cause internal gas or heat generation resulting in venting, leakage, explosion and personal injury.
- Never short circuit batteries as this may lead to high temperatures, leakage, or explosion. When the positive (+) and negative (-) terminals of a battery are in electrical contact with each other, the battery becomes short-circuited. This may result in venting, leakage, explosion and personal injury.

- In the event that the electrolyte comes into contact with the skin or eyes, immediately flush with fresh water for at least 15 minutes and seek medical attention.
- Never heat batteries in order to revive them. When a battery is exposed to heat, venting, leakage and explosion may occur and cause personal injury.
- Never attempt to disassemble, crush, puncture or open batteries. Such abuse may result in venting, leakage, rupture, and cause personal injury.
- Always purchase the correct size and grade of battery most suitable for the intended use.
- Clean the battery contacts and also those of the device prior to battery installation.
- Ensure the batteries are installed correctly with regard to polarity (+ and -).
- Remove batteries from device that is not to be used for an extended period of time. Remove used batteries promptly.

Symbols Explanation

This symbol stands for "Conformité Européenne", which declares "Conformity with EU directives, regulations and appplicable standards". With the CE-marking, the manufacturer confirms that this product complies with applicable European directives and regulation.

This symbol stands for "United Kingdom Conformity Assessed". With the UKCA-marking, the manufacturer confirms that this product complies with applicable regulations and standards within Great Britain.

—— Direct current (DC)

Cleaning and Maintenance

- Clean the product with a dry lint-free cloth. Do not allow any water or other liquids enter the product's interior.
- Donot use abrasives, harsh cleaning solutions or hard brushes for cleaning.
- Clean the battery contacts and also those of the product prior to battery installation.

Specifications

| Power Supply: | 1.5 V AA battery |
|----------------------|---------------------------------------------|
| Current consumption: | 30 mA |
| Weight: | 67.1 g (0.15 lbs) |
| Dimensions: | 4.1 x 2.9 x 1.5 in (10.50 x 7.45 x 3.77 cm) |
| Encryption: | AES128 |
| OS compatibility: | Windows 10 / 8 / 7 |
| Transmission power: | 1 mW |
| Frequency band: | 2.4 GHz (2.402 GHz – 2.480 GHz) |

12.1 Importer Information

| For EU | |
|----------------|------------------------------------------------------------------|
| Postal: | Amazon E:U Si r.I., 38 avenue John F. Kennedy, L-1855 Luxembourg |
| Business Reg.: | 134248 |

| For UK | |
|----------------|-------------------------------------------------------------------------------------------|
| Postal: | Amazon EU SARL, UK Branch, 1 Principal Place, Worship St, London EC2A 2FA, United Kingdom |
| Business Reg.: | BR017427 |

Disposal (for Europe only)

The Waste Electrical and Electronic Equipment (WEEE) laws aim to minimise the impact of electrical and electronic goods on the environment and human health, by increasing re-use and recycling and by reducing the amount of WEEE going to landfill.

The symbol on this product or its packaging signifies that this product must be disposed separately from ordinary household wastes at its end of life. Be aware that this is your responsibility to dispose of electronic equipment at recycling centres in order to conserve natural resources. Each country should have its collection centres for electrical and electronic equipment recycling. For information about your recycling drop off area, please contact your related electrical and electronic equipment waste management authority, your local city office, or your household waste disposal service.

Battery Disposal

Do not dispose of used batteries with your household waste. Take them to an appropriate disposal/collection site.

15. Feedback and Help

We would love to hear your feedback. To ensure we are providing the best customer experience possible, please consider writing a customer review. Scan QR Code below with your phone camera or QR reader: **US:**



https://www.amazon.com/review/review-your-purchases/listing/?ref=HPB_UM_CR

| UK: amazon.co.uk/review/review-your-purchases# |
|-------------------------------------------------------------------------------------------|
| If you need help with your Amazon Basics product, please use the website or number below. |
| US: amazon.com/gp/help/customer/contact-us |

UK: amazon.co.uk/gp/help/customer/contact-us
1 877-485-0385 (US Phone Number)



Documents / Resources



amazon basics B0787D6SGQ Wireless Ergonomic Mouse for PC [pdf] User Manual B0787D6SGQ Wireless Ergonomic Mouse for PC, B0787D6SGQ, Wireless Ergonomic Mouse for PC, Ergonomic Mouse for PC

References

• User Manual

Manuals+, Privacy Policy