

Anboqi Technology ABQ-A28 Wifi Camera



Anboqi Technology ABQ-A28 Wifi Camera User Guide

[Home](#) » [Anboqi Technology](#) » Anboqi Technology ABQ-A28 Wifi Camera User Guide 

Contents

- [1 Anboqi Technology ABQ-A28 Wifi Camera](#)
- [2 Specifications](#)
- [3 WiFi network configuration](#)
- [4 FAQ](#)
- [5 Warranty Card](#)
- [6 FCC STATEMENT](#)
- [7 Documents / Resources](#)
 - [7.1 References](#)

Anboqi Technology

Anboqi Technology ABQ-A28 Wifi Camera



Quick Operation Guide

- **Step 1:** Download and install the app Scan the QR code to download the app, or go to the app store and search for it.
- **Step 2:** Turn on the camera Long-press the reset button until you hear the prompt tone, then wait for the red light to flash, indicating that the camera is ready for setup.
- **Step 3:** Add the camera to the app Open the app, register an account, and log in. Click the '+' icon to add the camera. Choose your device type and follow the on-screen instructions.
- **Step 4:** Connect the camera to your network Ensure your phone's network connection is 2.4GHz. Enter the Wi-Fi password when prompted in the app to connect the camera to your network.

Specifications

Model	Quick Operation Guide
Power Supply	DC5V-1A
Power Consumption	<5W
Operating Temperature	-10°C~+50°C
Operating Humidity	Less than 95% RH

FAQ

- **Q1:** How to ensure a stable vision?
- **A1:** Place the camera in a location with a stable network connection, and ensure that the camera is within the range of your Wi-Fi router.
- **Q2:** How to fix the camera not connected or offline?
- **A2:** Check the camera's network connection and power supply, and ensure your router is online and working properly. Restart the camera if necessary.
- **Q3:** Is the reset supported?
- **A3:** Yes, you can reset the camera by pressing and holding the reset button for 5 seconds until you hear the prompt tone.

Notices

- This warranty is provided by the manufacturer and is valid for 12 months from the purchase date.
- This warranty is only applicable to the original purchaser and is not transferable.
- The warranty does not cover damage caused by accident, misuse, or any unauthorized disassembly, repair, or modification.
- The manufacturer's liability is limited to the repair or replacement of the product according to the warranty terms and conditions.
- Keep the camera away from strong magnetic fields to avoid image distortion.
- Do not expose the camera to high temperatures or direct sunlight.
- Do not place the camera in an extremely humid or dusty environment.
- Handle the camera with care to avoid physical damage.

For warranty service, please return the product to the dealer or authorized service centre with the warranty card and purchase receipt.

The company reserves the right to make a final decision in case of any disputes.

Quick Operation Guide

- **Step 1** Download and install the App

Tips on: Scan the QR code below to download the "iCSee" App.



Tips two: Search "iCSee" in the App Store and download.

- **Step 2** Turn on the power

Power on the camera, turn on the device, and it will send the “system starting up, wait be configured, Wait for the connection, please configure the network according to the Instructions” prompt after several seconds, If the camera does not have a prompt sound for a long time, you can press and hold the camera Reset button until you hear the prompt ” Restore factory settings, please do not power off “and release it to restore the camera to factory settings and then configure the network.

Note:

If you need local storage, please install the memory card first, and then power on the device (the memory card does not support hot swapping, please plug and unplug the memory card when the device is powered off). Cloud storage is recommended, which is safe and convenient. Details See “Step 4” for operation.


- **Slap 3** Configure the network of lha camera

Bluetooth network configuration

Note: If the device supports Bluetooth network configuration, please configure it as follows.

1. Connect your phone to the WiFi network and turn on Bluetooth.
2. Dpen the iCSee app, register an account and log in (Figure 1).

Figure 1




3. After successful login, Click the •• button in the top right corner of the screen (Figure 2).
4. Wait for the device to be added to be found, and click “OK” (Figure 3).

Figure 2





Figure 3



5. Enter the wireless router password and click ·confirm· (Figure 4).

6. Wait for the camera network configuration, when the camera emits the voice message "connecting, please use it, connect router successfully", the network connection is successful (Figure 5).

Figure 4





Figure 5



7. After the network configuration is successful, the s&t lha camera name(Figura 6).

8. Follow the APP interface to guide you through the set-up. After the oonnguration is completed, the device is displayed in the device list interface. Click to open the real-time preview screen. and carry out relevant operations and settings(Figure 7).

Figure 6





Figure 7



WiFi network configuration

Note: If the device does not support Bluetooth network configuration or Bluetooth network configuration fails, please configure it as follows.

1. Connect your phone to a WiFi network.
2. Login to iCSee App, click "+" to add devices (Figure 8), and select "WiFi Camera" (Figure 9).
3. Set network configuration according to the camera's voice prompts and the APP interface step-by-step guide.
When the camera emits a "Connect router successfully" prompt, it means that the camera has successfully configured the network.

Figure 8






Figure 9



4. After the network configuration is successful, follow the instructions on the APP interface to set the camera password and name.


5. After the configuration is completed, the device is displayed in the device list interface. Click to open the real-time preview screen, and carry out relevant operations and settings(Figure 10).

Figure 10



- **Step 4 Cloud Storage** Steps to open cloud storage: click the “cloud” icon in the device list interface (Figure 11), and follow the guidance of the app interface to understand and open the cloud storage package, with a variety of packages available.

Figure 11



- **Q:** How do cameras store video?
- **A:** Local TF card storage, maximum support up to 128G TF card after fully automatically deleting earlier video, overwrite video.
 - Cloud storage.
- **Q:** What to do if the camera is not connected or offline?
- **A:** Check if the camera power or network of the router normal.
 - 2. Plug the camera power to restart camera.
 - 3. Restore the camera to factory settings.
- **Q:** Is a 5g router supported?
- **A:** If you use 5g router, 5G and 2.4G use the same connection hotspot (that is, SSID is the same), you can connect directly. If 5G and 2.4G are not the same connection hotspot (that is, SSID is different, generally SSID of 2.4G is xxxxx-2.4G, SSID of 5G is xxxxx-
 - please connect the WiFi of the mobile phone to the hotspot of xxxxx-2.4G of the router before configuring the camera.

Notice

1. Please change the user password when using this product: to avoid being misappropriated by criminals.
2. Do not Install the device In a place that Is damp, dusty, or aloes! llble to children.
3. Please use and store within the allowable temperature and humidity range, and do not disassemble the equipment at will.

Directions

1. Please refer to the actual product, the manual is for reference only.
2. The APP and product firmware will be updated from time to time. You can upgrade to lhe latest firmware crnline by yourself without notice. The manual is for reference only.
3. The manual may contain technically inaccurate parts or parts that are inconsistent with product functions or printed errors. Please refer to our company's fi na l interpretation ..

Warranty Card

Product Name		Model	
Purchase Date		Purchase Store	
Cause			
Process			
Customer Name		Customer Gender	
Customer Phone		ZIP	
Address			

- Warranty period: one year.
- This warranty card is only for our company's products.

FCC STATEMENT

Labelling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference. and
2. this device must accept any interference received, including Inj Interference that may cause undesired operation.

Information to the user.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, according to part 15 of the FCC Rules.

Those limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used under the Instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to

correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help,

RF warning for Mobile devices

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum diameter of 20cm between the radiator & your body.

Documents / Resources

	Anboqi Technology ABQ-A28 Wifi Camera [pdf] User Guide ABQ-A28, ABQ-A28 Wifi Camera, Wifi Camera, Camera
---	---

References

- [User Manual](#)

[Manuals+](#). [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.