

androidty X8PLUS Android TV Box User Manual

Home » androidtv » androidtv X8PLUS Android TV Box User Manual

Contents

- 1 androidty X8PLUS Android TV
- **2 INTRODUCTION**
- 3 What's in the Box
- 4 Let's Get It Started
- 5 Troubleshooting Guide
- **6 FCC Statement**
- 7 Documents / Resources
 - 7.1 References




androidty X8PLUS Android TV Box



INTRODUCTION


Please read the user manual before you operate the device. Android and Android TV are trademarks of Google LLC.

What's in the Box



- 1. TV BOX
- 2. Remote Control
- 3. User Manual
- 4. HDMI Cable
- 5. Power Adapter

Let's Get It Started



1. Connection with TV

• Connect HDMI/AV cable to HDMI/AV port of the Android TV box and TV set.

2. Connection with Power

• Connect the power adapter to the Android TV box. After power is on, it can start automatically.

3. Connection with network

- Plug the Ethernet cable into the LAN port of the Android TV box, the other side into the LAN port of the router, of the Ethernet port of the home broadband network.
- **Notice:** Before powering on, please switch the signal input of the TV to the correct source.
- **Tips:** The Android TV box supports Wi-Fi as well. Go to settings > Network and then select the relevant SSID. Select connect, enter password to Wi-Fi.

Troubleshooting Guide

Issue	
No Power	Check if the power adapter is properly connected to the power and the TV BOX Press the power on the remote controller to turn on the power
No Picture	Re-Connect the TV BOX Check if the TV BOX and TV are powered on
No sound or distored sound	Adjust the volume Check that the speakers are connected correctly
The TV Stick does not respondto the remote control	Aim the remote control directly at the sensor on the front of the TV Reduce the distance to the TV BOX Replace batteries in the remote control Possibility of system crash, disconnect and reconnect the power supply
No sound during playback	The audio codec may not be supported by the TV BOX Check the volume
The contents of the USBor flash drive cannot be read	The USB or flash drive format is not compatible with the box If one of the drives can not be read, please turn off and unplug the TV BOX for 30 seconds, the re-plug the TV BOX into the TV HDM port
Slow operation of theUSB flash drive	Large or high resolution files on the USB flash drive take longer time to read and dispaly on the TV screen

- Warning Place the device in a well-ventilated location to prevent accumulation of internal heat.
- Protect the device from high temperatures, humidity, water, and dust.
- Do not place any objects that might damage your unit near it (e.g. liquid filled objects or candles).
- CAUTION Notice: To prevent fire and electric shock, do not expose this device to rain or moisture.
- To avoid any possible risk of electric shock, never attempt to open the unit. In case of the unit breaking down, repair of the unit should be carried out by qualified technicians. No part of this unit should be repaired by users.

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following four conditions:

This device may not cause harmful interference; This device must accept any interference received, including interference that may cause undesired operation; This device complies with FCC radiation exposure limits set forth for an uncontrolled environment This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

NOTE This equipment has been tested and found to comply with the limits for a Class B digital device, according to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment uses and can radiate radio frequency energy and, if not installed and used under the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. Suppose this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on. In that case, the user is encouraged to try to correct the interference by one of the following measures.

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF Exposure Information

- This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This
 equipment should be installed and operated with a minimum distance of 20cm between the radiator and your
 body.
- **Warning** Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

Documents / Resources



<u>androidtv X8PLUS Android TV Box</u> [pdf] User Manual
2AP2G-X8PLUS, 2AP2GX8PLUS, x8plus, X8PLUS Android TV Box, X8PLUS, Android TV Box, TV Box, Box

References

User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.