ANGEWOZ OBD2 Car Key Programmer Tool with Keyless Entry Remote





ANGEWOZ OBD2 Car Key Programmer Tool with Keyless Entry Remote User Guide

Home » ANGEWOZ » ANGEWOZ OBD2 Car Key Programmer Tool with Keyless Entry Remote User Guide 🖫



Contents

- 1 ANGEWOZ OBD2 Car Key Programmer Tool with Keyless Entry **Remote**
- **2 Product Usage Instructions**
- **3 IMPORTANT NOTES**
- **4 PROGRAMMING INSTRUCTIONS**
- **5 FREQUENTLY ASKED QUESTIONS**
- 6 Documents / Resources
 - **6.1 References**



ANGEWOZ OBD2 Car Key Programmer Tool with Keyless Entry Remote



Specifications:

Product: ANGEWOZ Key Fob and Programmer

Model: V1.0100

• Compatible with: Chevrolet, Buick, GMC, Cadillac, Pontiac, Saturn, Suzuki

• Maximum Remotes: Up to 4 total remotes

Product Usage Instructions

Important Notes:

Before proceeding with programming, ensure to read and understand the following:

- 1. All remotes, including new ones, must be reprogrammed.
- 2. Have at least one original key or fob available.
- 3. New key will only have original remote functions.
- 4. Maximum of 4 remotes can be added to the vehicle.
- 5. Do not use the programmer while the vehicle is in motion.

Programming Instructions:

Follow these steps to program your remotes:

- 1. Enter the vehicle and ensure all doors are closed.
- 2. Insert the key into the ignition and turn it to the ON position without starting the engine.
- 3. Plug the programmer into the OBD port located under the steering column near the brake pedals. The programmer will beep 3 times rapidly to indicate it has powered up.
- 4. Press and hold both LOCK and UNLOCK buttons simultaneously on the remote until you hear a beep from the vehicle or the door locks cycle (approximately 15-30 seconds).

Note:

Your vehicle may provide feedback such as door lock cycling, a dashboard message, or a chime during programming.

Frequently Asked Questions:

- Q: Can I use the same program on other vehicles?
 - A: No, the programmer is locked to the first vehicle it is used on. It cannot be used on different vehicles.
- Q: Where is the location of the OBD port?
 - A: The OBD port is located under the steering column near the brake pedals. It may be covered by a
 faceplate that can be easily removed.
 - For further assistance, contact technical support at:
 - Tel: (+86)17727801121
 - Email: angewoz service@163.com

Pairing Instructions for Chevrolet, Buick, GMC, Cadillac, Pontiac, Saturn, Suzuki Replacement Remotes

IMPORTANT NOTES

Before operating this equipment, please read these instructions carefully, paying particular attention to safety warnings and cautions. Failure to use this product correctly may result in damage and make the remote control unsuitable for the vehicle.

- 1. All currently programmed and new remotes must be reprogrammed to your vehicle. Please have all remotes in hand at the time of programming.
- 2. You must have at least one of the original keys or fobs for the programming process.
- 3. Only the original functions of the remote control can be used on the new key, regardless of the buttons on the new key. This key doesn't add remote features that your vehicle did not have before.
- 4. The vehicle allows add up to 4 total remotes.
- 5. Do not use the programmer while the vehicle is in motion. Unplug it from the OBD port before driving the vehicle. An alarm will sound reminding you to remove it after 5 minutes.

PROGRAMMING INSTRUCTIONS


Instructions have timing requirements. If you wait too long between steps, your vehicle's computer may time out, requiring you to start over. Once plugging the programmer in, you will have 2 MINUTES to program all new and existing remotes to the vehicle. After 2 minutes your session will time out and your vehicle will no longer in programming mode.

1. Enter the vehicle and close all doors



2.

Insert the key into the ignition and turn to the ON position. DO NOT start the engine



3. Insert the programme to your vehicle's on-board diagnostic(OBD) port. The programmer will beep 3 times rapidly when it powers up and starts the process.



- 4. PRESS and HOLD both LOCK and UNLOCK buttons simultaneously on the remote until you hear a beep from the vehicle or the door locks cycle (approximately 15~30 seconds).

 Note: Your vehicle may or may not provide feedback such as the door lock cycling, a message on the dashboard, or a chime.
- 5. Perform step 4 for all additional remotes.
- 6. After all remotes have been programmed, turn the key to the OFF position, remove the programmer and test each remote. If remote programming is unsuccessful, repeat the process from step 1.

Note: Some vehicles may need to have the engine started and stopped, and the driver's door opened and

closed before the remotes will work.

FREQUENTLY ASKED QUESTIONS

Q: Can I use the same program on other vehicles?

A: No, the programmer will be locked to the first vehicle that uses it. You may add more keys to the same vehicle again as needed, but it will not work on different vehicles.

Q: Where is the location of the OBD port

A: This port is located under the steering column, near the brake pedals. It may be covered by a faceplate that will easily pop off.

Thank you for purchasing the ANGEWOZ key fob and programmer. Our tools are manufactured to high standards, and following these instructions will provide trouble-free performance.

For help or assistance, please contact technical support at:

- Tel: (+86)17727801121
- E-Mail: angewoz-service@163.com

Documents / Resources



ANGEWOZ OBD2 Car Key Programmer Tool with Keyless Entry Remote [pdf] User Guide OBD2 Car Key Programmer Tool with Keyless Entry Remote, OBD2, Car Key Programmer Tool with Keyless Entry Remote, Keyless Entry Remote e, Entry Remote

References

User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.