



## anslut 014659 Infrared Heater Instruction Manual

[Home](#) » [anslut](#) » anslut 014659 Infrared Heater Instruction Manual 

### Contents

- 1 [anslut 014659 Infrared Heater](#)
- 2 **SAFETY INSTRUCTIONS**
  - 2.1 **TECHNICAL DATA**
  - 2.2 **HOW TO USE**
  - 2.3 **MAINTENANCE**
- 3 **Documents / Resources**
  - 3.1 **References**
- 4 **Related Posts**



**anslut 014659 Infrared Heater**



## SAFETY INSTRUCTIONS

- For outdoor use.
- The product can only be used for heating objects in rooms or on terraces, and only in accordance with these instructions. All other use, for example drying washing by hanging it on the product, is to be considered as incorrect use and is not permitted. Always respect the minimum of free space permitted around
- Check that the mains voltage corresponds to the rated voltage on the type plate. Only connect the product to an earthed power point that complies with the rules and regulations for the place in question and which is protected with an RCD with a tripping current of 30 mA.
- Only use the product as it is intended to be used – for the heating of terraces etc.  
The product must not be used to dry textiles,  
for commercial purposes, or for heating buildings, greenhouses, or stables etc.
- Handle the product with care and do not subject it to knocks and blows.
- Check that the mains voltage corresponds to the rated voltage on the type plate and that the power point is earthed.
- Pull out the plug when the product is not in use.
- Switch off the product and pull out the plug before cleaning and/or maintenance.
- Do not pull the power cord to pull out the plug.
- Never use an extension cord
  - fire risk.
- Place the power cord so it cannot be exposed to damage or stress, severe bending, sharp edges, or contact





with hot surfaces.

- The product's openings must not be covered.
- Do not cover the product.
- Make sure that wind or other conditions cannot bring curtains, drapes, awnings, flags, plastic ribbons etc. near the product, or cover the product – risk of material damage or fire. Do not place the product immediately over or under a power point.
- Do not place the product near flammable objects, or substances – fire risk.
- Do not touch the product with wet hands or wet parts of the body, and do not immerse it in water or any other liquid, or pour or spray water on it. Do not use the product near water, such as a bath, washbasin, washbowl, kitchen sink, in a wet basement or near a swimming pool. Do not use the product outdoors in the rain or in damp weather.
- The product is not intended to be controlled by an external timer, a separate remote control, or other equipment that can switch on the product automatically. The product is not intended to be controlled by an external voltage regulator, such as a dimmer – risk of material damage if connected to the product.
- Do not use the product in rooms where there are flammable substances (petrol, solvent, spray cans, etc.) or flammable materials (wood, paper, etc.). Keep such substances and materials away from the product – fire risk.
- Never poke your fingers or any objects into the inlet or outlet openings – risk of electric shock, fire and/or personal injury.
- Do not use the product if the power cord or plug are damaged, if it is not working properly, after it has been dropped, or if the product is damaged in any other way.
- Switch off the product immediately and pull out the plug if the product, the power cord or plug for any reason are not working properly.
- Contact an authorized service center if the product gets damaged or stops working properly. Do not dismantle the product or attempt to repair it. Repairs carried out by unauthorized or unqualified personnel will invalidate the warranty. The manufacturer cannot accept liability for any damage resulting from unauthorized repairs or modifications.
- This product can be used by children from 8 years of age and by persons with physical, sensorial or mental disabilities, or persons who lack experience or knowledge, if they are supervised or receive instructions concerning the safe use of the product and understand the risks involved. Keep children under supervision to make sure they do not play with the product. Do not allow children to clean or maintain the product without supervision.
- Keep small children under supervision to make sure they do not play with the product.
- Do not leave children unattended near the product, and choose a place for installation where children cannot access the product.
- The product is powerful and emits a lot of heat. For this reason do not expose animals or people, especially infants, older or sensitive persons, to the direct thermal radiation from the product.
- Switch off the product and pull out the plug from the power point before moving or cleaning the product.
- Pull out the plug when the product is not in use. Do not pull the power cord to pull out the plug.
- For safety reasons the product must be connected to a power point with a residual current device that has a maximum tripping current of 30 mA.
- Do not store gas cylinders or flammable liquids, such as paint or petrol, near the product. Do not use the product in an explosive environment, e.g. near flammable liquids, gas cylinders, spray cans etc. –risk of fire or

explosion.

## WARNING!

- Some parts of the product get very hot – risk of burn injuries. Keep the product under careful supervision when it is used by, or near children or persons with functional disorders.
- The product does not have a thermostat.
- Do not use the product unsupervised in small rooms where there are persons who cannot leave the room without assistance.
- Do not cover the product, this can result in overheating.

SYMBOLS	
	Read the instructions.
	WARNING!
	Do not cover.
CE	Approved in accordance with the relevant directives.
	Recycle discarded product in accordance with local regulations.

## WARNING!

New installations and extensions to existing systems should always be carried out by an authorised electrician. If you have the necessary experience and knowledge (otherwise contact an electrician), you can replace power switches and wall sockets, fit plugs, extension cords and light sockets. Incorrect installation can result in fatal injury and the risk of fire.

## TECHNICAL DATA

- Rated voltage 230 V ~ 50 Hz
- Output 450/900 W
- Safety class IP24

## HOW TO USE

1. Plug the plug into the power point.

2. The product has two power levels: I = 450 W and II = 900 W.

**FIG. 1**

**MAINTENANCE**


**WARNING!**

- Switch off the product and allow it to cool before maintenance or moving the product. Pull out the plug from the power point when the product is not in use.
- Do not expose the product, power cord or plug to water or any other liquid – risk of electric shock.

Wipe the product with a clean, non-fluffing cloth, or brush it clean with a soft brush. Never use abrasive detergent, hard brushes, strong chemicals or flammable detergents such as benzene, alcohol, or thinner etc.

<b>Model identifier(s): 014659</b>			
Item	Symbol	Value	Unit
Heat output			
Nominal heat output	P <sub>nom</sub>	0.9	kW
Minimum heat output (indicative)	P <sub>min</sub>	0.75	kW
Maximum continuous heat output	P <sub>max,c</sub>	0.9	kW
Auxillary electricity consumption			
At normal heat output	e <sub>lmax</sub>	–	kW
At minimum heat output	e <sub>lmin</sub>	–	kW
In standby mode	e <sub>lSB</sub>	–	kW
Type of heat input, for electric storage local space heaters only (select one)			
Manual heat charge control, with integrated thermostat			No
Manual heat charge control with room and/or outdoor temperature feedback			No
Electronic heat charge control with room and/or outdoor temperature feedback			No
Fan assisted heat output			No
Type of heat output/room temperature control (select one)			
Single stage heat output and no room temperature control			No
Two or more manual stages, no room temperature control			Yes
With mechanic thermostat room temperature control			No
With electronic thermostat room temperature control			No
Electronic room temperature control plus day timer			No
Electronic room temperature control plus week timer			No
Other control options (multiple selections possible)			
Room temperature control, with presence detection			No
Room temperature control, with open window detection			No
With distance control option			No
With adaptive start control			No
With working time limitation			No
With black bulb sensor			No
Contact details: <a href="http://www.jula.com">www.jula.com</a>			

## Documents / Resources

	<a href="#">anslut 014659 Infrared Heater</a> [pdf] Instruction Manual 014659 Infrared Heater, 014659, Infrared Heater, Heater
---	---

References

- [Jula – products for home and garden](#)
- [Jula – ingenting kan stoppe deg!](#)
- [Jula – Teraz nic Cię nie powstrzyma!](#)
- [Jula – inget kan stoppa dig nu!](#)