

# anslut 019928 LED Panel Instruction Manual

Home » anslut » anslut 019928 LED Panel Instruction Manual




#### **Contents**

- 1 anslut 019928 LED Panel
- **2 SAFETY INSTRUCTIONS** 
  - 2.1 ELECTRICAL **SAFETY**
- **3 TECHNICAL DATA**
- **4 INSTALLATION** 
  - **4.1 CONNECTION**
- **5 MAINTENANCE**
- 6 Documents / Resources
  - **6.1 References**
- 7 Related Posts



anslut 019928 LED Panel



#### **SAFETY INSTRUCTIONS**

- Read these instructions carefully before installing the product. Always consult qualified personnel if in doubt.
- · For indoor use.
- The light source is not replaceable. When the light source has reached the end of its useful life the complete light must be replaced.
- Disconnect the power supply before installation.
- The product must not be covered with anything that obstructs ventilation, e.g. insulation, foil, paper, plastic, or the equivalent.
- Check that the mains voltage corresponds to the rated voltage on the type plate.
- Always follow the electrical specifications on the product labelling.
- Do not use the product if the glass cover is damaged.
- Never modify the lamp, this could result in serious material damage/personal injury, and will invalidate the warranty.
- Check that no parts of the product are missing or damaged. Supplement/replace missing/damaged parts before starting the installation.
- · Keep out of the reach of children.
- Do not touch the product when it is in use. Switch off the product and allow it to cool before touching it.
- Do not install the product near sources of heat, or in damp conditions.
- If the cord to this lamp is damaged it must only be replaced by the manufacturer or service technician, or other qualified people, to ensure safe use.

#### **ELECTRICAL SAFETY**

New installations and extensions to existing systems should always be carried out by an authorised electrician. If you have the necessary experience and knowledge

(otherwise contact an electrician), you can replace power switches and wall sockets, fit plugs, extension cords and light sockets. Incorrect installation can result in fatal injury and the risk of fire.

### **SYMBOLS**


SYMBOLS	
	Read the instructions.
	Safety class II.
<u>8</u> 8 8	The product must not be covered with insulation material or the equivalent.
	The product is not dimmable.
CE	Approved in accordance with the relevant directives.
	Recycle discarded product as electrical waste.

### **TECHNICAL DATA**

Rated voltage	230 V ~ 50 Hz
Output	33 W
Energy class	Е
Safety class	II
Protection rating	IP20
Luminous flux	4100 lm
Colour temperature	4000 K
Life span	50000 h
Dimmable	No
Diffusion angle	120°
Power factor	0.95
Colour rendering index	80
Weight	2.3 kg

# **INSTALLATION**

# INSTALLATION OF LAMP Triangular bracket FIG. 1







FIG. 3



### CONNECTION

## **IMPORTANT:**

Disconnect the power supply before connecting.

- 1. Connect the mains voltage wires to the correct terminals and so that no copper wires are exposed outside the terminals.
- 2. Connect the control voltage wires as per the wiring diagram.
- 3. Fit the product and the actuator in the correct position.
- 4. Switch on the power supply.

### FIG. 4






FIG. 5




### **Connection of DALI controller**

FIG. 6



**Emergency connection** 

FIG. 7



#### **MAINTENANCE**

#### **IMPORTANT:**

Disconnect the power supply before cleaning the product.


- 1. Wipe the lamp with a dry or slightly damp cloth.
- 2. Wait until the lamp is completely dry before switching the power supply on again.

#### NOTE:

Do not use detergents, alcohol, solvents or the equivalent to clean.

#### INFORMATION FOR DISMANTLING

- 1. Remove this screws
- 2. Remove the back plate
- 3. Remove the foam plastic
- 4. Remove the reflector/LGP/diffusor FIG. 8



## **Documents / Resources**



### References

• Jula – products for home and garden