







































ANSMANN T12000FR Led Alu Torch User Manual

[Home](#) » [ANSMANN](#) » ANSMANN T12000FR Led Alu Torch User Manual 



BEDIENUNGSANLEITUNG
USER MANUAL
LED ALU TORCH
T12000FR

						
1x COB LED	COB: 120 W	≥ 70 Ra	20 cm	6500-7500 K	> 30.000 h	COB: 59°
HIGH	MEDIUM	LOW	BOOST			
						
7000 lm	3000 lm	350 lm	12000 lm	Li-Ion 7.4 V 5000 mAh 37 Wh	5.0 V 2.0 A USB TYPE-C	7 h
						
4500 lx	2400 lx	350 lx	8000 lx	USB Ladekabel	IPX5	IK07
						
up to 130 m	up to 95 m	up to 35 m	up to 178 m	-10 °C ... 25 °C	-10 °C ... 35 °C	0 °C ... 35 °C
						
1.5 h	2.5 h	12 h	~30 sec.	Aluminium	750 g	282.3 x Ø 64 x Ø 34.6 mm




Contents


- 1 T12000FR Led Alu Torch
- 2 GENERAL SAFETY INSTRUCTIONS
- 3 DANGER OF FIRE AND EXPLOSION
- 4 Documents / Resources
 - 4.1 References
- 5 Related Posts


T12000FR Led Alu Torch


SAFETY – EXPLANATION OF NOTES

Please take note of the following symbols and words used in the operating instructions, on the product and on the packaging:

 = **Information** | Useful additional information about the product

 = **Note** | The note warns you of possible damage of all kinds

 = **Caution** | Attention – Hazard can lead to injuries

 = **Warning** | Attention – Danger! May result in serious injury or death

PROPER INTENDED USE

The product serves as a mobile light source and is not intended for use in other applications. The product is intended exclusively for private, household use and is not suitable for commercial use or for household room

lighting and is only for use as described in the operating instructions. Use outside that stipulated in the information is improper use and this can result in damage to property or personal injury. We accept no liability for damage caused by incorrect or improper use.



GENERAL SAFETY INSTRUCTIONS

This product may be used by children from the age of 8 and by persons with reduced physical, sensory or mental abilities or lack of experience and knowledge, if they have been instructed on the safe use of the product and are aware of the hazards. Children are not permitted to play with the product. Children are not permitted to carry out cleaning or care without supervision.

Keep the product and the packaging away from children. This product is not a toy. Children should be supervised in order to ensure that they do not play with the product or packaging.

Avoid eye injuries – Never look directly into the beam of light or shine it into other people's faces. If this occurs for too long, the blue light portion of the beam can cause retinal damage.

Never touch a device that is connected to the mains with wet hands, or if it has fallen into water. In this case, first switch off the house circuit breaker and then pull out the mains plug.

Do not expose to potentially explosive environments where there are flammable liquids, dusts or gases. Never submerge the product in water or other liquids. Use only an easily accessible mains socket so that the product can be quickly disconnected from the mains in the event of a fault.

All illuminated objects must be at least 10cm away from the lamp.

Use the product exclusively with the accessories included with it.

Never try to open, crush or heat a standard/rechargeable battery or set it on fire. Do not throw into a fire.



The product may only be charged in closed, dry and spacious rooms, away from combustible materials and liquids. Disregard can result in burns and fires.

Leaking battery fluid can cause irritation if it comes into contact with the skin. Immediately rinse affected areas with fresh water and then seek medical attention.

Do not short-circuit connection terminals or batteries.



DANGER OF FIRE AND EXPLOSION

Do not use while still in the packaging.

Do not cover the product – risk of fire.

Never expose the product to extreme conditions, such as extreme heat/cold etc.

Do not use in the rain or in damp areas.



GENERAL INFORMATION

- Do not throw or drop
- The LED cover cannot be replaced. If the cover is damaged, the product must be disposed of.
- The LED light source cannot be replaced. If the LED has reached the end of its service life, the complete lamp must be replaced.
- Do not open or modify the product! Repair work shall only be carried out by the manufacturer or by a service technician appointed by the manufacturer or by a similarly qualified person.
- Disconnect the device from the power supply only by pulling on the plug or plug housing, never on the cable.
- Information for the light and mains adapter as well as mains voltage on the socket must match with the type plate.
- The lamp shall not be placed face-down or allowed to topple face-down.



RECHARGEABLE BATTERY PACK

The product contains a non-replaceable, rechargeable battery pack. If the rechargeable battery pack is empty, recharge it immediately. Once fully charged, remove from the charger.

In the event of liquid leaking from the power source, remove this with protective gloves and a dry cloth.

 **Charge the lamp on a fireproof surface and only under the constant supervision of an adult!**

ENVIRONMENTAL INFORMATION DISPOSAL

Dispose of packaging after sorting by material type.

Cardboard and cardboard to the waste paper, film to the recycling collection.



■ Dispose of the unusable product in accordance with legal provisions. The „waste bin“ symbol indicates that, in the EU, it is not permitted to dispose of electrical equipment in household waste.

For disposal, pass the product on to a specialist disposal point for old equipment, use the return and collection systems in your area or contact the dealer from whom you purchased the product.



Batteries and rechargeable batteries contained in electrical appliances must be disposed of separately whenever possible.

Always dispose of used batteries & rechargeable batteries (only when discharged) in accordance with the local regulations and requirements.

Improper disposal may result in toxic ingredients being released into the environment, which may have adverse health effects on humans, animals and plants.

In this way you will fulfil your legal obligations and contribute to environmental protection.

PRODUCT DESCRIPTION

1. Main light
2. On/off button
3. LED status display
4. Battery compartment
5. Charge socket with rubber cover
6. USB output socket (power-bank function)
7. Zoom swivel joint

FIRST USE

- Insert the battery with the correct polarity.
- Pressing the button cycles through the following functions:
- Press 1× = High power
- Press 2× = Medium power
- Press 3× = Low power
- Press 4× = Off
- Press and hold to activate the boost function.

Boost mode is active for approx. 30sec, then automatic change to „High power“.

LED indicator

Battery capacity <10%: LED flashes orange

Charge battery

LED flashes green: charging

LED lights green: fully charged

Lighting and charging at the same time is not possible.



The product complies with the requirements from the EU directives.
Subject to technical changes. We assume no liability for printing errors.

	Class 3 equipment
	Conforms to the European directive
	UK Conformity Assessed
	Risk-Group – Do not look into the lamp
	Waste of Electrical and Electronic Equipment (WEEE-Guideline)
	Battery disposal information – Not for household waste
	Read the operating instructions carefully before use!
	Minimum distance from lighted objects
	IP-Protection class

Customer service:

ANSMANN AG
Industriestrasse 10, 97959 Assamstadt
Germany
Support & FAQ: [ansmann.de](https://www.ansmann.de)
E-Mail: hotline@ansmann.de
Hotline: +49 (0) 6294 / 4204 3400
MA-1600-0595/V0/07-2023

Documents / Resources

	ANSMANN T12000FR Led Alu Torch [pdf] User Manual T12000FR Led Alu Torch, T12000FR, Led Alu Torch, Alu Torch, Torch
--	---

References

- [^ **ANSMANN AG - We bring products to life**](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.