



## AOC GM200 Gaming Mouse User Guide

[Home](#) » [AOC](#) » AOC GM200 Gaming Mouse User Guide 

### Contents

- [1 AOC GM200 Gaming Mouse](#)
- [2 PACKAGE CONTENTS/SYSTEM REQUIREMENTS](#)
- [3 Specifications](#)
- [4 Technical support](#)
- [5 DEVICE LAYDUT AND FUNCTIDNAL](#)
- [INTRDDUCTION](#)
- [6 SAFETY AND MAINTENANCE](#)
- [7 Documents / Resources](#)
- [8 Related Posts](#)

# AOC

**AOC GM200 Gaming Mouse**



## **PACKAGE CONTENTS/SYSTEM REQUIREMENTS**

### **Package contents**

- AOC GM200 gaming mouse
- USER'S GUIDE

### **System requirements**

- Windows® 7 or above/Mac OS
- Available USB port

### **Specifications**

- Advanced optical sensor with true 4,200 dpi
- Up to 48 inches per second(IPS)
- Switchable DPI -800 (Green)/1600 (Yellow)/2400(Blue)/ 4200 (Red) default 800 DPI
- Mechanical switch with up to 10 million clicks lifespan
- Up to 1000Hz/ms report rate

### **Approximate Size & Weight**

- **Length:** 127 mm/ 5 in
- **Width:** 74 mm/ 2.9 in

- **Height:** 40 mm/ 1.57 in
- **Weight:** 148 g/0.35 lbs
- **Cable Length:** 1.8 m/ 5.9 ft


### Operating Environment

- **Operating Temperature:** 0 ° C (32 ° F) to 40 ° C (104 ° F)
- **Operating Humidity:** 10% – 85%

### Technical support

- 2 years limited warranty
- Free on line technical support at <https://eu.aoc.com>

### DEVICE LAYDUT AND FUNCTIDNAL INTRDDUCTION



- **A.** Left button
- **B.** Right button
- **C.** Scroll wheel
- **D.** Forwarder button
- **E.** Backward button
- **F.** DPI setting (Default) BOO (Green) -1600 (Yellow) – 2400 (Blue) -4200 (Red)
- **G.** Foot pad
- **H.** Cable
- **I.** Optical Sensor

### Getting started and lighting effect

1. Plug the device into USB port on your computer.
2. The computer operating system will automatically detect the device (no drivers required).
3. RGB light will start breathing.


## SAFETY AND MAINTENANCE

### Important

For your safety, please carefully read the following guidelines for the device. , ,

1. Do not operate the device under abnormal conditions.
2. Avoid Looking directly at the device's tracking beam or pointing the beam at anyone's eyes. Please note that the tracking beam is not visible to the naked eye and is set as always-on.
3. Do not disassemble the device (this will void the warranty) and do not attempt to operate under abnormal current Loads.
4. Keep the device away from Liquid or moisture. Operate the device only within the indicated temperature range: 0 • C (32 • F) to 40 • C (104 • F). If the temperature of the device is too high, unplug the device to Lower the temperature.
5. If the RGB Lighting is not running properly, or the device is not functioning, or if there is an abnormal thermal situation, troubleshoot the device by unplugging the device and plugging the device back in.
6. If the troubleshooting process does not resolve the issue, unplug the device and visit <https://eu.aoc.com> for support. Do not attempt to repair the device yourself.

## Documents / Resources

|   |  |
|---|--|
|  <p>AOC GAMING</p> <p>GM200 GAMING MOUSE</p> <p>© 2022 AOC. All Rights Reserved.</p> | <p><a href="#">AOC GM200 Gaming Mouse</a> [pdf] User Guide</p> <p>GM200 Gaming Mouse, GM200, Gaming Mouse, Mouse</p> |
|---|--|