




Arkfeld Copper Bones Three Light Sources Portable EDC Flashlight User Manual

[Home](#) » [Arkfeld](#) » Arkfeld Copper Bones Three Light Sources Portable EDC Flashlight User Manual 

Contents

- [1 Arkfeld Copper Bones Three Light Sources Portable EDC Flashlight](#)
- [2 Mul1ti-language dictionary. see Table 3:](#)
- [3 Documents / Resources](#)
 - [3.1 References](#)
- [4 Related Posts](#)


Arkfeld Copper Bones Three Light Sources Portable EDC Flashlight



USER MANUAL



Arkfeld Pro Copper Bones









MCC

Table 1:

Specifications


COOL WHITE CCT: 5700~6700K CRI:70

NEUTRAL WHITE CCT: 4000~5000K CRI:70

TURBO	1300 lumens		4min		126min
HIGH	420 lumens		135min		12min
MED	100 lumens		9h45min		
LOW	15 lumens		6.5h		

Input	USB-A DC 5V 1A
Output	CC&CV 4.2V 1A
Time to fully charge	About 2.5 hours

Figure 1
Lock/Unlock



Press and hold




> 1 sec



> 2 sec



Figure 2
Charging








Figure 3

Selector---Switch Mode:






Mode change

OPERATE IN WHITE LIGHT MODE

Figure 4

ON/OFF



Press





Figure 5
Moonlight




Press and hold



Figure 6

Turbo



Triple press





Figure 7

Strobe



Double press





Figure 8

Change Brightness Level





Press and hold





Figure 9

Timed shutdown



Double press and hold

Blink once : 3 min

Blink twice : 9 min






OPERATE IN LASER MODE

Figure 10

ON/ OFF



Press




Figure 11

**Turn on the white light while the
laser on**






Figure 12

Turn off the white light while the laser on








Figure 13

When the laser and white light are turned on at the same time, change the brightness of the white light



Press and hold




OPERATE IN UV MODE

Figure 14

ON / OFF

ON/ OFF



Press






Figure 15

Battery Level Indicator Display






* One red indicator (<10%)

OPERATE IN UV MODE

Figure 14

ON/ OFF




OFF



ON

Figure 15

Battery Level Indicator Display



* One red indicator (<10%)

Multilingual dictionary. see Table 3:

1. Please refer to Table 1 and Table 2 for product specifications;

2. Lock/unlock. see Figure 1:

When the light is off, press and hold the button (about 2 seconds) until you see moon light mode. the laser (Laser mode), or UV

light (UV mode) turn on and then quickly off. the flashlight has then been locked out. when the light is locked, press and hold the button (about 1 second) until the flashlight activates moonlight mode. the laser or UV light. the flashlight will then be unlocked.

3. Charging. see Figure 2:

4. The selector switch mode, see Figure 3;

Rotate the selector clockwise to select moonlight mode; rotate the selector counter-clockwise to switch to UV mode; stop in the middle to switch to laser mode.

5. In the white light mode. the center button operation guide: 5.1 Turn on/off the flashlight? see Figure 4:

Single press the button to turn on and off.

5.2 Moonlight. see Figure 5;

Press and hold for 5 seconds when the light is off. the light will enter moonlight mode.

5.3 TURBO. see Figure 6;

Press the Switch three times or 10 times continuously to turn on Turbo. 5.4 Strobe. see Figure 7;

In bright light? quickly double press the switch to turn on Strobe.

5.5 Change brightness level. see Figure B;

While the flashlight is on, press and hold the on/off cycle through the brightness levels. The order of brightness is low, medium, then high.

5.6 Timed shutdown, see Figure 9;

When the light is on, double press and hold the Switch to access the timer settings. A single press accesses the short timer while the light blinks accesses the long timer. The light will automatically turn off when the timer reaches its setting.

6. Instructions for center button operation in laser mode: 6.1 Turn Off the laser. see Figure 10;

Single press the button to turn on/off the laser.


6.2 When the laser is on, turn on the highest brightness white light. see Figure 11:

With the laser on, double press the center button to activate white light high level.

6.3 When the laser is on, turn off the white light. see Figure 12; When the laser and the white light are on at the same time, double press to turn off the white light. the laser will continue to.

6.4 When the laser and white light are turned on at the same time, change the brightness of the white light. see Figure 13; When the laser and the white light are on at the same time, press and hold the button to cycle through the brightness levels. The order of brightness is Low, medium, then high.

Documents / Resources



[Arkfeld Copper Bones Three Light Sources Portable EDC Flashlight](#) [pdf] User Manual
Copper Bones Three Light Sources Portable EDC Flashlight, Copper Bones, Three Light Sources Portable EDC Flashlight, Sources Portable EDC Flashlight, Portable EDC Flashlight, EDC Flashlight, Flashlight

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.