



Artograph 225360 Tracer Projector User's Guide

[Home](#) » [Support](#) » Artograph 225360 Tracer Projector User's Guide 

Contents

- [1 Artograph 225360 Tracer Projector](#)
- [2 Specifications](#)
- [3 IMPORTANT SAFETY INSTRUCTIONS](#)
- [4 Set up & Operation](#)
- [5 Projector Maintenance](#)
 - [5.1 Cleaning](#)
- [6 Warranty](#)
- [7 User Support](#)
- [8 FAQs](#)
- [9 Video- Product Honest Review](#)

ARTOGRAPH®

Artograph 225360 Tracer Projector



Specifications

- **Product Dimensions:** 17 x 7 x 15 inches
- **Item Weight:** 3.69 pounds
- **Manufacturer:** Artograph
- **Item model number:** 225360
- **Recommended Uses For** Product Education, Home Cinema, Business
- **Special Feature:** Lightweight
- **Item Dimensions LxWxH:** 17 x 7 x 15 inches
- **Form Factor:** Portable

Thank You... for purchasing Artograph's Tracer Projector. Whether you wish to enlarge a pattern, trace a picture, create a mural, or more, the Tracer provides a fast and easy way to let you get to the fun part faster. We hope you enjoy your new Tracer! If you have any questions or suggestions, please contact us at 763-553-1112, toll-free at 1-888-975-9555, or send an email to info@artograph.com. Electrically-operated product. For use by ages 15 and up.

IMPORTANT SAFETY INSTRUCTIONS

When using this projector, always follow basic safety precautions, including the following:

1. Read and understand all instructions before operating.
2. Close supervision is necessary when used by or near children. Do not leave it unattended while in use.
3. Do not operate this equipment with a damaged cord, or if it has been dropped or otherwise damaged until it has been examined by a qualified electrician.
4. If an extension cord is necessary, be sure it has a suitable current rating. Cords rated for less amperage than this equipment may overheat. Be careful to arrange the cord so that it will not be tripped over or pulled.
5. Always unplug from the electrical outlet when not in use. Disconnect by grasping and pulling the plug from the

outlet; never yank the cord to disconnect the plug.

6. Allow the projector to cool completely before moving. Loop the cord loosely when storing.
7. If the projector receives water damage, do not use it until inspected by a qualified electrician.
8. To avoid electrical shock hazards, do not disassemble. Take the projector to a qualified electrician. Incorrect reassembly can cause an electrical shock hazard.
9. Care must be taken as burns can occur from touching hot parts.
10. The projector switch is provided with the symbols 0, indicating off, and I, indicating on.
11. Position the cord so that it will not be tripped over, pulled, or come in contact with hot surfaces.
12. Always unplug the projector from the electrical outlet before cleaning, servicing, and when not in use.
13. To reduce the risk of electrical shock, do not immerse this projector in water or other liquids.
14. The use of attachments not recommended by the manufacturer may cause the risk of fire, electric shock, or injury to persons.
15. Connect this projector to a grounded outlet.
16. Disconnect the projector from the power supply before replacing the lamps.

WARNING: The Tracer must be positioned near an electrical outlet. Carefully arrange the cord so that it won't be tripped over or pulled while projecting in a dark room.

CAUTION: We do not recommend using photographs or resin-coated prints with the Tracer. Photographs were not intended to handle the intense light and heat created by a projector. Photographs may be adversely affected by the heat and light. If using original or valuable art, we recommend that you project from copies if it can not be replaced.

Set up & Operation

- **Step 1.** Place art face-up on a hard surface
- **Step 2.** Place Tracer over art
- **Step 3.** Switch off "O"
- **Step 4.** Plug-In
- **Step 5.** Switch on "I"
- **Step 6.** Adjust room lighting
- **Step 7.** Sizing the image
- **Step 8.** Focusing

Projector Maintenance

Cleaning

- **LENS:** Clean the lens with a commercial lens cleaner and a soft cloth or lens tissue. Apply cleaner to the cloth: NEVER apply cleaner directly onto the lens as it may seep inside.
- **MIRROR:** The Tracer features a special front-surface mirror, which eliminates double imaging and enhances brightness. Normally the mirror will not require cleaning other than occasional dusting. Clean the silvered surface with care using a mild cleaning solution and a soft cloth or tissue. DO NOT SCRUB!
- **LAMP:** Use LED 10-15 watt with A19 bulb shape.

Warranty

Be sure to register your Artograph product online at www.artograph.com.

THIS WARRANTY DOES NOT APPLY TO LAMPS. Artograph® products are warranted to be free from defects in material and workmanship for a period of one year from the date of sale to the original purchaser. Any defective product will be repaired or replaced by Artograph® at its option, provided the product is returned, shipping prepaid, to our factory within the warranty period. The customer shall promptly notify either the original seller or Artograph of any warranty claim in sufficient detail to describe both the problem and its symptoms along with a copy of the original purchase receipt or other acceptable proof of purchase. All allowed returns will be provided a Return Authorization (RA) number. Any product received without a Return Authorization number will be returned. Equipment repaired or replaced under this warranty will be returned freight or postage prepaid. The warranty period for repaired or replacement products shall be for the same duration as the original warranty. This warranty does not cover repair for damage to the product, or product components or malfunctions caused by (i) misuse, neglect, power failures or surges, lightning, fire, flood, or accident; (ii) use of products or facilities supplied by others; or (iii) failure to follow installation, operation or maintenance instructions.

THE EXPRESS WARRANTIES HEREIN CONTAINED ARE IN LIEU OF ANY AND ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT, EACH OF WHICH SELLER DISCLAIMS AND ARE EXCLUDED. WHILE THERE ARE NO WARRANTIES THAT EXTEND BEYOND THE DESCRIPTION ON THE FACE HEREOF, THE CUSTOMER'S LOCAL LAW MAY PROVIDE OTHERWISE. SELLER SHALL NOT BE LIABLE FOR DAMAGES, INCLUDING SPECIAL AND INCIDENTAL OR CONSEQUENTIAL DAMAGES, INTERRUPTION OF BUSINESS ARISING OUT OF OR IN CONNECTION WITH PERFORMANCE OF THE PRODUCTS OR USE BY CUSTOMER.

This Class B RFLD complies with the Canadian standard ICES-005.

User Support

- 763-553-1112
- 888-975-9555
- service@artograph.com
- www.artograph.com
- 525 9th Street South Delano, MN 55328-8624 U.S.A.

FAQs

What is the Artograph 225360 Tracer Projector?

The Artograph 225360 Tracer Projector is a versatile image projector designed for artists and professionals, allowing them to enlarge and trace images onto various surfaces.

What types of surfaces can I project onto with this projector?

You can project images onto a variety of surfaces, including paper, canvas, walls, and fabric, making it useful for a wide range of artistic projects.

What is the maximum image size that can be projected?

This projector can enlarge images up to 10 times their original size, depending on the distance between the projector and the surface.

Does it have a built-in light source?

Yes, the Artograph 225360 Tracer Projector is equipped with a bright and durable LED light source, ensuring clear and consistent projection.

Is it suitable for both professional artists and beginners?

Yes, it is suitable for artists of all levels, from beginners to professionals, due to its ease of use and versatile applications.

Can I adjust the brightness of the projected image?

Yes, you can typically adjust the brightness level to suit your preferences and the lighting conditions of your workspace.

Is it portable and easy to set up?

Yes, this projector is designed to be portable and easy to set up, making it convenient for artists on the go.

What types of images can I project with it?

You can project a wide range of images, including drawings, photographs, sketches, and more, onto your desired surface.

Is it suitable for use in dimly lit environments?

Yes, the LED light source provides ample brightness for tracing in various lighting conditions, including dimly lit spaces.

Can I use it for both horizontal and vertical projections?

Yes, the Artograph 225360 Tracer Projector allows for both horizontal and vertical projection, giving you flexibility in your artistic projects.

Does it come with a lens for fine-tuning the projection size?

Yes, it often includes a lens that allows you to adjust and fine-tune the size and focus of the projected image.

Is there a warranty included with the product?

Warranty terms may vary, but many Artograph projectors come with a manufacturer's warranty to ensure product quality and reliability.

Can I use this projector for professional presentations?

While it's primarily designed for artistic purposes, you can use it for professional presentations that involve image projection.

Video- Product Honest Review



[Download this PDF Link: Artgraph 2259607849/Projector-2259607849-Grader-Projector.mp4](#)

Manuals+.