

[manuals.plus](#) /› [Energizer](#) /› [Energizer MAX C Alkaline Batteries User Manual](#)

## Energizer E93BP-2

# Energizer MAX C Alkaline Batteries User Manual

Model: E93BP-2

## 1. PRODUCT OVERVIEW

Energizer MAX C Alkaline Batteries are designed to provide long-lasting, dependable power for your everyday devices. These batteries incorporate PowerSeal Technology, an innovation from Energizer that ensures reliable energy delivery. They are suitable for a wide range of household electronics.

Key features include:

- Long-lasting power for everyday electronics.
- Holds power for up to 10 years while in storage, ensuring availability when needed.
- Features PowerSeal Technology for reliable energy.
- World's first zero mercury alkaline battery.



Image showing the front of an Energizer MAX C Alkaline Batteries 2-Count package.

## 2. SAFETY INFORMATION

Please read and follow these safety guidelines carefully to prevent injury or damage:

- **Do not install backwards:** Ensure correct polarity (+/-) when inserting batteries into a device.
- **Do not charge:** These are non-rechargeable alkaline batteries. Attempting to charge them may cause leakage or explosion.
- **Do not put in fire:** Exposing batteries to fire can cause them to explode.
- **Do not mix with other battery types:** Mixing old and new batteries, or different battery types (e.g., alkaline with carbon-zinc), can cause leakage or explosion.
- **Replace all batteries at the same time:** For optimal performance and safety, replace all batteries in a device simultaneously.
- **Keep out of reach of children:** Batteries can be a choking hazard.
- **Store in a cool, dry place:** Avoid extreme temperatures and humidity.

## 3. SETUP

To install Energizer MAX C Alkaline Batteries in your device:

1. Identify the battery compartment on your electronic device.
2. Open the battery compartment cover.
3. Observe the polarity markings (+ and -) inside the compartment.
4. Insert the Energizer MAX C batteries, aligning the positive (+) end of the battery with the positive (+) terminal in the compartment, and the negative (-) end with the negative (-) terminal.
5. Ensure all batteries are securely seated.
6. Close the battery compartment cover.

## 4. OPERATING INSTRUCTIONS

---

Once the Energizer MAX C Alkaline Batteries are correctly installed, your device should be ready for operation. Refer to your device's specific user manual for instructions on how to power it on and use its functions.

These batteries are suitable for a variety of devices, including:

- Flashlights
- Radios
- Toys
- Clocks
- Portable audio players
- Other high-drain and everyday electronics requiring C batteries.

## 5. MAINTENANCE

---

Proper handling and storage can extend the life and ensure the safety of your batteries:

- **Storage:** Store unused batteries in their original packaging in a cool, dry place at room temperature. Avoid storing them in direct sunlight or extreme temperatures.
- **Disposal:** Dispose of used batteries according to local regulations. Many communities have recycling programs for batteries. Do not dispose of batteries in household trash or fire.
- **Cleaning:** If battery terminals appear dirty, gently wipe them with a clean, dry cloth.
- **Removal from unused devices:** If a device will not be used for an extended period, remove the batteries to prevent potential leakage and damage to the device.

## 6. TROUBLESHOOTING

---

If your device is not functioning after installing new batteries, consider the following:

- **Check Polarity:** Ensure batteries are inserted with the correct positive (+) and negative (-) orientation.
- **Verify Contact:** Make sure the battery terminals are clean and making proper contact with the device's contacts.
- **Test Batteries:** If possible, test the batteries with a battery tester to confirm they have a charge.
- **Inspect Device:** Check the device itself for any damage or malfunction. Try the batteries in another compatible device if available.
- **Replace All Batteries:** If only some batteries were replaced, ensure all batteries in the device are new and of the same type.

## 7. SPECIFICATIONS

Specification	Detail
Model Number	E93BP-2
Battery Type	C Alkaline
Count	2 batteries per package
Shelf Life	Up to 10 years in storage
Battery Cell Composition	Alkaline
Product Dimensions	4.3 x 3.7 x 1.2 inches (package)
Weight	2.34 ounces (package)
Manufacturer	Energizer
First Available Date	December 4, 2006

## 8. WARRANTY AND SUPPORT

For information regarding product warranty, technical support, or general inquiries, please visit the official Energizer website or contact their customer service.

Official Website: [www.energizer.com](http://www.energizer.com)

Energizer is committed to providing reliable power solutions and customer satisfaction.