

## Sharpie 30001

# Sharpie Permanent Markers User Manual

Model: 30001 | Brand: Sharpie

## INTRODUCTION

This manual provides essential information for the proper use and care of your Sharpie Permanent Markers. Designed for vibrant, bold, and lasting impressions, these fine-point markers are suitable for a wide range of surfaces including paper, plastic, and metal. They feature quick-drying, water-resistant, and fade-resistant ink, making them a reliable tool for various applications in offices, classrooms, and homes.



Figure 1: Sharpie Fine Tip Permanent Markers, 12-count pack.

## PRODUCT FEATURES

- **Fine-Tipped for Detailed Marks:** The versatile fine tip allows for precise and eye-catching marks.
- **Permanent Ink:** Formulated to create resilient marks on diverse surfaces such as paper, plastic, and metal.

- **Quick-Drying:** Ensures rapid drying to prevent smudging and maintain the integrity of your work.
- **Vibrant Impressions:** Rich black ink provides strong, clear marks for differentiation and emphasis.
- **Water and Fade Resistant:** Designed for long-lasting results that resist fading over time and exposure to water.
- **AP Certified:** Suitable for use in various environments, including educational and professional settings.
- **High Quantity:** Each pack contains 12 black Sharpie permanent markers.



Figure 2: Fine tip for precise and detailed markings.



Figure 3: Permanent ink adheres to multiple surfaces.



Figure 4: Water and fade resistant properties of Sharpie ink.

---

## SETUP

Sharpie Permanent Markers are ready for immediate use directly out of the packaging. No assembly or special preparation is required.

1. Remove the marker from its packaging.
2. Carefully remove the cap by pulling it straight off. Avoid twisting to prevent damage to the tip.
3. The cap can be placed on the end of the marker barrel while in use to prevent loss and provide a balanced feel.



Figure 5: Markers are ready for use directly from the packaging.

## OPERATING INSTRUCTIONS

Sharpie Permanent Markers are designed for ease of use across various applications.

### General Use:

- Hold the marker firmly, ensuring a comfortable grip.
- Apply the fine tip to the desired surface with light to moderate pressure.
- Allow a few seconds for the ink to dry completely, especially on non-porous surfaces, to prevent smudging.
- Always replace the cap securely after each use to prevent the ink from drying out.

### Recommended Surfaces:

- Paper and Cardboard
- Plastic (e.g., storage bins, containers)
- Metal (e.g., tools, labels)
- Wood
- Fabric (note: ink is permanent and may bleed on some fabrics)



Figure 6: Using a Sharpie marker on a notebook.



Figure 7: Labeling a storage container with a Sharpie marker.

## MAINTENANCE AND CARE

- **Always Cap After Use:** To prevent the ink from drying out, ensure the cap is securely replaced on the marker after every use. A click sound indicates a secure seal.
- **Storage:** Store markers horizontally to ensure even ink distribution and prevent one side of the tip from drying out. Store at room temperature, away from direct sunlight or extreme heat.
- **Cleaning:** If ink gets on unintended surfaces, rubbing alcohol or hand sanitizer may help remove it from non-porous materials. Test in an inconspicuous area first.
- **Avoid Excessive Pressure:** While durable, applying excessive pressure can fray the fine tip over time.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Marker not writing or ink is faint.	Cap left off, ink dried out, or low ink level.	Ensure cap is always replaced. Try gently pressing the tip on a scrap piece of paper to re-prime. If still faint, the marker may be empty and needs replacement.
Ink smudges after writing.	Not enough drying time, especially on non-porous surfaces.	Allow more time for the ink to dry completely before touching the marked surface. Drying time varies by surface.
Tip appears frayed or damaged.	Excessive pressure during use or improper storage.	Use lighter pressure when writing. Ensure markers are stored horizontally. A damaged tip cannot be repaired, and the marker should be replaced for optimal performance.

## SPECIFICATIONS

Attribute	Detail
Brand	Sharpie
Model Number	30001
Item Weight	3.2 ounces (for 12-count pack)
Product Dimensions (per marker)	Approximately 5.6 inches (14 cm) in length
Color	Black
Material Type	Aluminum (barrel)
Number of Items	12 Count (Pack of 1)
Point Type	Fine
Ink Color	Black




Figure 8: Approximate dimensions of a single Sharpie marker.

---

## SAFETY INFORMATION

Sharpie Permanent Markers contain alcohol-based ink. Please observe the following safety guidelines:

- **Ventilation:** Use in a well-ventilated area to avoid inhaling fumes.
  - **Flammability:** Keep away from open flames or high heat sources.
  - **Skin Contact:** Avoid prolonged skin contact. Wash hands thoroughly after use.
  - **Eye Contact:** In case of eye contact, flush immediately with plenty of water and seek medical advice if irritation persists.
  - **Ingestion:** Do not ingest. If swallowed, seek immediate medical attention.
  - **Children:** Keep out of reach of young children. Adult supervision is recommended for use by children.
  - **Proposition 65 Warning:** This product may contain chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.
- 

## WARRANTY AND SUPPORT

Specific warranty information for Sharpie Permanent Markers is not provided in this manual. For details regarding product warranty, returns, or customer support, please refer to the official Sharpie website or contact their customer service directly.

You can visit the official Sharpie Store for more information: [Sharpie Official Store](#)