

**Microsoft K80-00038**

# Microsoft Wireless Optical Mouse - Steel Blue User Manual

Model: K80-00038

Brand: Microsoft

## 1. INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, and maintenance of your Microsoft Wireless Optical Mouse - Steel Blue. Designed for comfort and efficiency, this mouse features advanced optical tracking and wireless connectivity for a clutter-free workspace. Please read this manual thoroughly to ensure optimal performance and longevity of your device.

Wireless freedom  
in a stylish design

Microsoft®



*Discover the Difference*  
Microsoft® Hardware

**TILT WHEEL:** 4-way scrolling for control and efficiency

**COMFORT:** The contour shape provides an enhanced grip

**EXTENDED BATTERY LIFE:** More than six months of battery life\*



## Microsoft® Wireless Optical Mouse 3000

Tilt Wheel | 6+ Months Battery Life | Customizable Buttons



PC | MAC • USB | PS/2

MICROSOFT®  
Optical Technology

Image: The retail packaging for the Microsoft Wireless Optical Mouse 3000, highlighting its key features and compatibility.

## 2. PACKAGE CONTENTS

Verify that all items are present in the package:

- Microsoft Wireless Optical Mouse - Steel Blue
- Wireless Receiver (USB/PS/2 compatible)
- USB to PS/2 Adapter (if applicable)
- 2 AA Batteries
- Software Installation CD (IntelliType Pro)
- User Guide/Booklet

## 3. SETUP GUIDE

### 3.1. Battery Installation

1. Locate the battery compartment on the underside of the mouse.
2. Open the battery compartment cover.
3. Insert the two (2) AA batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
4. Close the battery compartment cover securely.

### 3.2. Connecting the Wireless Receiver

The wireless receiver can be connected via a USB port or a PS/2 port using the provided adapter.

- **USB Connection:** Plug the USB connector of the receiver directly into an available USB port on your computer.
- **PS/2 Connection:** Attach the USB to PS/2 adapter to the USB connector of the receiver, then plug the PS/2 end into the mouse (green) PS/2 port on your computer.

### 3.3. Software Installation

For full functionality, including customizable buttons and advanced tilt wheel features, install the IntelliType Pro software.

1. Insert the software installation CD into your computer's CD/DVD drive.
2. Follow the on-screen prompts to complete the installation.
3. Restart your computer if prompted.

## 4. OPERATING INSTRUCTIONS

### 4.1. Basic Mouse Functions

- **Left Click:** Primary button for selecting items, opening files, and activating functions.
- **Right Click:** Secondary button for accessing context menus and additional options.
- **Scroll Wheel:** Roll the wheel up or down to scroll vertically through documents and web pages.

### 4.2. Tilt Wheel Technology

The revolutionary Tilt Wheel allows for enhanced navigation:

- **4-Way Scrolling:** In addition to vertical scrolling, tilt the wheel left or right to scroll horizontally through wide documents or web pages.
- **Window Toggling:** Depress the scroll wheel (click it down) to quickly toggle between open windows, facilitating multi-tasking.

### 4.3. Customizable Buttons

Utilize the IntelliType Pro software to customize the functions of various mouse buttons, including the scroll wheel click and side buttons (if present), to suit your workflow.

## 5. KEY FEATURES

- **Tilt Wheel Technology:** Provides 4-way scrolling for improved control and efficiency, allowing smooth navigation through documents and web pages both vertically and horizontally.
- **Ergonomic Design:** The contoured shape is designed by Microsoft ergonomics experts to provide comfortable support for your hand in a natural position. The ambidextrous design ensures comfort for both left- and right-handed users.
- **Extended Battery Life:** Experience up to six months or more of battery life, significantly reducing the frequency of battery changes.
- **Microsoft Optical Technology:** Delivers superior tracking speed and precision, resulting in accurate and responsive cursor movement on various surfaces.
- **Smart Receiver:** Features intelligent technology that alerts you to potential interference or low battery life, minimizing interruptions during use.
- **Wireless Freedom:** Eliminates the need for cables, freeing your desktop from clutter and providing greater flexibility in mouse placement.
- **Versatile Connectivity:** Offers both USB and PS/2 connection options for broad compatibility with Windows-based and Macintosh computers.

## 6. MAINTENANCE

### 6.1. Cleaning Your Mouse

To maintain optimal performance, periodically clean your mouse:

- Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution.
- Wipe the exterior of the mouse.
- For the optical sensor, use a dry cotton swab to gently remove any dust or debris. Avoid using abrasive materials or excessive moisture.

### 6.2. Battery Replacement

When the low battery indicator appears (if applicable) or mouse performance degrades, replace the batteries:

- Open the battery compartment on the underside of the mouse.
- Remove the old AA batteries.
- Insert two new AA batteries, observing the correct polarity.
- Close the battery compartment.

## 7. TROUBLESHOOTING

If you encounter issues with your Microsoft Wireless Optical Mouse, try the following solutions:

- **No Cursor Movement:**
  - Ensure the receiver is securely plugged into a USB or PS/2 port.
  - Check that the batteries are correctly inserted and not depleted. Replace if necessary.
  - Verify that the mouse is within range of the receiver (typically a few feet).
  - Try connecting the receiver to a different USB or PS/2 port.
- **Erratic Cursor Movement:**
  - Clean the optical sensor on the underside of the mouse.
  - Ensure you are using the mouse on a suitable surface. Highly reflective or transparent surfaces may cause issues. A mouse pad is recommended.



