

## Trust 12616

# Trust Soundwave 1000P PC Speaker User Manual

Model: 12616

## INTRODUCTION

This manual provides essential instructions for the setup, operation, maintenance, and troubleshooting of your Trust Soundwave 1000P PC Speaker system. Please read this manual thoroughly before using the product to ensure proper functionality and longevity.



Image: The Trust Soundwave 1000P PC Speaker system, featuring a central subwoofer unit and two compact satellite speakers, designed for computer audio. The subwoofer is typically placed on the floor, while the satellite speakers are positioned on a desk.

## SETUP INSTRUCTIONS

Follow these steps to correctly set up your Trust Soundwave 1000P PC Speaker system.

- Unpacking:** Carefully remove all components from the packaging. Ensure you have the subwoofer, two satellite speakers, and all necessary cables.
- Speaker Placement:**
  - Place the subwoofer on the floor, preferably near your computer desk, to optimize bass response. The vertical bass reflex design benefits from clear space around it.
  - Position the two satellite speakers on your desk, equidistant from your listening position, for optimal stereo sound.
- Connecting Satellite Speakers:** Connect the cables from the satellite speakers to the corresponding output ports on the subwoofer unit. Ensure a secure connection.
- Connecting to Audio Source (PC):** Connect the 3.5mm audio jack cable from the subwoofer to the audio output port (usually green) on your computer's sound card.
- Power Connection:** Plug the power cable from the subwoofer into a standard electrical outlet.

6. **Initial Power On:** Turn on the speaker system using the power control, typically located on the subwoofer or a wired remote.

## OPERATING THE SPEAKERS

Once set up, you can begin using your Soundwave 1000P speakers.

- **Power On/Off:** Use the main power switch or button to turn the system on or off. An indicator light may confirm the power status.
- **Volume Control:** Adjust the overall volume using the dedicated volume knob or controls. Start with a low volume and gradually increase it.
- **Bass Adjustment:** The subwoofer features an adjustable bass control. Rotate the bass knob to achieve your desired level of deep bass.
- **3D Sound Switch:** Activate or deactivate the 3D sound feature using the designated switch. Experiment with this setting to find your preferred audio experience for different content.
- **Audio Input:** The system primarily uses an AUX connection. Ensure your audio source is playing sound through its 3.5mm audio output.

## MAINTENANCE AND CARE

Proper maintenance ensures the longevity and optimal performance of your speaker system.

- **Cleaning:**
  - Disconnect the power before cleaning.
  - Use a soft, dry cloth to wipe down the speaker surfaces.
  - Do not use liquid cleaners, aerosols, or abrasive materials, as these can damage the finish or internal components.
- **Placement:** Avoid placing speakers in direct sunlight, near heat sources, or in areas with high humidity. Ensure adequate ventilation around the subwoofer.
- **Cable Management:** Keep cables tidy and avoid sharp bends or kinks to prevent damage.
- **Storage:** If storing the speakers for an extended period, disconnect them from power, clean them, and store them in a dry, cool place, preferably in their original packaging.

## TROUBLESHOOTING GUIDE

If you encounter issues with your Trust Soundwave 1000P speakers, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
No sound from speakers.	<ul style="list-style-type: none"><li>• Power not connected or turned on.</li><li>• Audio cable disconnected or faulty.</li><li>• Volume too low.</li><li>• Incorrect audio output selected on PC.</li></ul>	<ul style="list-style-type: none"><li>• Ensure power cable is securely plugged in and speakers are turned on.</li><li>• Check 3.5mm audio cable connection to both speakers and PC. Try a different cable if available.</li><li>• Increase speaker volume and PC volume.</li><li>• Verify PC audio settings to ensure the correct output device is selected.</li></ul>

Problem	Possible Cause	Solution
Distorted or unclear sound.	<ul style="list-style-type: none"><li>• Volume too high.</li><li>• Poor audio source quality.</li><li>• Loose cable connections.</li></ul>	<ul style="list-style-type: none"><li>• Reduce volume on both speakers and PC.</li><li>• Test with a different audio source or file.</li><li>• Check all cable connections for tightness.</li></ul>
Subwoofer not producing bass.	<ul style="list-style-type: none"><li>• Bass control knob set too low.</li><li>• Subwoofer not powered.</li></ul>	<ul style="list-style-type: none"><li>• Increase the bass control knob on the subwoofer.</li><li>• Ensure the subwoofer unit is receiving power and is turned on.</li></ul>

## PRODUCT SPECIFICATIONS

Key technical details for the Trust Soundwave 1000P PC Speaker system.

- **Model Number:** 12616
- **Brand:** Trust
- **Speaker Type:** Subwoofer (2.1 system)
- **Maximum Peak Output Power:** 1000 Watt
- **RMS Wattage:** 7 Watt (5 + 2 x 1 Watt RMS)
- **Connectivity Technology:** AUX (3.5mm jack)
- **Audio Output Mode:** Stereo
- **Power Source:** Wired Electric
- **Item Weight:** 10 g
- **Mounting Type:** Tabletop Mount (for satellites), Floor (for subwoofer)
- **Control Method:** Touch

## WARRANTY INFORMATION

This product comes with a **Limited Warranty**. For specific terms and conditions, including warranty duration and claim procedures, please refer to the warranty card included with your purchase or visit the official Trust website. Keep your proof of purchase for warranty claims.

## CUSTOMER SUPPORT

For further assistance, technical support, or inquiries not covered in this manual, please visit the official Trust support website or contact their customer service department. Contact details can typically be found on the manufacturer's website or product packaging.

Official Trust Website: [www.trust.com](http://www.trust.com)