

## Flymo 963351301

# Flymo Turbo Lite 350 Lawnmower User Manual

Model: 963351301

## 1. INTRODUCTION

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your Flymo Turbo Lite 350 Lawnmower. Please read this manual thoroughly before using the appliance and keep it for future reference.

The Flymo Turbo Lite 350 is an electric hover mower designed for quick and easy lawn maintenance. It operates on a cushion of air, making it highly maneuverable.



Figure 1: Flymo Turbo Lite 350 Lawnmower. This image shows the complete lawnmower, featuring its orange body, grey handle assembly, and the characteristic hover skirt at the base.

## 2. SAFETY INFORMATION

Always observe the following safety precautions to reduce the risk of injury or damage:

- Read all instructions carefully before use.
- Keep hands and feet away from the cutting blade.
- Do not operate the mower in wet conditions or rain.
- Ensure the power cable is kept clear of the cutting area.
- Always disconnect from the power supply before cleaning, adjusting, or if the cable is damaged.
- Wear appropriate personal protective equipment, including sturdy footwear and eye protection.
- Do not allow children or untrained persons to operate the mower.
- Inspect the area to be mowed and remove any objects that could be thrown by the blade.

### 3. ASSEMBLY AND SETUP

The Flymo Turbo Lite 350 requires minimal assembly. Follow these steps:

1. **Handle Assembly:** Attach the upper handle to the lower handle using the provided fasteners. Ensure the handles are securely tightened.
2. **Cable Management:** Secure the power cable along the handle using the clips provided to prevent it from interfering with operation.
3. **Blade Installation/Check:** Ensure the metal blade is correctly installed and secured. Refer to the diagram for proper orientation.
4. **Height of Cut Adjustment:** The mower features four heights of cut. To adjust, turn the mower upside down and reposition the spacers on the blade bolt to achieve the desired cutting height. Refer to the markings for guidance.
5. **Power Connection:** Connect the mower's power cable to a suitable outdoor extension lead, ensuring the connection is secure and protected from moisture.



Figure 2: Handle Assembly Detail. This image highlights the grey handle structure with orange grip areas and the control switch, demonstrating where the handle components connect.

## 4. OPERATING INSTRUCTIONS

To operate your Flymo Turbo Lite 350 Lawnmower:

1. **Pre-Operation Check:** Before each use, inspect the mower for any damage, loose parts, or worn blades. Ensure the power cable is in good condition.
2. **Starting the Mower:**
  - Plug the mower into a suitable power outlet.
  - Press and hold the safety 'lock off' button on the handle.
  - Simultaneously squeeze the dual handle controls (Advanced Switch System) to engage the motor.
  - Once the motor starts, you can release the safety button, but keep the dual controls squeezed.
3. **Mowing Technique:**

- Push the mower forward in overlapping strips.
- Due to its hover design, the mower will float slightly above the grass, making it easy to maneuver.
- Avoid mowing over the power cable. Always keep the cable behind you.

4. **Stopping the Mower:** Release the dual handle controls. The motor will stop immediately.
5. **After Mowing:** Disconnect the mower from the power supply.

## 5. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your mower.

- **Cleaning:** After each use, disconnect the power and clean the underside of the mower and the blade. Use a brush or cloth; do not use water jets.
- **Blade Care:** Regularly inspect the metal blade for sharpness and damage. A blunt or damaged blade can affect cutting performance. Replace the blade if necessary, ensuring it is a genuine Flymo replacement part.
- **Storage:** Store the mower in a dry, secure place, away from direct sunlight and extreme temperatures. The handle can be folded for compact storage.
- **Cable Inspection:** Periodically check the power cable for cuts, abrasions, or signs of wear. If damaged, have it replaced by a qualified electrician.

## 6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Mower does not start.	No power supply; safety switch not engaged; motor overload.	Check power connection; ensure safety button and dual controls are pressed correctly; allow motor to cool if overloaded.
Poor cutting performance.	Blunt or damaged blade; incorrect cutting height; long or wet grass.	Sharpen or replace blade; adjust cutting height; avoid mowing very long or wet grass.
Mower vibrates excessively.	Damaged or unbalanced blade; loose components.	Inspect and replace blade if damaged; check all fasteners are tight.

If the problem persists after attempting these solutions, please contact an authorized service center.

## 7. SPECIFICATIONS

Feature	Detail
Model	Flymo Turbo Lite 350

Feature	Detail
Item Model Number	963351301
Power Source	Corded Electric
Voltage	230 Volts
Wattage	1400 watts
Cutting Width	33 cm (metal blade)
Heights of Cut	Four
Item Weight	7.8 kg
Package Dimensions	68 x 50.4 x 33.8 cm
Manufacturer	Husqvarna

## 8. WARRANTY AND SUPPORT



For information regarding warranty coverage, product registration, or technical support, please refer to the official Flymo website or contact your local authorized Flymo dealer. Keep your proof of purchase for warranty claims.





**Contact Information:** Please visit [www.flymo.com](http://www.flymo.com) for the most up-to-date contact details and support resources.

© 2024 Flymo. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.

### Related Documents - 963351301

	<p><a href="#">FLYMO H400 Cylinder Lawnmower: Operating Instructions and Safety Guide</a></p> <p>Comprehensive operating instructions, safety guidelines, maintenance tips, and troubleshooting for the FLYMO H400 Cylinder Lawnmower. Learn how to use and care for your lawnmower.</p>
	<p><a href="#">Flymo SimpliGlide Electric Hover Lawnmower Operator's Manual</a></p> <p>This operator's manual provides essential information for the safe and effective use of the Flymo SimpliGlide electric hover lawnmower. It covers assembly, operation, maintenance, troubleshooting, technical specifications, and warranty details for models SimpliGlide 300, 330, and 360.</p>

	<p><a href="#">Flymo Glider Compact 330AX Electric Lawnmower Operator's Manual</a></p> <p>Comprehensive operator's manual for the Flymo Glider Compact 330AX electric lawnmower, covering safety guidelines, assembly, operation, maintenance, troubleshooting, technical specifications, and warranty information.</p>
	<p><a href="#">Flymo EasiGlide Electric Hover Lawnmower Operator's Manual</a></p> <p>Comprehensive operator's manual for the Flymo EasiGlide electric hover lawnmower, covering safety, assembly, operation, maintenance, storage, troubleshooting, technical data, and warranty information. Includes model details and usage guidelines.</p>
	<p><a href="#">Flymo EasiLife Robotic Lawn Mower Quick Guide: Installation and Operation</a></p> <p>Concise quick guide for Flymo EasiLife 200, 350, and 500 robotic lawn mowers. Learn how to install the charging station, boundary wire, guide wire, and start/stop your mower. Visit <a href="http://flymo.com/uk">flymo.com/uk</a> for full details and support.</p>
	<p><a href="#">Flymo EasiBlowVac P4A 18V Cordless Garden Blower Vacuum Operator's Manual</a></p> <p>Operator's manual for the Flymo EasiBlowVac P4A 18V cordless garden blower vacuum. Includes safety instructions, assembly, operation, maintenance, troubleshooting, and technical data for models Art. 9707657-01 and Art. 9707658-01.</p>