

[manuals.plus](#) /

› [Energizer](#) /

› [Energizer 377 Silver Oxide Watch/Electronic Battery User Manual](#)

Energizer 377

Energizer 377 Silver Oxide Watch/Electronic Battery User Manual

Model: 377 (WAC5150)

INTRODUCTION

This manual provides essential information for the safe and effective use of Energizer 377 Silver Oxide Watch/Electronic Batteries. These batteries are designed to provide reliable power for a variety of small electronic devices, including watches.

- Energizer Silver Oxide Watch/Electronic Batteries
- Bright clear package graphics with helpful icons
- Cross-reference information on front of package
- Large type clearly indicates cell size

SAFETY INFORMATION

WARNING: Keep batteries away from small children. Swallowing may lead to serious injury or death. If swallowed, seek immediate medical attention.

- Keep away from small children. If swallowed, promptly see doctor; have doctor phone 202-625-3333 collect.
- Do not dispose of in fire or charge - may explode or leak causing injury.
- Always store batteries in their original packaging until ready for use.
- Do not mix old and new batteries, or different types of batteries.
- Ensure correct polarity (+/-) when installing.

PRODUCT OVERVIEW

The Energizer 377 battery is a silver oxide button cell battery, providing 1.55 Volts of power. It is commonly used in watches and other small electronic devices.



Image: Energizer 377 Silver Oxide Watch/Electronic Batteries in child-resistant packaging. The package clearly displays 'Energizer', '377', 'Silver Oxide', and '1.55 V', along with icons for watch and electronic device compatibility. Two button cell batteries are visible through the blister pack.

INSTALLATION INSTRUCTIONS

Replacing a watch battery requires care and precision. If you are unsure, consult a professional watch technician.

- 1. Prepare Your Workspace:** Work on a clean, well-lit surface. Use a soft cloth or mat to prevent scratching your watch.
- 2. Open the Watch Case:** Depending on your watch model, you may need a specialized tool to open the case back. This could be a case back opener for screw-on backs or a thin blade for snap-on backs. Exercise caution to avoid damaging the case or internal components.
- 3. Locate the Old Battery:** Once the case is open, identify the existing battery. Note its orientation (which side is facing up).
- 4. Remove the Old Battery:** Carefully use non-metallic tweezers or a small screwdriver to gently pry out the old battery. Avoid touching the watch's internal mechanisms.
- 5. Insert the New Battery:** Place the new Energizer 377 battery into the battery compartment, ensuring the correct polarity (+/-) matches the original battery's orientation. The positive (+) side is typically marked on the

battery and should face upwards.

6. **Test the Watch:** Before closing the case, check if the watch is functioning correctly (e.g., hands moving, digital display active).
7. **Close the Watch Case:** Carefully reattach the case back, ensuring it is securely sealed to maintain water resistance (if applicable).

USAGE AND STORAGE

Energizer 377 batteries are designed for single use and are not rechargeable. For optimal performance and safety, follow these guidelines:

- Use batteries only in devices specified by the manufacturer.
- Store unused batteries in a cool, dry place at room temperature.
- Keep batteries in their original packaging to prevent short-circuiting.
- Do not expose batteries to excessive heat or direct sunlight.

MAINTENANCE

These batteries require no maintenance. However, proper handling and storage are crucial for their longevity and safety.

- Regularly check your device for signs of battery leakage or corrosion. If found, remove the battery immediately and clean the compartment.
- Dispose of used batteries responsibly according to local regulations. Many communities offer battery recycling programs.

TROUBLESHOOTING

If your device does not function after installing a new battery, consider the following:

- **Incorrect Polarity:** Double-check that the battery is inserted with the correct positive (+) and negative (-) orientation.
- **Improper Contact:** Ensure the battery is seated firmly in its compartment and that the contact points are clean and free of debris or corrosion.
- **Device Issue:** The problem might not be the battery. The device itself may have a malfunction.
- **Expired Battery:** Although new, check the expiry date on the packaging.
- **Professional Assistance:** If the issue persists, consult a qualified technician for your device.

SPECIFICATIONS


Feature	Detail
Brand	Energizer
Model Number	WAC5150 (377)
Battery Cell Composition	Silver Oxide

Battery Capacity	1.55 Volts
Unit Count	2 Count (Pack of 1)
Item Weight	0.634 ounces
Recommended Uses	Watch, Electronic Devices

WARRANTY AND SUPPORT

For specific warranty information or product support, please refer to the official Energizer website or contact their customer service directly. Keep your purchase receipt as proof of purchase.

Related Documents - 377

 <p>QUICK START GUIDE EIP1-1003 v1.2</p>	<p>Energizer Smart WiFi Indoor Camera EIP1-1003 Quick Start Guide</p> <p>Get started quickly with the Energizer Smart WiFi Indoor Camera (EIP1-1003). This guide provides essential setup, installation, and operational information for your home security needs.</p>
 <p>QUICK START GUIDE EOD1-1002-2002 v1.2</p>	<p>Energizer Smart WiFi Video Doorbell Quick Start Guide EOD1-1002-2002</p> <p>Quick start guide for the Energizer Smart WiFi Video Doorbell (Model EOD1-1002-2002). Learn how to set up, connect, and use your video doorbell with step-by-step instructions and troubleshooting tips.</p>
 <p>QUICK START GUIDE EOD1-1002-2002 v1.2</p>	<p>Energizer Smart WiFi Video Doorbell Quick Start Guide EOD1-1002-2002</p> <p>Get started with your Energizer Smart WiFi Video Doorbell (EOD1-1002-2002). This quick start guide covers setup, app connection, live view, recording, and troubleshooting for seamless home security.</p>
 <p>Step 1 Smart Video Doorbell EOD1-1001-SIL QUICK START GUIDE v1.3</p>	<p>Energizer Smart Video Doorbell EOD1-1001-SIL Quick Start Guide</p> <p>A quick start guide for the Energizer Smart Video Doorbell (Model EOD1-1001-SIL), covering package contents, app pairing, setup, voice activation with Alexa and Google Assistant, and troubleshooting.</p>



[Energizer EOD1-1002-2KB Smart WiFi Video Doorbell Quick Start Guide](#)

Get started quickly with the Energizer EOD1-1002-2KB Smart 5GHz WiFi Video Doorbell Wired. This guide provides essential setup and installation instructions for your smart home security device.

[Energizer ALSRL7SMART Lantern: Setup and Compliance Guide](#)

Instructions for pairing the Energizer ALSRL7SMART Lantern with the mobile app, along with FCC and IC compliance statements.