

[Manuals.plus](#) /

› [DURACELL](#) /

› DURACELL LR44 Alkaline Button Coin Cell Battery User Manual

DURACELL LR44

DURACELL LR44 Alkaline Button Coin Cell Battery User Manual

Model: LR44

1. INTRODUCTION

This user manual provides important information regarding the safe and effective use of DURACELL LR44 Alkaline Button Coin Cell Batteries. Please read these instructions carefully before use and retain them for future reference. These batteries are designed for use in various small electronic devices, including calculators, watches, toys, and medical devices.

2. PRODUCT OVERVIEW

The DURACELL LR44 is a 1.5-volt alkaline button coin cell battery. This product typically comes in a 2-pack. It is also known by alternative codes such as A76, V13GA, and 76A.



Image 1: DURACELL LR44 Alkaline Button Coin Cell Battery. This image shows the individual battery cell.

LEAKAGE PREVENTION



Image 2: DURACELL LR44 Battery Packaging. This image displays the battery in its retail packaging, indicating it is a 2-pack.

3. SETUP AND INSTALLATION

1. **Identify Battery Compartment:** Locate the battery compartment on your device. Refer to your device's instruction manual for specific guidance.
2. **Open Compartment:** Carefully open the battery compartment. This may require a small screwdriver or a coin, depending on the device.
3. **Observe Polarity:** Note the correct polarity (+ and -) indicated inside the battery compartment.
4. **Insert Battery:** Insert the LR44 battery, ensuring the positive (+) side aligns with the positive terminal and the negative (-) side aligns with the negative terminal. Incorrect insertion can damage the device or battery.
5. **Close Compartment:** Securely close the battery compartment.

Warning: Keep batteries out of reach of children. Swallowing can lead to serious injury or death.

4. OPERATING INSTRUCTIONS

Once properly installed, the LR44 battery will power your compatible device. There are no specific operating instructions for the battery itself beyond correct installation. If your device does not power on after battery installation, refer to the Troubleshooting section of this manual or your device's manual.

5. MAINTENANCE AND STORAGE

- **Storage:** Store unused batteries in their original packaging in a cool, dry place at room temperature. Avoid extreme temperatures and direct sunlight.
- **Cleaning:** If battery contacts become dirty, gently wipe them with a clean, dry cloth. Do not use abrasive materials or liquids.
- **Leakage:** If a battery shows signs of leakage, handle it with gloves and dispose of it properly. Avoid contact with skin and eyes.
- **Replacement:** Replace all batteries in a device at the same time. Do not mix old and new batteries, or different types of batteries.

6. TROUBLESHOOTING

- **Device Not Powering On:**
 - Check that the batteries are inserted with the correct polarity (+ and -).
 - Ensure the battery compartment is securely closed.
 - Verify that the batteries are new and not depleted.
 - Inspect battery contacts for dirt or corrosion and clean if necessary.
 - Test the device with a new set of batteries.
- **Short Battery Life:**
 - Ensure the device is not left on when not in use.
 - Check if the device has a high power consumption.
 - Verify that the batteries are stored correctly when not in use.

7. SPECIFICATIONS

Feature	Detail
Model Number	LR44
Battery Cell Type	Alkaline
Voltage	1.5 Volts
Amperage	76 Amps
Reusability	Single Use
Unit Count	2 Count
Item Dimensions	0.46 x 0.21 x 0.46 inches

Item Weight	0.01 Kilograms (approx. 4 Grams per battery)
Country of Origin	China

8. SAFETY INFORMATION

- **Keep out of reach of children. Swallowing button batteries can cause severe internal burns in as little as 2 hours, leading to serious injury or death. If ingestion is suspected, seek immediate medical attention.**
- Do not recharge, disassemble, heat, or dispose of in fire. Batteries may explode or leak.
- Do not short-circuit the battery terminals.
- Do not mix new and used batteries, or different brands/types of batteries.
- Store batteries in their original packaging until ready for use.
- If battery fluid comes into contact with skin or eyes, immediately flush with plenty of water and seek medical attention.

9. DISPOSAL INFORMATION

Proper disposal of batteries is important for environmental protection. Do not dispose of batteries in household waste. Please recycle batteries at designated collection points or return them to the point of purchase. Check local regulations for specific disposal requirements.

10. WARRANTY AND SUPPORT

DURACELL LR44 batteries are typically covered by a standard return policy, allowing for refund or replacement within 30 days of purchase if the product is defective. For specific warranty details or customer support, please refer to the official DURACELL website or contact their customer service directly. Always retain your proof of purchase.
