

Manuals.plus /

- › Duracell /
- › Duracell Coppertop 9V Battery User Manual

Duracell MN1604B4

Duracell Coppertop 9V Alkaline Batteries

Model: MN1604B4

[Introduction](#) [Setup](#) [Operating](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Safety](#)
[Information](#) [Warranty & Support](#)

1. INTRODUCTION

Duracell Coppertop 9V alkaline batteries are designed to provide reliable, long-lasting power for a wide range of everyday devices. These batteries are suitable for use in household and office electronics, ensuring consistent performance when you need it most.



Image: A blister pack containing four Duracell Coppertop 9V batteries, highlighting the 'Guaranteed 5 Years in Storage' feature.

2. SETUP: BATTERY INSTALLATION

To install Duracell Coppertop 9V batteries, follow these general steps:

1. **Identify Battery Compartment:** Locate the battery compartment on your electronic device. This is often found on the back, bottom, or side of the device.
2. **Open Compartment:** Open the battery compartment cover. This may involve sliding a latch, pressing a button, or unscrewing a small screw.
3. **Observe Polarity:** Note the polarity markings (+ and -) inside the battery compartment. These indicate the correct orientation for the battery.
4. **Insert Battery:** Insert the 9V battery, aligning the positive (+) terminal of the battery with the positive (+) marking in the compartment, and the negative (-) terminal with the negative (-) marking. The 9V battery has distinct male and female terminals that will only connect one way.
5. **Close Compartment:** Securely close the battery compartment cover.

Always refer to your device's specific instruction manual for detailed battery installation procedures.

3. OPERATING GUIDELINES

Duracell Coppertop 9V batteries are designed for immediate and reliable power delivery. Once installed correctly, your device should function as intended.

POWER YOU CAN TRUST



Image: Visual representation of common devices powered by Duracell batteries, emphasizing 'Power You Can Trust'.

- **Device Compatibility:** These batteries are suitable for a wide range of devices including toys, remote controls, flashlights, calculators, clocks, radios, wireless mice, and keyboards.
- **Performance:** Expect consistent and long-lasting power for your devices. Performance duration will vary based on the device's power consumption.
- **Battery Life Indicator:** Some devices may have a low battery indicator. Replace batteries promptly when this indicator appears to ensure uninterrupted operation.



Image: A Duracell 9V battery prominently displayed with the text 'LONG LASTING POWER', indicating its primary benefit.

4. MAINTENANCE AND STORAGE

Proper maintenance and storage can extend the life and ensure the readiness of your Duracell Coppertop 9V batteries.

- **Storage:** Store unused batteries in their original packaging in a cool, dry place at room temperature. Avoid extreme temperatures and direct sunlight.
- **Shelf Life:** Duracell Coppertop 9V batteries are guaranteed for 5 years in storage.
- **Disposal:** Dispose of used batteries according to local regulations. Do not dispose of batteries in fire.
- **Cleaning:** If battery terminals become dirty, gently wipe them with a clean, dry cloth.
- **Leakage Prevention:** Remove batteries from devices that will not be used for extended periods to prevent potential leakage and damage to the device.

**GUARANTEED
5 YEARS
IN STORAGE**

Image: A graphic displaying the text 'GUARANTEED 5 YEARS IN STORAGE', highlighting the battery's long shelf life.

5. TROUBLESHOOTING

If your device is not functioning correctly with new Duracell Coppertop 9V batteries, consider the following:

Problem	Possible Cause	Solution
Device does not turn on.	Incorrect battery installation.	Check battery polarity (+/-) and ensure batteries are inserted correctly.
Device functions intermittently.	Low battery power or loose connection.	Replace batteries with new ones. Ensure batteries are seated firmly in the compartment.
Battery compartment feels warm.	Short circuit or incorrect battery type.	Immediately remove batteries. Ensure no foreign objects are in the compartment. Use only recommended battery types.
Device performance is poor.	Batteries are nearing end of life.	Replace all batteries with a fresh set.

6. SPECIFICATIONS

- **Brand:** Duracell
- **Model Number:** MN1604B4
- **Battery Cell Composition:** Alkaline
- **Battery Capacity:** 9 Volts
- **Number of Batteries:** 4 (included in pack)
- **Product Dimensions:** 0.4 x 6 x 4.5 inches
- **Item Weight:** 7 ounces
- **Recommended Uses:** Clock, Radio, Remote Controls, Calculators, Flashlights, Wireless Keyboard, Wireless Mouse.
- **Shelf Life:** Guaranteed for 5 years in storage
- **ASIN:** B000K2NW08

7. IMPORTANT SAFETY INFORMATION

WARNING:

- May explode or leak, and cause burn injury, if recharged, disposed of in fire, mixed with a different battery type, inserted backwards or disassembled.
- Replace all used batteries at the same time.
- Do not carry batteries loose in your pocket or purse.
- Do not remove the battery label.
- Keep batteries away from children.

- If swallowed, consult a physician at once. For information on treatment, call (202) 625-3333 collect.

8. WARRANTY & SUPPORT

Duracell guarantees these 9V batteries against defects in material and workmanship. For specific warranty claims or support, please refer to the official Duracell website or contact their customer service.

- **Warranty Coverage:** Guaranteed against defects in material and workmanship.
- **Limitations:** Warranty does not cover misuse of the product.
- **Contact Support:** Visit the official Duracell website for customer service and support information.