



Manuals.plus /

› Maxx Air /

› Maxx Air 20-Inch High Velocity Floor Fan (Model HVFF20UPS) User Manual

Maxx Air HVFF20UPS

Maxx Air 20-Inch High Velocity Floor Fan (Model HVFF20UPS) User Manual

1. INTRODUCTION AND OVERVIEW

This manual provides essential information for the safe and efficient operation of your Maxx Air 20-Inch High Velocity Floor Fan, model HVFF20UPS. This fan is designed for indoor use to provide powerful air circulation in various settings.

Key features include:

- Powerful airflow with 2250 CFM for efficient air circulation.
- Versatile 3-speed control to adapt to various ventilation needs.
- Sturdy metal construction for durability and long-lasting performance.
- Adjustable tilt functionality to direct airflow precisely.

2. SAFETY INFORMATION

Please read and understand all safety instructions before using this fan. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always unplug the fan before cleaning, servicing, or moving.
- Do not operate the fan with a damaged cord or plug. If the cord or plug is damaged, contact qualified service personnel.
- Keep fingers and other objects away from the fan blades and openings during operation.
- Do not use this fan near water or in wet locations.
- Ensure the fan is placed on a stable, level surface to prevent tipping.
- Do not run the power cord under carpeting or cover it with throw rugs, runners, or similar coverings. Arrange the cord away from traffic areas to avoid tripping hazards.
- This fan is for indoor use only.

3. PACKAGE CONTENTS

Verify that all components are present:

- Maxx Air 20-Inch High Velocity Floor Fan unit
- Floor stand/bracket (pre-attached or requiring minor assembly)
- Instruction Manual

4. SETUP

Your Maxx Air fan is designed for versatile placement, either on the floor using its integrated stand or mounted to a wall (mounting hardware not included).

4.1 Attaching the Floor Stand

If the floor stand is not pre-attached, align the stand with the designated mounting points on the fan's body. Secure it using the provided screws. Typically, only two screws are required for assembly.

4.2 Placement

Place the fan on a firm, level surface. Ensure there is adequate space around the fan for proper air intake and exhaust. For optimal air circulation, position the fan to direct airflow towards the desired area.



Figure 1: Front view of the Maxx Air 20-inch high velocity floor fan.



**Adjustable
Tilt**



**3 Speed
Operation**



**Carry
Handle**



**3 Prong
Plug**

Figure 2: Side view of the fan, showing adjustable tilt and key features.




Figure 3: Fan size comparison with a person.

5. OPERATING INSTRUCTIONS

The Maxx Air fan features simple controls for ease of use.

5.1 Power Connection

Plug the fan's 3-prong power cord into a standard 120-volt grounded electrical outlet.

5.2 Speed Control

Locate the control knob on the fan's motor housing. Rotate the knob to select one of the three available speed settings: Low (1), Medium (2), or High (3). To turn the fan off, rotate the knob to the '0' position.

5.3 Adjusting Tilt

To adjust the angle of the fan head, loosen the large knob on the side of the fan's frame. Tilt the fan to the desired upward or downward angle, then tighten the knob securely to lock it in place.



Figure 4: Close-up views of the fan's control knob, tilt adjustment, carry handle, and power plug.



Figure 5: Rear view of the fan, showing the speed control knob and power cord.

6. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your fan.

6.1 Cleaning

- Always unplug the fan before cleaning.
- Use a soft, damp cloth to wipe the exterior surfaces of the fan.
- To clean the fan blades, carefully remove the front grille (if applicable and designed for removal) and wipe the blades with a soft cloth. Ensure the grille is securely reattached before operating.
- Do not use abrasive cleaners or solvents, as these may damage the fan's finish.

6.2 Storage

When not in use for extended periods, store the fan in a cool, dry place, preferably in its original packaging, to

protect it from dust and damage.

7. TROUBLESHOOTING

If your fan is not operating correctly, consult the following common issues and solutions:

Problem	Possible Cause	Solution
Fan does not turn on	No power to the unit; Power switch is off; Damaged power cord/plug	Check power outlet and circuit breaker; Ensure speed control knob is set to a speed (1, 2, or 3); Inspect power cord for damage, contact support if damaged.
Reduced airflow	Fan blades or grille are dirty; Fan is too far from the area needing circulation	Clean fan blades and grille; Reposition the fan closer to the desired area.
Unusual noise or vibration	Loose parts; Fan not on a stable surface; Obstruction in fan blades	Check for any loose screws or components; Place fan on a stable, level surface; Unplug fan and check for obstructions around blades.

8. SPECIFICATIONS

Feature	Detail
Brand	Maxx Air
Model Name	Maxx Air 20 In. High Velocity Floor Fan
Item Model Number	HVFF20UPS
Electric Fan Design	Floor Fan
Color	Gray
Power Source	Corded Electric
Voltage	120 Volts
Wattage	20 watts
Number of Power Levels	3
Air Flow Capacity	2250 Cubic Feet Per Minute (CFM)
Blade Length	20 Inches
Product Dimensions	30"D x 8"W x 6"H
Item Weight	13 Pounds
Special Features	High Velocity, Tilttable
Indoor/Outdoor Usage	Indoor
UPC	047242061253

9. WARRANTY

This Maxx Air fan comes with a **1-year limited warranty** covering parts, but not labor. Please retain your proof of purchase for warranty claims.

10. SUPPORT

For further assistance, technical support, or to inquire about replacement parts, please contact Maxx Air customer service. Refer to the official Maxx Air website or product packaging for current contact information.