

## Beka 16303094

# Beka T&T Exacto Timer with Thermometer User Manual

MODEL: 16303094

## Introduction

Thank you for choosing the Beka T&T Exacto Timer with Thermometer. This device is designed to assist you in precise cooking by monitoring temperatures and timing processes. It features a durable stainless steel construction and a clear LCD display. Please read this manual carefully before using the product to ensure proper operation and longevity.




Image of the Beka T&T Exacto Timer with Thermometer, showing its stainless steel body and digital display.

## Setup

---

1. **Battery Installation:** Locate the battery compartment on the back of the unit. Insert the required batteries (not included) according to the polarity indicators (+/-). Close the compartment securely.
2. **Probe Connection:** Connect the stainless steel temperature probe cable into the designated port on the side or back of the main unit. Ensure a firm connection.
3. **Initial Placement:** Place the main unit on a stable surface or use its integrated stand/magnet (if available) for convenient viewing. Ensure the probe cable is not kinked or exposed to direct heat sources beyond its intended use.

## Operating Instructions

---

The Beka T&T Exacto Timer with Thermometer offers both temperature monitoring and timing functions.

### Temperature Measurement

1. **Power On:** The device typically powers on automatically once batteries are installed and the probe is connected. Note that this model may not feature a dedicated power switch; to turn off, the battery may need to be removed.
2. **Unit Selection:** Use the “°C/°F” button to switch between Celsius and Fahrenheit temperature readings.
3. **Probe Insertion:** Carefully insert the stainless steel probe into the center of the food item you wish to measure, avoiding bones or fat. For liquids, ensure the probe tip is fully submerged.
4. **Reading Temperature:** The current temperature will be displayed on the LCD screen. The device can measure temperatures up to 250 °C (482 °F).

### Timer Function

1. **Setting the Timer:** Use the “MIN” and “SEC” buttons to set the desired countdown time. The timer can be programmed up to 99 minutes and 59 seconds.
2. **Starting the Timer:** Press the “START/STOP” button to begin the countdown.
3. **Pausing/Resuming:** Press “START/STOP” again to pause or resume the timer.
4. **Resetting the Timer:** To reset the timer, press and hold the “MIN” and “SEC” buttons simultaneously, or press the “CLEAR” button if available.
5. **Alarm:** An audible alarm will sound when the countdown reaches zero. Press any button to silence the alarm.

## Maintenance

---

- **Cleaning:** Wipe the main unit with a soft, damp cloth. Do not immerse the main unit in water. The stainless steel probe can be cleaned with warm, soapy water. Ensure the probe is completely dry before storage.
- **Storage:** Store the timer and probe in a clean, dry place when not in use. Avoid extreme temperatures and humidity.
- **Battery Replacement:** Replace batteries when the display becomes dim or the device stops functioning correctly. Always use the recommended battery type.

## Troubleshooting

---

- **No Display/Device Not Turning On:**

- Check battery installation and ensure correct polarity.
- Replace old or depleted batteries with new ones.
- Ensure the probe is securely connected.

- **Inaccurate Temperature Readings:**

- Ensure the probe tip is fully inserted into the center of the food item and not touching bone or the bottom of a pan.
- Verify the probe cable is not damaged.
- Test the thermometer in boiling water (100 °C / 212 °F at sea level) or ice water (0 °C / 32 °F) to check calibration. If readings are consistently off, the probe or unit may require replacement.

- **Timer Not Functioning:**

- Ensure batteries are fresh and correctly installed.
- Check that the time is set correctly before starting the countdown.

## Specifications

Model Number	16303094
Brand	Beka
Dimensions (L x W x H)	18.7 x 9 x 2.8 cm (7.36 x 3.54 x 1.1 inches)
Weight	117.93 g (0.26 lbs)
Exterior Material	Stainless Steel
Display Type	LCD
Temperature Range	Up to 250 °C (482 °F)
Timer Range	Up to 99 minutes
Power Source	Battery Operated
Included Components	Temperature Probe
Special Feature	Timer Function

## Warranty and Support

For warranty information and customer support, please refer to the documentation provided at the time of purchase or contact your retailer. You may also visit the official Beka website for further assistance.