

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [OSRAM](#) /

› [OSRAM Sylvania 60A19/TS/8M/SS 10442 Incandescent Light Bulb User Manual](#)

## OSRAM 60A19/TS/8M/SS

# OSRAM Sylvania 60A19/TS/8M/SS 10442 Incandescent Light Bulb User Manual

Model: 60A19/TS/8M/SS (Part Number: 10442)

## 1. INTRODUCTION

This user manual provides essential information for the safe and effective use of your OSRAM Sylvania 60A19/TS/8M/SS 10442 Incandescent Light Bulb. This 60-watt, A19 shape bulb features an E26 medium screw base and is designed for indoor use with 120-125 volt electrical systems. Please read this manual thoroughly before installation and retain it for future reference.

## 2. SAFETY INFORMATION

- **Electrical Hazard:** Always turn off power to the fixture at the circuit breaker or fuse box before installing, removing, or cleaning the bulb. Failure to do so may result in electric shock.
- **Burn Hazard:** Light bulbs can become hot during operation. Allow the bulb to cool completely before handling.
- **Proper Voltage:** Ensure the bulb's voltage rating (120-125V) matches your electrical supply. Using an incorrect voltage can damage the bulb or electrical system.
- **Indoor Use Only:** This bulb is designed for indoor applications. Do not use in outdoor or wet locations unless specifically rated for such environments.
- **Fixture Compatibility:** Use only in fixtures designed for incandescent bulbs and rated for the bulb's wattage (60W).
- **Disposal:** Dispose of used or broken bulbs according to local regulations.

## 3. SETUP AND INSTALLATION

Follow these steps to safely install your incandescent light bulb:

1. **Turn Off Power:** Locate the light fixture's power switch and turn it to the 'OFF' position. For added safety, turn off the corresponding circuit breaker or remove the fuse.
2. **Allow Cooling:** If replacing an existing bulb, ensure it has cooled down completely before touching it.
3. **Remove Old Bulb (if applicable):** Carefully unscrew the old bulb counter-clockwise from the socket.
4. **Inspect Fixture:** Check the light fixture's socket for any damage or debris.

5. **Install New Bulb:** Gently screw the OSRAM Sylvania 60A19/TS/8M/SS bulb clockwise into the E26 medium screw base socket until it is snug. Do not overtighten.



*Image 1: A single OSRAM Sylvania 60A19 incandescent light bulb, showing the clear glass envelope and the E26 screw base. This image illustrates the bulb's physical form for installation reference.*

## 4. OPERATING INSTRUCTIONS

Once the bulb is securely installed and power is restored, operating the OSRAM Sylvania 60A19/TS/8M/SS bulb is straightforward:

- **Power On:** Turn on the light fixture's power switch. The bulb should illuminate immediately.
- **Power Off:** To turn off the light, simply switch the fixture's power switch to the 'OFF' position.

This incandescent bulb provides a warm white light (2700 Kelvin) suitable for general illumination.

## 5. MAINTENANCE

The OSRAM Sylvania 60A19/TS/8M/SS incandescent light bulb requires minimal maintenance:

- **Cleaning:** Ensure the bulb is cool and the power is off before cleaning. Wipe the bulb with a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as these can damage the bulb or create a safety hazard.
- **Replacement:** Replace the bulb when it burns out. Follow the installation steps outlined in Section 3.

## 6. TROUBLESHOOTING

If your OSRAM Sylvania 60A19/TS/8M/SS bulb is not functioning as expected, consider the following:

- **Bulb Does Not Light:**
  - Check if the power switch is in the 'ON' position.
  - Verify that the bulb is screwed in securely into the socket.
  - Check the circuit breaker or fuse for the fixture; reset if tripped or replace if blown.

- Test the bulb in another working fixture to confirm if the bulb itself is faulty.
- Ensure the fixture is receiving power.

• **Bulb Flickers:**

- Ensure the bulb is screwed in tightly. A loose connection can cause flickering.
- Check for loose wiring in the fixture or switch (consult a qualified electrician if unsure).
- Verify that the fixture is not connected to a dimmer switch unless the bulb is specifically rated as dimmable (this bulb is a standard incandescent).

If issues persist after troubleshooting, consider replacing the bulb or consulting a qualified electrician.

## 7. SPECIFICATIONS

Key technical specifications for the OSRAM Sylvania 60A19/TS/8M/SS 10442 Incandescent Light Bulb:

Feature	Specification
Brand	OSRAM / Sylvania
Model Number	60A19/TS/8M/SS (10442)
Light Type	Incandescent
Wattage	60 Watts
Bulb Shape Size	A19
Bulb Base	E26 (Medium Screw)
Voltage	120-125 Volts
Light Color	Warm White
Color Temperature	2700 Kelvin
Brightness	90 Lumens
Finish	Clear
Indoor/Outdoor Usage	Indoor
Material	Copper (base)
Item Weight	Approximately 12 ounces (for a single bulb)



*Image 2: A package containing multiple OSRAM Sylvania 60A19 incandescent light bulbs. This image provides a general view of the product as it might be supplied.*

## **8. WARRANTY AND SUPPORT**

Specific warranty information for the OSRAM Sylvania 60A19/TS/8M/SS 10442 Incandescent Light Bulb is typically provided at the point of purchase or included with the product packaging. For detailed warranty terms, conditions, and customer support, please refer to the documentation accompanying your purchase or visit the official OSRAM or Sylvania website.

For further assistance or inquiries, please contact OSRAM customer service through their official channels.