

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Amazon](#) /
- › [Amazon Kindle DX 9.7-inch E Ink Display 3G User Manual](#)

Amazon Kindle DX

Amazon Kindle DX User Manual

Model: Kindle DX (9.7-inch E Ink Display, Free 3G)

[Setup](#)

[Operating](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty & Support](#)

1. SETUP

This section guides you through the initial setup of your Amazon Kindle DX.

1.1 Unboxing and Initial Charge

Upon receiving your Kindle DX, carefully remove it from its packaging. It is recommended to fully charge the device before first use. Connect the included USB cable to the Kindle DX and a power adapter or a computer's USB port. The charging indicator light will show the charging status.

1.2 Powering On

To power on your Kindle DX, locate the power button, typically on the bottom edge of the device. Press and hold it for a few seconds until the screen activates.

1.3 Registration

Follow the on-screen prompts to register your Kindle DX to your Amazon account. This step is essential for purchasing and downloading content.

1.4 Connecting to Whispernet (3G)

The Kindle DX features free 3G wireless connectivity, known as Whispernet, which works globally. This allows you to download books and periodicals without needing a Wi-Fi connection. Ensure wireless is enabled in the device settings to utilize this feature.




Figure 1: The Kindle DX displaying a document with a graph. The device features a large E Ink screen and a physical keyboard below.

2. OPERATING YOUR KINDLE DX

Learn how to navigate and utilize the features of your Kindle DX for an optimal reading experience.

2.1 Reading and Navigation

The Kindle DX uses an E Ink display designed for comfortable reading, similar to print on paper. You can adjust font sizes for personal comfort. Page turns are performed using the dedicated page-turn buttons located on the side of the device. The 5-way controller is used for menu navigation and selecting items.



Figure 2: A hand holding the Kindle DX, which is displaying text from a novel. The large screen provides ample space for reading.

2.2 PDF Document Support

The 9.7-inch screen size and auto-orientation feature of the Kindle DX are well-suited for reading PDF documents. You can rotate the device to change the screen orientation, which can be particularly useful for viewing wider PDF layouts. While the device supports PDF, it does not offer color display, and advanced zoom functionalities may be limited.




Figure 3: The Kindle DX displaying a newspaper article. The E Ink display provides a clear, high-contrast view of text and images.

2.3 Web Browsing (Experimental)

The Kindle DX includes an experimental web browser. This browser is primarily designed for simple, text-based websites and may be slow compared to modern web browsers. It is not intended for complex or media-rich web content.

2.4 Note-Taking

You can take notes on your Kindle DX using the physical keyboard. While functional, the input speed may be slower than on devices with touchscreens or full-sized keyboards.

2.5 Battery Life Management

To maximize battery life, it is recommended to turn off the wireless (3G) feature when not actively downloading content. The Kindle DX offers extended battery life with wireless turned off, allowing for weeks of reading on a single charge.



Figure 4: A person comfortably reading the Kindle DX outdoors, demonstrating its portability and readability in various environments.

3. MAINTENANCE

Proper care ensures the longevity and optimal performance of your Kindle DX.

3.1 Cleaning the Device

Use a soft, lint-free cloth to clean the screen and body of your Kindle DX. Avoid using abrasive cleaners or solvents, as these can damage the display and finish.

3.2 Protection

While the Kindle DX is designed to be durable, it is advisable to use a protective cover or case to prevent scratches and damage from accidental drops or impacts. Avoid exposing the device to liquids or extreme temperatures.



Figure 5: A side view of the Kindle DX, highlighting its thin profile. This design makes it comfortable to hold for extended reading sessions.

4. TROUBLESHOOTING

This section addresses common issues you might encounter with your Kindle DX.

4.1 PDF Display Issues

Some users may experience difficulties with PDF documents, such as incorrect margin display or limited zoom functionality. While the Kindle DX supports PDF, its rendering capabilities may not match dedicated PDF

readers. Experiment with different zoom levels or consider converting complex PDFs to Kindle format if available.

4.2 Slow Performance or Unresponsiveness

If your Kindle DX becomes slow or unresponsive, try restarting the device. To do this, press and hold the power button for approximately 20 seconds until the device reboots. This can resolve minor software glitches.

4.3 Unable to Download Content

Ensure that the wireless (3G) feature is enabled in your device settings. Content downloads require an active Whispernet connection. If the issue persists, verify your Amazon account registration and payment methods.

5. SPECIFICATIONS

| Feature | Description |
|--------------|--|
| Display | 9.7-inch E Ink display, 16-level grayscale |
| Connectivity | Free 3G Wireless (Whispernet) |
| Storage | Approximately 3GB of available storage for content |
| Battery Life | Up to 2 weeks on a single charge with wireless off (usage dependent) |
| Input | Full QWERTY keyboard, 5-way controller |



Figure 6: The back view of the Kindle DX, showing its brushed metal finish and the Amazon Kindle logo.

6. WARRANTY & SUPPORT

For detailed warranty information and customer support, please refer to the documentation included with your Kindle DX or visit the official Amazon support website. Amazon provides resources and assistance for product-related inquiries and technical support.

You can typically find support resources by visiting [amazon.com/devicesupport](https://www.amazon.com/devicesupport) or by logging into your Amazon account and navigating to the 'Help' section.

