

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [POWER ZONE](#) /
- › [OR801118 Powerzone Power Strip User Manual](#)

## POWER ZONE OR801118

# OR801118 Powerzone Power Strip User Manual

Model: OR801118 | Brand: POWER ZONE

## PRODUCT OVERVIEW

The POWER ZONE OR801118 Power Strip is designed to convert a single wall outlet into six grounded outlets, providing expanded power access for multiple devices. It features a built-in circuit breaker for overload protection, ensuring safety and reliability for your electrical equipment.

This power strip is rated for 15 Amps, 125 Volts, and 1875 Watts, making it suitable for a variety of household and office electronics. It is UL listed, indicating compliance with safety standards.



Figure 1: The POWER ZONE OR801118 Power Strip, showing its six outlets, integrated circuit breaker switch, and attached power cord with a standard 3-prong plug.

## SAFETY INFORMATION

---

Please read and understand all safety instructions before using this product. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Do not exceed the electrical ratings of 15 Amps, 125 Volts, or 1875 Watts. Overloading the power strip can cause the circuit breaker to trip or lead to fire hazards.
- This product is designed for indoor use only. Do not expose to moisture or use in wet environments.
- Do not plug one power strip into another. This is known as "daisy-chaining" and can lead to electrical overload.
- Ensure the plug is fully inserted into the wall outlet. A loose connection can cause overheating.
- Keep children and pets away from the power strip and connected devices.
- Do not disassemble or modify the power strip. There are no user-serviceable parts inside.
- If the circuit breaker trips, unplug some devices before resetting the switch.

## SETUP

---

1. **Unpack the Power Strip:** Carefully remove the power strip from its packaging. Inspect it for any signs of damage. Do not use if damaged.
2. **Choose a Location:** Select a dry, indoor location away from water sources, heat, and direct sunlight. Ensure there is adequate ventilation around the power strip and connected devices.
3. **Plug into Wall Outlet:** Insert the power strip's straight plug firmly into a standard 3-prong, 125V grounded wall outlet. Ensure the connection is secure.
4. **Connect Devices:** Plug your electronic devices into the six available outlets on the power strip. Ensure that the total wattage of all connected devices does not exceed 1875 Watts.
5. **Activate Power:** If the power strip has an ON/OFF switch (often integrated with the circuit breaker), ensure it is in the "ON" position. The switch is typically red and clearly marked.

## OPERATING INSTRUCTIONS

---

The POWER ZONE OR801118 Power Strip is designed for simple operation.

- **Power On/Off:** The power strip features a master ON/OFF switch, which also functions as a circuit breaker. To supply power to the connected devices, press the switch to the "ON" position. To cut power to all connected devices, press the switch to the "OFF" position.
- **Overload Protection:** In the event of an electrical overload (when the total current draw exceeds 15 Amps or 1875 Watts), the built-in circuit breaker will automatically trip, cutting power to all connected devices to prevent damage and fire hazards.
- **Resetting the Circuit Breaker:** If the circuit breaker trips, first unplug some of the devices connected to the power strip to reduce the load. Then, push the circuit breaker switch back to the "ON" position to restore power. If the breaker continues to trip, consult the Troubleshooting section.

## MAINTENANCE

---

Regular maintenance helps ensure the longevity and safe operation of your power strip.

- **Cleaning:** Disconnect the power strip from the wall outlet before cleaning. Use a dry, soft cloth to wipe the

exterior. Do not use liquid cleaners or sprays directly on the power strip.

- **Inspection:** Periodically inspect the power strip, its cord, and the plug for any signs of damage, such as frayed wires, cracks, or discoloration. If any damage is observed, discontinue use immediately and replace the unit.
- **Storage:** When not in use for extended periods, store the power strip in a cool, dry place, away from direct sunlight and extreme temperatures.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
No power to connected devices.	<ul style="list-style-type: none"><li>◦ Power strip switch is OFF.</li><li>◦ Circuit breaker has tripped.</li><li>◦ Wall outlet has no power.</li><li>◦ Power strip is damaged.</li></ul>	<ul style="list-style-type: none"><li>◦ Ensure the ON/OFF switch is in the "ON" position.</li><li>◦ Reduce the load by unplugging some devices, then reset the circuit breaker.</li><li>◦ Test the wall outlet with another device. Check your home's circuit breaker panel.</li><li>◦ Discontinue use and replace the power strip.</li></ul>
Circuit breaker trips frequently.	<ul style="list-style-type: none"><li>◦ Overload (too many devices or high-power devices).</li><li>◦ Faulty device connected.</li><li>◦ Internal fault in power strip.</li></ul>	<ul style="list-style-type: none"><li>◦ Calculate total wattage of connected devices; ensure it's below 1875 Watts. Distribute devices across multiple outlets if possible.</li><li>◦ Unplug devices one by one to identify the faulty one.</li><li>◦ Discontinue use and replace the power strip.</li></ul>
Power strip feels hot.	<ul style="list-style-type: none"><li>◦ Overload.</li><li>◦ Poor ventilation.</li><li>◦ Internal damage.</li></ul>	<ul style="list-style-type: none"><li>◦ Immediately unplug all devices and the power strip from the wall. Reduce load.</li><li>◦ Ensure power strip is not covered or in an enclosed space.</li><li>◦ Discontinue use and replace the power strip.</li></ul>

## SPECIFICATIONS

<b>Model Number</b>	OR801118
<b>Brand</b>	POWER ZONE
<b>Total Power Outlets</b>	6
<b>Voltage Rating</b>	125 Volts
<b>Amperage Capacity</b>	15 Amps
<b>Wattage Rating</b>	1875 Watts
<b>Plug Format</b>	Type B (3-prong grounded)
<b>Cord Length</b>	18 inches (approximate, based on description)
<b>Item Weight</b>	9 ounces

<b>Product Dimensions (L x W x H)</b>	11.88 x 9 x 8.75 inches
<b>Certifications</b>	UL Listed
<b>Recommended Uses</b>	Apartment, Hotel, Office, Restaurant, TV (general purpose)

## WARRANTY AND SUPPORT

---

Specific warranty information is not provided in the product details. For warranty claims or technical support, please contact POWER ZONE customer service directly. Refer to the product packaging or the manufacturer's official website for contact details.

It is recommended to retain your purchase receipt as proof of purchase for any warranty-related inquiries.

---

© 2023 POWER ZONE. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.

